

Hikrobot Co., Ltd.

# ID2000 Series Industrial Code Reader

User Manual

**HIKROBOT**

# Legal Information

© Hangzhou Hikrobot Co., Ltd. All rights reserved.

## About this Document

This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the company website (<https://en.hikrobotics.com/>). Unless otherwise agreed, Hangzhou Hikrobot Co., Ltd. or its affiliates (hereinafter referred to as “Hikrobot”) makes no warranties, express or implied. Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

## Acknowledgment of Intellectual Property Rights

- Hikrobot owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties. Any part of the Document, including text, pictures, graphics, etc., belongs to Hikrobot. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKROBOT** and other Hikrobot's trademarks and logos are the properties of Hikrobot in various jurisdictions. Other trademarks and logos mentioned are the properties of their respective owners.

## LEGAL DISCLAIMER

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKROBOT MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKROBOT BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKROBOT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

YOU ACKNOWLEDGE THAT THE NATURE OF INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKROBOT SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKROBOT WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND

YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.

THE PERFORMANCE DATA IN THIS PUBLICATION IS BASED ON HIKROBOT'S INTERNAL RESEARCH/EVALUATION. ACTUAL DATA MAY VARY DEPENDING ON SPECIFIC CONFIGURATIONS AND OPERATING CONDITIONS AND HIKROBOT SHALL NOT BEAR THE CONSEQUENCES ARISING THEREFROM.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATTER PREVAILS.

## Regulatory Information

---



**Note**

These clauses apply only to the products bearing the corresponding mark or information.

---

### EU Conformity Statement



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the Directive 2014/30/EU(EMCD), Directive 2001/95/EC(GPSD) and Directive 2011/65/EU(RoHS).



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: <http://www.recyclethis.info>



Regulation (EU) 2023/1542(Battery Regulation): This product contains a battery and it is in conformity with the Regulation (EU) 2023/1542. The battery cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), or lead (Pb). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: [www.recyclethis.info](http://www.recyclethis.info).

## KC Mark Certification

Class A: The device is advised to note that as a seller or a business user (Class A) Devices and intended for use outside the Home area.

A급 기기: 이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기바라며, 가정 외의 지역에서 사용하는 것을 목적으로 합니다.

## Symbol Conventions

The symbols that may be found in this document are defined as follows.

| Symbol                                                                                           | Description                                                                                                                                                     |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Danger</b>  | Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury.                                                     |
|  <b>Caution</b> | Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results. |
|  <b>Note</b>    | Provides additional information to emphasize or supplement important points of the main text.                                                                   |

## Available Model

This manual is applicable to the ID2000 Series Industrial Code Reader.

## Contact Information

Hangzhou Hikrobot Co., Ltd.

E-mail: [global.support@hikrobotics.com](mailto:global.support@hikrobotics.com)

Website: <https://en.hikrobotics.com/>

# Contents

|                                                                                           |           |
|-------------------------------------------------------------------------------------------|-----------|
| <b>Chapter 1 Safety Instruction.....</b>                                                  | <b>1</b>  |
| 1.1 Safety Claim.....                                                                     | 1         |
| 1.2 Safety Instruction.....                                                               | 1         |
| 1.3 Electromagnetic Interference Prevention .....                                         | 3         |
| 1.4 Laser Precaution .....                                                                | 4         |
| <b>Chapter 2 Overview .....</b>                                                           | <b>5</b>  |
| 2.1 Introduction.....                                                                     | 5         |
| 2.2 Key Features .....                                                                    | 5         |
| <b>Chapter 3 Appearance .....</b>                                                         | <b>6</b>  |
| <b>Chapter 4 Installation .....</b>                                                       | <b>11</b> |
| 4.1 Installation Preparation .....                                                        | 11        |
| 4.2 Device Wiring .....                                                                   | 13        |
| 4.3 Device Installation.....                                                              | 19        |
| <b>Chapter 5 Connector and Cable .....</b>                                                | <b>20</b> |
| 5.1 ID2000M Series Devices with Network Interface.....                                    | 20        |
| 5.2 ID2000EM &ID2000EMI Series Devices with Network Interface.....                        | 23        |
| 5.3 ID2000M Series Devices with USB Interface (Without I/O Function).....                 | 26        |
| 5.4 ID2000EM & ID2000EMI Series Devices with USB Interface (Without I/O<br>Function)..... | 27        |
| 5.5 ID2000M Series Devices with USB Interface (With I/O Function).....                    | 28        |
| 5.6 ID2000EM & ID2000EMI Series Device with USB Interface (With I/O Function) .           | 31        |
| <b>Chapter 6 I/O Electrical Feature and Wiring .....</b>                                  | <b>35</b> |
| 6.1 Opto-Isolated I/O .....                                                               | 35        |
| 6.1.1 Opto-Isolated Input Circuit .....                                                   | 36        |
| 6.1.2 Opto-Isolated Output Circuit.....                                                   | 37        |
| 6.1.3 I/O Wiring .....                                                                    | 38        |
| 6.2 Non Opto-Isolated I/O .....                                                           | 39        |
| 6.2.1 Non Opto-Isolated Input Circuit .....                                               | 39        |
| 6.2.2 Non Opto-Isolated Output Circuit.....                                               | 40        |
| 6.2.3 Non Opto-Isolated Bi-Directional I/O Circuit .....                                  | 41        |

|                                                                  |    |
|------------------------------------------------------------------|----|
| 6.2.4 I/O Wiring .....                                           | 43 |
| 6.3 RS-232 Serial Port .....                                     | 44 |
| Chapter 7 Device Debugging .....                                 | 46 |
| 7.1 Debugging via Configuration Codes .....                      | 46 |
| 7.2 Client Software Installation .....                           | 47 |
| 7.3 Device Connection .....                                      | 47 |
| 7.3.1 Preparations .....                                         | 48 |
| 7.3.2 Device Discovery .....                                     | 51 |
| 7.3.3 Pre-Connection Configuration .....                         | 53 |
| 7.3.4 Device Connecting .....                                    | 56 |
| 7.3.5 Post-Connection Configuration .....                        | 56 |
| 7.3.6 Device Group .....                                         | 60 |
| 7.4 Quick Start Guide .....                                      | 61 |
| Chapter 8 Configuration Codes .....                              | 65 |
| 8.1 Set Configuration Codes of Code Type .....                   | 65 |
| 8.2 Set Configuration Codes of Code Scanning Mode .....          | 68 |
| 8.3 Set Configuration Codes of Code Color .....                  | 68 |
| 8.4 Set Configuration Codes of Code Reading Quantity .....       | 69 |
| 8.5 Set Configuration Codes of Data Processing .....             | 71 |
| 8.6 Set Configuration Codes of Aiming System .....               | 73 |
| 8.7 Set Configuration Codes of Light Source .....                | 73 |
| 8.8 Set Configuration Codes of Buzzer .....                      | 74 |
| 8.9 Set Configuration Codes of USB Communication .....           | 75 |
| 8.10 Set Configuration Codes of Serial Port .....                | 76 |
| 8.11 Set Configuration Codes of Sending Device Information ..... | 78 |
| 8.12 Set Configuration Codes of Trigger .....                    | 78 |
| 8.13 Set Configuration Codes of Management .....                 | 79 |
| 8.14 Set Configuration Codes of Log .....                        | 80 |
| 8.15 Set Configuration Codes of Power Management .....           | 82 |
| Chapter 9 Device Settings .....                                  | 83 |
| 9.1 Feature Tree .....                                           | 83 |
| 9.2 Running Mode Settings .....                                  | 84 |

|                                          |            |
|------------------------------------------|------------|
| <b>9.3 Image Quality Settings .....</b>  | <b>85</b>  |
| 9.3.1 Set Image .....                    | 85         |
| 9.3.2 Set Parameter Polling .....        | 86         |
| 9.3.3 Set Light Source .....             | 90         |
| 9.3.4 Set Smart Tune .....               | 91         |
| 9.3.5 Set Focus .....                    | 93         |
| 9.3.6 Set Self-Adaptive Adjustment ..... | 96         |
| 9.3.7 Set Mirror X .....                 | 98         |
| 9.3.8 Set Test Pattern .....             | 99         |
| <b>9.4 Code Algorithm Settings .....</b> | <b>99</b>  |
| 9.4.1 Add Code .....                     | 99         |
| 9.4.2 Set Code Reading ROI .....         | 100        |
| 9.4.3 Set Algorithm Parameter .....      | 102        |
| 9.4.4 Set Code Quality Evaluation .....  | 105        |
| 9.4.5 Set Code Score .....               | 106        |
| <b>9.5 Input/Output Settings .....</b>   | <b>107</b> |
| 9.5.1 Line Mode Settings .....           | 107        |
| 9.5.2 Signal Input Settings .....        | 108        |
| 9.5.3 Stop Trigger .....                 | 115        |
| 9.5.4 Signal Output Settings .....       | 120        |
| 9.5.5 Set Buzzer .....                   | 124        |
| <b>9.6 Communication Settings .....</b>  | <b>125</b> |
| 9.6.1 Set SmartSDK .....                 | 125        |
| 9.6.2 Set TCP Client .....               | 125        |
| 9.6.3 Set Serial .....                   | 126        |
| 9.6.4 Set FTP .....                      | 126        |
| 9.6.5 Set TCP Server .....               | 127        |
| 9.6.6 Set Profinet .....                 | 127        |
| 9.6.7 Set MELSEC/SLMP .....              | 127        |
| 9.6.8 Set Ethernet/IP .....              | 128        |
| 9.6.9 Set ModBus .....                   | 128        |
| 9.6.10 Set UDP .....                     | 129        |

|                                                                                |     |
|--------------------------------------------------------------------------------|-----|
| 9.6.11 Set Fins .....                                                          | 129 |
| 9.6.12 Set USB .....                                                           | 130 |
| 9.7 Data Processing Settings .....                                             | 131 |
| 9.7.1 Set Filter Rule .....                                                    | 131 |
| 9.7.2 Data Processing Settings.....                                            | 136 |
| 9.8 Characters Replace.....                                                    | 139 |
| 9.9 Multi-Reader Synchronization .....                                         | 140 |
| 9.9.1 Main-Sub Configuration .....                                             | 141 |
| 9.9.2 Multicast .....                                                          | 147 |
| 9.9.3 Multi Frame .....                                                        | 148 |
| 9.10 Lua Script.....                                                           | 149 |
| 9.11 Contrast Control Settings .....                                           | 151 |
| 9.12 User Set Customization .....                                              | 153 |
| 9.13 Statistics Information.....                                               | 154 |
| 9.14 Diagnose Event Report .....                                               | 155 |
| Chapter 10 Device Maintenance .....                                            | 156 |
| 10.1 Update Firmware .....                                                     | 156 |
| 10.2 Set Time .....                                                            | 156 |
| 10.3 Enable Device Auto Work .....                                             | 157 |
| 10.4 Restart Device .....                                                      | 157 |
| Chapter 11 FAQ (Frequently Asked Question) .....                               | 159 |
| 11.1 Why there is no device listed after I run the IDMVS client software?..... | 159 |
| 11.2 Why the image is very dark? .....                                         | 159 |
| 11.3 Why the image's frame rate is very low in the live view?.....             | 159 |
| 11.4 Why there is no image in the live view? .....                             | 160 |
| Chapter 12 Revision History .....                                              | 161 |
| Appendix A ASCII Table .....                                                   | 162 |

# Chapter 1 Safety Instruction

The safety instructions are intended to ensure that the user can use the device correctly to avoid danger or property loss. Read and follow these safety instructions before installing, operating and maintaining the device.

## 1.1 Safety Claim

- To ensure personal and device safety, when installing, operating, and maintaining the device, follow the signs on the device and all safety instructions described in the manual.
- The note, caution and danger items in the manual do not represent all the safety instructions that should be observed, but only serve as a supplement to all the safety instructions.
- The device should be used in an environment that meets the design specifications, otherwise it may cause malfunctions, and malfunctions or component damage caused by non-compliance with relevant regulations are not within the scope of the device's quality assurance.
- Our company will not bear any legal responsibility for personal safety accidents and property losses caused by abnormal operation of the device.

## 1.2 Safety Instruction

### **Caution**

- Do not install the device if it is found that the device and accessories are damaged, rusted, water ingress, model mismatch, missing parts, etc., when unpacking.
- Avoid storage and transportation in places such as water splashing and rain, direct sunlight, strong electric fields, strong magnetic fields, and strong vibrations.
- Avoid dropping, smashing or vigorously vibrating the device and its components.
- It is forbidden to install the indoor device in an environment where it may be exposed to water or other liquids. If the device is damp, it may cause fire and electric shock hazard.
- Place the device in a place out of direct sunlight and ventilation, away from heat sources such as heaters and radiators.
- In the use of the device, you must be in strict compliance with the electrical safety regulations of the nation and region.
- Use the power adapter provided by the official manufacturer. The power adapter must meet the Limited Power Source (LPS) requirements. For specific requirements, please refer to the device's technical specifications.
- It is strictly forbidden to wire, maintain, and disassemble the device is powered on. Otherwise, there is a danger of electric shock.
- Make sure that the device is installed in good condition, the wiring is firm, and the power

supply meets the requirements before powering on the device.

- For a device with a power switch, please use the switch to power on and off. It is strictly forbidden to plug and unplug the power cord.
- Looking directly at the device may cause harm to the eyes. Protective measures like wearing protective glasses should be taken in the process of installation, maintenance and debugging.
- If the device emits smoke, odor or noise, please turn off the power and unplug the power cord immediately, and contact the dealer or service center in time.
- It is strictly forbidden to touch any terminal of the device when operating it. Otherwise there is a danger of electric shock.
- It is strictly forbidden for non-professional technicians to detect signals during device operation, otherwise it may cause personal injury or device damage.
- It is strictly forbidden to maintain the device that is powered on, otherwise there is a danger of electric shock.
- Avoid aiming the image sensor at strong light in direct mode or reflection mode, such as laser beams, otherwise the image sensor will be damaged.
- Keep clean of the device's image acquisition window. It is recommended to use cleaning water (not the alcohol-based corrosive solutions) to wipe off the dust. When the device is not in use, please add a dust cover to protect the image acquisition window.
- If the device does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.
- Please dispose of the device in strict accordance with the relevant national or regional regulations and standards to avoid environmental pollution and property damage.

### **Note**

- Check whether the device's package is in good condition, whether there is damage, intrusion, moisture, deformation, etc. before unpacking.
- Check the surface of the device and accessories for damage, rust, bumps, etc. when unpacking.
- Check whether the quantity and information of the device and accessories are complete after unpacking.
- Store and transport the device according to the storage and transport conditions of the device, and the storage temperature and humidity should meet the requirements.
- It is strictly prohibited to transport the device in combination with items that may affect or damage the device.
- Please read the manual and safety instructions carefully before installing the device.
- Quality requirements for installation and maintenance personnel:
  - Qualification certificate or working experience in weak current system installation and maintenance, and relevant working experience and qualifications. Besides, the personnel must possess the following knowledge and operation skills.
  - The basic knowledge and operation skills of low voltage wiring and low voltage electronic circuit connection.
  - The ability to comprehend the contents of this manual.
- Do not contact the device with strong acids, alkalis, oils, greases or organic solutions

such as thinners.

- Do not expose the device directly to flashlights, high-frequency switch lighting devices, or to sunlight, which may affect the performance.
- Do not impose pressure on the cable end of the device, such as forced bending, pulling, etc.

### 1.3 Electromagnetic Interference Prevention

- Make sure that the shielding layer of cables is intact and 360° connected to the metal connector when using shielded cables.
- Do not route the device together with other equipment (especially servo motors, high-power devices, etc.), and control the distance between cables to more than 10 cm. Make sure to shield the cables if unavoidable.
- The control cable of the device and the power cable of the industrial light source must be wired separately to avoid bundled wiring.
- The power cable, data cable, signal cable, etc. of the device must be wired separately. Make sure to ground them if the wiring groove is used to separate the wiring and the wiring groove is metal.
- During the wiring process, evaluate the wiring space reasonably, and do not pull the cables hard, so as not to damage the electrical performance of the cables.
- If the device is powered on and off frequently, it is necessary to strengthen the voltage isolation, and consider adding a DC/DC isolation power supply module between the device and the adapter.
- Use the power adapter to supply power to the device separately. If centralized power supply is necessary, make sure to use a DC filter to filter the power supply of the device separately before use.
- The unused cables of the device must be insulated.
- When installing the device, if you cannot ensure that the device itself and all equipment connected to the device are well grounded, you should isolate the device with an insulating bracket.
- To avoid the accumulation of static electricity, ensure that other equipment (such as machines, internal components, etc.) and metal brackets on site are properly grounded.
- During the installation and use of the device, high voltage leakage must be avoided.
- Use a figure-eight bundle method if the device cable is too long.
- When connecting the device and metal accessories, they must be connected firmly to maintain good conductivity.
- Use a shielded network cable to connect to the device. If you use a self-made network cable, make sure that the shielding shell at the aviation head is well connected to the aluminum foil or metal braid of the shielding cable.

## 1.4 Laser Precaution

The laser safety class of some devices belongs to laser 2.



**Figure 1-1 Class 2 Laser Product**

### **Caution**

- Do not use optical instruments (such as telescopes, magnifier) to observe the laser beam.
- Do not look directly at the laser module window to avoid irreversible damage to your eyes.

## Chapter 2 Overview

### 2.1 Introduction

With functions of image acquisition, code recognition and output, the ID2000 series industrial code reader can read different types of 1D codes and 2D codes. It adopts compact design and is small in size. The device is applicable to consumer electronics, food and medicine, semiconductor, new energy, and other industries.

The device uses sensors and optical elements to obtain images of the measured object, and achieves code parsing via the built-in deep learning code reading algorithm. It also supports outputting the detection results through different communication modes.

### 2.2 Key Features

- Compact design and small in size.
- Adopts LED aiming light to help aim codes.
- Adopts buzzer and status indicator for prompting the device's operation status.
- Built-in deep learning algorithm to read codes with good robustness.
- Adopts multiple I/O interfaces and plug-in power interface.
- Supports multiple communication protocols, including TCP Server, Serial, FTP, TCP Client, UDP, USB, etc.
- Supports code quality evaluation, and quality standards include ISO15415, ISO15416, and ISO29158.

---

#### Note

- The specific functions may differ by device models.
  - Refer to the device's specifications for specific parameters.
-

## Chapter 3 Appearance

### Note

Appearance here is for reference only. Refer to the device's specification for detailed dimension information.




Refer to the tables and figures below for the device type and device appearance.



**Table 3-1 Device Type**

| Variant Components     | Device Type                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Connector on SR Cable  | <p>There are two connectors on the SR cable of the device: 17-pin M12 connector and DB15 connector.</p> <p>The device with DB15 connector refers to appearance of type IV, and the devices with 17-pin M12 connector refer to appearances of type I to type III.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Lens and Focusing Mode | <p>Based on the differences of lens and focusing mode, the devices can be classified to five types:</p> <ul style="list-style-type: none"> <li>Fixed-focus device: The device has built-in M5.8-mount/M5.5-mount lens, and its focal length cannot be adjusted. Make sure the measured object is within the field of view during using.</li> </ul> <p> <b>Note</b><br/>Refer to the device's specification for information of field of view.</p> <ul style="list-style-type: none"> <li>Auto-focusing device: The device has built-in M12-mount lens, and its focal length can be adjusted via related parameters.</li> </ul> <p> <b>Note</b><br/>Refer to section <a href="#">Set Smart Tune</a> for details.</p> <ul style="list-style-type: none"> <li>Manual-focusing device with short focal length: The device has built-in M10-mount lens, and its focal length can be adjusted manually via focus knob on the top side of the device.</li> <li>Manual-focusing device with long focal length: The device has built-in M12-mount lens, and its focal length can be adjusted manually via focus knob on the top side of the device.</li> </ul> |
| Data Interface         | <p>Based on the data interface and data transmission protocol, the devices can be classified to two types: device with network interface and device with USB interface.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

| Variant Components | Device Type                                                                                                                                                                                                                                                                 |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                    | <p>There are differences in the interface definition and the cables provided in the package.</p> <p> <b>Note</b><br/>Refer to section <a href="#">Connector and Cable</a> for details.</p> |

**Table 3-2 Device Appearance**

| Device Type |                                                                                                      | Appearance                                                                          |                                                                                      |
|-------------|------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Type I      | ID2000M Series Auto-Focusing Device<br>(Network Interface & USB Interface)                           |    |    |
| Type II     | ID2000M Series Manual-Focusing Device with Short Focal Length<br>(Network Interface & USB Interface) |  |  |
| Type III    | ID2000M Series Manual-Focusing Device with Long Focal Length<br>(Network Interface & USB Interface)  |  |  |

| Device Type |                                                                           | Appearance                                                                                                                                                            |                                                                                  |
|-------------|---------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| Type IV     | ID2000EM Series Fixed-Focus Device<br>(Network Interface & USB Interface) |   | <p><b>Note</b><br/>The position of the SR cable may differ by device models.</p> |

**Table 3-3 Component Description**

| No. | Name       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Focus Knob | <p>It is used to adjust focal length manually.</p> <p><b>Note</b><br/>Only ID2000M series manual-focusing devices with Short/Long Focal Length have this component.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 2   | Screw Hole | <p>It is used to fix the device to the installation position, and is applicable to M2 or M3 screws.</p> <p><b>Note</b><br/>Refer to the device's specification for information of screw hole in dimension.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 3   | Button     | <p>It is used to trigger or restart the device, or execute smart tune.</p> <ul style="list-style-type: none"> <li>• Trigger button: When the device is in trigger mode and software trigger is selected, press the button and the device triggers once. All devices with the button support this function.</li> <li>• Smart tune button: Hold the button for 3 seconds and the device starts smart tune. Hold the button for 3 seconds again during smart tune process, and the adjustment will be cancelled. All devices with the button support this function.</li> <li>• Restarting: Hold the button for 10 seconds to restart the device. The configured parameters will not be edited after restarting. Only ID2000EM series fixed-focus device supports this function.</li> </ul> |
| 4   | SR Cable   | The connector on the SR cable provides power, I/O, Ethernet/USB,                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

| No. | Name             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-----|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     |                  | <p>and serial port. It should be used with the supplied cable.</p> <p> <b>Note</b></p> <ul style="list-style-type: none"> <li>• The connector on the SR cable may differ by device models. Refer to section <a href="#">Connector and Cable</a> for details.</li> <li>• The position of the SR cable may differ by models of ID2000EM series fixed-focus device.</li> </ul>                                                                                                                                                                                                     |
| 5   | LINK Indicator   | <p>It is a network status indicator. The indicator is flashing green when the network transmission is normal. Otherwise, it is unlit.</p> <p> <b>Note</b></p> <p>The devices with USB interface transfer data via virtual network interface in the client software. Therefore, the data transmission status of these devices can also be checked via this indicator.</p>                                                                                                                                                                                                        |
| 6   | Status Indicator | <ul style="list-style-type: none"> <li>• It is in red color when the device starts up or operation error occurs.</li> <li>• It is unlit when the device operates normally without reading codes.</li> <li>• It is in green color lasting 0.5 seconds when the device reads codes successfully.</li> <li>• It is solid green when the device reads codes continuously.</li> <li>• It is in red color lasting 0.5 seconds when the device does not read codes.</li> </ul> <p> <b>Note</b></p> <p>The specific function of the status indicator may differ by device models.</p> |
| 7   | PWR Indicator    | <p>It is a power indicator. The indicator is in red color during the device's power-on process. After the device is powered on, the indicator is in green color.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 8   | Light Source     | <p>It is the LED light source used to provide light when the device acquires images.</p> <p> <b>Note</b></p> <p>The light source color may differ by device models.</p>                                                                                                                                                                                                                                                                                                                                                                                                       |
| 9   | Image Sensor     | <p>It is used to acquire images.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 10  | Aiming Light     | <p>It helps to indicate the field of view and aim targets.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 11  | Buzzer           | <p>The buzzer beeps three times when the device is powered on, beeps twice when the device reads configuration codes successfully, and beeps once when the device reads codes successfully.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

| No. | Name | Description                                                                                                                                                                                                                                                                |
|-----|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     |      |  <b>Note</b> <ul style="list-style-type: none"><li>• Only ID2000EM series fixed-focus devices have a buzzer.</li><li>• Refer to section <a href="#">Set Buzzer</a> for details.</li></ul> |


## Chapter 4 Installation

### 4.1 Installation Preparation

You need to prepare following accessories before installation.

Table 4-1 Accessories

| No. | Name                                 | Image                                                                               | Quantity | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----|--------------------------------------|-------------------------------------------------------------------------------------|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Power Adapter or Switch Power Supply |    | 1        | You should select a suitable power adapter or switch power supply according to the device power supply and consumption. You need to purchase separately.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 2   | Cable                                |  | 1        | <p>It refers to the supplied cable that is used to connect the device to the external devices or accessories.</p> <p><b>Note</b></p> <ul style="list-style-type: none"><li>• For ID2000M series devices with network interface, it refers to the 3 m cable with 17-pin M12 to 8-pin terminal, RJ45, and DB9 serial port.</li><li>• For ID2000EM series devices with network interface, it refers to the 3.5 m cable with DB15 to 6-pin terminal, RJ45, and DB9 serial port.</li><li>• For ID2000M series devices with USB interface, it refers to the 2 m cable with 17-pin M12 to USB connector. If I/O function is needed, you can purchase the cable with 17-pin M12 to 8-pin terminal, USB connector, and DB9 serial port of our company.</li><li>• For ID2000EM series devices with USB interface, it refers to the 2 m cable with DB15 to USB connector. If I/O function is needed, you can purchase the cable with DB15 to 6-pin terminal, USB connector, RJ45, and DB9 serial port of our company.</li></ul> |

| No. | Name               | Image                                                                                                                                                   | Quantity | Description                                                                                                                                                                                                                             |
|-----|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3   | IO Box             |  <p>6-Pin IO Box</p> <p>8-Pin IO Box V1.0</p> <p>8-Pin IO Box V2.0</p> | 1        | <p>It refers to the IO box that is used for connecting the device's power supply and I/O interfaces to the external device.</p> <p><b>Note</b></p> <p>The IO box may not be included in the package due to different device models.</p> |
| 4   | Insulating Bracket |                                                                        | 1        | <p>It is used for electrostatic shielding between the device and other field-used devices, preventing the cables or devices from being burned out. You need to purchase separately.</p>                                                 |

## **Note**

- The type of the IO box may differ by the device model. Please refer to the actual one.

**Table 4-2 IO Box**

| IO Box            | Applicable Device      | Usage                                                                                                                                                                    | Description                                                                     |
|-------------------|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| 6-Pin IO Box      | ID2000EM Series Device | The IO box can be used for switching pull-up and pull-down resistors for each I/O channel.                                                                               | You should purchase it separately.                                              |
| 8-Pin IO Box V1.0 | ID2000M Series Device  | <p>The IO box can be used for switching pull-up and pull-down resistors for each I/O channel.</p> <p><b>Note</b></p> <p>This type of the I/O box is not recommended.</p> | One of the IO boxes is included in the package. Please refer to the actual one. |
| 8-Pin IO Box V2.0 |                        | The IO box can be used for upgrading the non opto-isolated I/O to opto-isolated I/O.                                                                                     |                                                                                 |

- You can scan the QR codes below to get the operating guide of the IO box.

**Table 4-3 Operating Guide of IO Box**

| IO Box            | Operating Guide                                                                     |
|-------------------|-------------------------------------------------------------------------------------|
| 6-Pin IO Box      |   |
| 8-Pin IO Box V1.0 |   |
| 8-Pin IO Box V2.0 |  |

---

## 4.2 Device Wiring

### ***Before You Start***

- Make sure that the device in the package is in good condition and all assembly parts are included.
- Make sure that all related equipment is powered off during the installation.
- When connecting the device to the cable, confirm whether it is a motion cable and pay attention to the following points during use.
  - The installation of the cable should avoid excessive bending and tension, especially at the connector. The motion cable should be secured in a manner that prevents mechanical stress or sharp bends at the connection.
  - The non-motion cable should not be used in scenarios that may cause damage, such as bending, dragging, or twisting.
  - The use of motion cable should comply with the cable specifications, including but

not limited to bending radius, movement speed, and service life.


---

### **Caution**

- When the power adapter or the industrial switching power supply is used for power supply, make sure that the device is powered independently and does not share the power source with other devices.
  - When the industrial switching power supply is used for power supply, pay attention to the following matters:
    - Before any installation or maintenance work, please disconnect the power supply from the utility, and ensure that it will not be reconnected inadvertently.
    - Do not install the power supply in places with high moisture or near the water.
    - Do not install the power supply in places with high ambient temperature or near fire source.
    - Please install the exposed high-voltage terminals on the power supply in a closed chassis or cabinet to prevent accidental contact.
    - Keep enough insulation distance between mounting screws and internal components of power supply.
    - Fans and ventilation holes must be kept free from any obstructions. Also a 10 cm to 15 cm clearance should be kept when the adjacent device is a heat source.
    - The power supply must be grounded as required.
    - Output current and output power must not exceed the rated values on specifications.
    - Non-standard mounting or operating under high ambient temperature may increase the internal component temperature and will decrease the output power.
    - All failure should be examined by a qualified technician. Do not remove the case of the power supply by yourself.
    - Do not touch the power terminal for 5 minutes after the power is turned off, that may cause electric shock.
  - When the ID2000M series devices with USB interface use the USB interface for power supply, it is recommended to use USB 3.0 interface on the PC. The USB 2.0 interface for power supply may cause startup failure.
  - When the ID2000EM series devices with USB interface use the USB interface for power supply, USB 2.0 interface and USB 3.0 interface on the PC are both acceptable. The current of the USB 2.0 interface is 500 mA.
-

## ID2000M Series Devices with Network Interface

You can use the supplied cable to wire the device.



**Figure 4-1 Device Wiring via Supplied Cable**

### Steps


1. Connect the 17-pin M12 female connector of the cable to the 17-pin M12 male connector of the SR cable on the device.
2. Connect the 8-pin terminal.  
It is recommended to connect the 8-pin terminal to the 8-pin IO box, and then connect the IO box to other devices. The VCC and GND of IO box can be connected to a suitable power adapter or industrial switching power supply for power supply. If I/O function is needed, you can connect other pins of the IO box to the external device, and refer to section [I/O Wiring](#) for details. If IO box is not used, you can refer to the wiring method of the fixed-focus devices.
3. Insert RJ45 network interface of the cable into a switch or a PC for data transmission.
4. (Optional) If RS-232 serial port communication is required, refer to section [RS-232 Serial Port](#) for wiring via DB9 serial port of the cable.

## ID2000M Series Devices with USB Interface

If I/O function is not needed, use the supplied cable to wire the device.

### Steps

1. Connect the 17-pin M12 female connector of the cable to the 17-pin M12 male connector of the SR cable on the device.
2. Connect the USB interface of the cable to the PC for power supply and data transmission.




**Figure 4-2 Device Wiring via Supplied Cable**

If I/O function is needed, use the cable purchased from our company to wire the device.

### Steps

1. Connect the USB interface of the cable to the PC.
2. For connection of other connectors, refer to wiring methods of ID2000M series devices with network interface for details.



**Figure 4-3 Device Wiring via Purchased Cable**

---


### Note

The 8-pin terminal and USB interface can be used for power supply. When both power supply methods are in operation simultaneously, power supply via the 8-pin terminal will prevail.


---

### ID2000EM & ID2000EMI Series Devices with Network Interface

You can use the supplied cable to wire the device.



**Figure 4-4 Device Wiring via Supplied Cable (ID2000EMI Series Device)**



**Figure 4-5 Device Wiring via Supplied Cable (ID2000EM Series Device)**

### Steps

1. Connect the DB15 female connector of the cable to the DB15 male connector of the SR cable on the device.
2. Connect the open line or 6-pin terminal.
  - If the 6-pin IO box is not used, connect pins corresponding to the red and black lines in the 6-pin terminal or the open line to a suitable power adapter or industrial switching power supply. If I/O function is needed, you can connect other pins of the 6-pin terminal or the open line to the external device. Refer to section [I/O Wiring](#) for details.

---

### Note

The ID2000EMI series device has opto-isolated I/O, with no need for the IO box.

---

- If the 6-pin IO box is used, connect the 6-pin terminal to the 6-pin IO box, and then connect the IO box to other devices. The VCC and GND of IO box can be connected to a suitable power adapter or industrial switching power supply for power supply. If I/O function is needed, you can connect other pins of the IO box to the external device.
3. Insert RJ45 network interface of the cable into a switch or a PC for data transmission.
  4. Connect DB9 serial port of the cable to the power adapter for power supply.
  5. (Optional) If RS-232 serial port communication is required, refer to section [RS-232 Serial Port](#) for wiring via DB9 serial port of the cable.
- 

### Note

The open line / 6-pin terminal and DB9 serial port can be used for power supply. Do not use both power supply methods simultaneously. Otherwise, it may cause the burnout of the power supply.


---

## ID2000EM & ID2000EMI Series Devices with USB Interface

If I/O function is not needed, use the supplied cable to wire the device.

## Steps

1. Connect the DB15 female connector of the cable to the DB15 male connector of the SR cable on the device.
2. Connect the USB interface of the cable to the PC for power supply and data transmission.




**Figure 4-6 Device Wiring via Supplied Cable**


If I/O function is needed, use the cable purchased from our company to wire the device.

## Steps

1. Connect the USB interface of the cable to the PC.
2. For connection of other connectors, refer to wiring methods of ID2000EM series devices with network interface for details.



**Figure 4-7 Device Wiring via Purchased Cable (ID2000EMI Series Device)**



**Figure 4-8 Device Wiring via Purchased Cable (ID2000EM Series Devices)**

## Note

- The 6-pin terminal, DB9 serial port, and USB interface can be used for power supply. Do not use power supply methods via 6-pin terminal and DB9 serial port simultaneously.


Otherwise, it may cause the burnout of the power supply. When the power supply via the USB interface is used with other two methods simultaneously, power supply via the 6-pin terminal or DB9 serial port will prevail.

- It is unnecessary to use the RJ45 network interface in the figure above.
- 

### 4.3 Device Installation

#### **Before You Start**

- Make sure that the device in the package is in good condition and all assembly parts are included.
  - Make sure that all related devices are powered off during the installation.
- The insulating bracket should be installed on the device first. Side mounting or back mounting is supported.



**Figure 4-9 Insulating Bracket Installation**

#### **Steps**

1. Use the screws to fix the insulating bracket to the mounting holes on the side or back of the device.
2. Fix the L-type bracket or other structural part to the insulating bracket.
3. Fix the device to the mechanical assembly via the L-type bracket or other structural part.

## Chapter 5 Connector and Cable

This section introduces the device's connector and pin definitions.


---

### Note

- The I/O functions may differ by the firmware version of the device. This document mainly introduces the functions supported by the following firmware versions. For unlisted firmware versions, you can contact the technical support.
    - Firmware version of V3.0.4 and above: ID2000EM series fixed-focus device
    - Firmware version of V3.0.0 and above: ID2000M series auto-focusing device, ID2000M series manual-focusing device with long focal length
    - Firmware version of V2.6.8 and above: ID2000M series manual-focusing device with short focal length
  - The last column of the tables in this section indicates the trigger source name displayed in the client software. And the pins with actual usage will be introduced only.
- 

### 5.1 ID2000M Series Devices with Network Interface

The ID2000M series devices with network interface have the 17-pin M12 connector.



**Figure 5-1 17-Pin Connector**


The supplied cable is a 17-pin M12 cable to 8-pin terminal, RJ45, and DB9 serial port. The cable has converted the pins of device interface for power supply, I/O, RS-232 and data communication into the 8-pin terminal, RJ45 network interface, and DB9 serial port. You can use the cable directly without wiring.

---

### Caution

The three open cables of the 8-pin terminal cannot be wired with the device, including purple/white open cable, pink open cable, and purple open cable.

---



**Figure 5-2 17-Pin M12 Cable to 8-Pin Terminal, RJ45, and DB9 Serial Port**

The pin definitions may differ by device type.

### ID2000M Series Auto-Focusing Devices, and ID2000M Series Manual-Focusing Devices with Long Focal Length

Refer to the table below for the pin definitions, trigger source, and the corresponding supplied cable.

**Table 5-1 Pin Definition**

| No. | Signal   | Description                          | Supplied Cable                        | Trigger Source |
|-----|----------|--------------------------------------|---------------------------------------|----------------|
| 1   | POWER_IN | Direct current power supply positive | Pin 8 of 8-pin terminal (Red)         | --             |
| 2   | OUT_COM  | Output signal ground                 | Pin 6 of 8-pin terminal (Brown)       | --             |
| 4   | RS232_TX | RS-232 serial port output            | DB9 female serial port                | --             |
| 5   | RS232_RX | RS-232 serial port input             | DB9 female serial port                | --             |
| 6   | TX+      | Fast Ethernet signal TX+             | RJ45 network interface                | --             |
| 7   | RX-      | Fast Ethernet signal RX-             | RJ45 network interface                | --             |
| 8   | GPIO2    | Non-isolated input                   | Pin 4 of 8-pin terminal (Blue/White)  | Input: Line 2  |
| 9   | IN_COM   | Input signal ground                  | Pin 3 of 8-pin terminal (Blue)        | --             |
| 10  | GPIO3    | Non-isolated output                  | Pin 5 of 8-pin terminal (Brown/White) | Output: Line 4 |
| 11  | GND      | Direct current power supply          | Pin 7 of 8-pin terminal               | --             |

| No. | Signal | Description                                              | Supplied Cable                  | Trigger Source                  |
|-----|--------|----------------------------------------------------------|---------------------------------|---------------------------------|
|     |        | negative                                                 | (Black)                         |                                 |
| 14  | TX-    | Fast Ethernet signal TX-                                 | RJ45 network interface          | --                              |
| 15  | RX+    | Fast Ethernet signal RX+                                 | RJ45 network interface          | --                              |
| 16  | GPIO0  | Bi-directional non-isolated I/O, and input is by default | Pin 1 of 8-pin terminal (Gray)  | Input: Line 0<br>Output: Line 0 |
| 17  | GPIO1  | Bi-directional non-isolated I/O, and input is by default | Pin 2 of 8-pin terminal (White) | Input: Line 1<br>Output: Line 1 |

The 8-pin IO box should be used with the devices. Refer to section [Installation Preparation](#) for details. If you want to use the I/O function without IO box, refer to section [I/O Wiring](#) for details.

## ID2000M Series Manual-Focusing Devices with Short Focal Length

Refer to the table below for the pin definitions, trigger source, and the corresponding supplied cable.

**Table 5-2 Pin Definition**


| No. | Signal   | Description                          | Supplied Cable                        | Trigger Source |
|-----|----------|--------------------------------------|---------------------------------------|----------------|
| 1   | POWER_IN | Direct current power supply positive | Pin 8 of 8-pin terminal (Red)         | --             |
| 2   | OUT_COM  | Output signal ground                 | Pin 6 of 8-pin terminal (Brown)       | --             |
| 4   | RS232_TX | RS-232 serial port output            | DB9 female serial port                | --             |
| 5   | RS232_RX | RS-232 serial port input             | DB9 female serial port                | --             |
| 6   | TX+      | Fast Ethernet signal TX+             | RJ45 network interface                | --             |
| 7   | RX-      | Fast Ethernet signal RX-             | RJ45 network interface                | --             |
| 8   | GPIO2    | Non-isolated input                   | Pin 4 of 8-pin terminal (Blue/White)  | Input: Line 2  |
| 9   | IN_COM   | Input signal ground                  | Pin 3 of 8-pin terminal (Blue)        | --             |
| 10  | GPIO3    | Non-isolated output                  | Pin 5 of 8-pin terminal (Brown/White) | Output: Line 3 |
| 11  | GND      | Direct current power supply negative | Pin 7 of 8-pin terminal (Black)       | --             |

| No. | Signal | Description                                              | Supplied Cable                  | Trigger Source                  |
|-----|--------|----------------------------------------------------------|---------------------------------|---------------------------------|
| 14  | TX-    | Fast Ethernet signal TX-                                 | RJ45 network interface          | --                              |
| 15  | RX+    | Fast Ethernet signal RX+                                 | RJ45 network interface          | --                              |
| 16  | GPIO0  | Bi-directional non-isolated I/O, and input is by default | Pin 1 of 8-pin terminal (Gray)  | Input: Line 0<br>Output: Line 0 |
| 17  | GPIO1  | Bi-directional non-isolated I/O, and input is by default | Pin 2 of 8-pin terminal (White) | Input: Line 1<br>Output: Line 1 |

The 8-pin IO box should be used with the devices. Refer to section [Installation Preparation](#) for details. If you want to use the I/O function without IO box, refer to section [I/O Wiring](#) for details.

## 5.2 ID2000EM & ID2000EMI Series Devices with Network Interface

The ID2000EM & ID2000EMI series devices with network interface have the DB15 connector.




**Figure 5-3 DB15 Connector**

The supplied cable is a DB15 cable to open line / 6-pin terminal, RJ45, and DB9 serial port. The cable has converted the pins of device interface for power supply, I/O, RS-232 and data communication into the open line / 6-pin terminal, RJ45 network interface, and DB9 serial port. You can use the cable directly without wiring.

### Note

The open line / 6-pin terminal and DB9 serial port can be used for power supply. Do not use both power supply methods simultaneously. Otherwise, it may cause the burnout of the power supply.




**Figure 5-4 DB15 Cable to Open Line, RJ45, and DB9 Serial Port (ID2000EMI Series Device)**

Refer to the table below for the pin definitions, signal source, and the corresponding supplied cable.

**Table 5-3 Pin Definition (ID2000EMI Series Device)**

| No. | Signal    | Description                          | Cable Color     |                                                                                     | Supplied Cable         | Trigger Source |
|-----|-----------|--------------------------------------|-----------------|-------------------------------------------------------------------------------------|------------------------|----------------|
| 1   | POWER_IN  | Direct current power supply positive | Red             |   | DB9, Open              | --             |
| 2   | RS232_TX  | RS-232 serial port output            | Yellow          |  | DB9                    | --             |
| 3   | RS232_RX  | RS-232 serial port input             | White           |  | DB9                    | --             |
| 4   | GND       | Direct current power supply negative | Black           |  | DB9, Open              | --             |
| 5   | OPTO_IN0  | Opto-isolated input                  | Blue            |  | Open                   | Input: Line 0  |
| 6   | TX+       | Fast Ethernet signal TX+             | White/<br>Green |  | RJ45 Network Interface | --             |
| 7   | RX-       | Fast Ethernet signal RX-             | Orange          |  | RJ45 Network Interface | --             |
| 8   | OPTO_OUT0 | Opto-isolated output                 | Gray            |  | Open                   | Output: Line 3 |
| 10  | OPTO_OUT1 | Opto-isolated output                 | Brown           |  | Open                   | Output: Line 4 |
| 11  | OUT_COM   | Output signal ground                 | Pink            |  | Open                   | --             |
| 12  | IN_COM    | Input signal ground                  | Light Green     |  | Open                   | --             |

| No. | Signal   | Description              | Cable Color      |                                                                                   | Supplied Cable         | Trigger Source |
|-----|----------|--------------------------|------------------|-----------------------------------------------------------------------------------|------------------------|----------------|
| 13  | OPTO_IN1 | Opto-isolated input      | Purple           |  | Open                   | Input: Line 1  |
| 14  | TX-      | Fast Ethernet signal TX- | Green            |  | RJ45 Network Interface | --             |
| 15  | RX+      | Fast Ethernet signal RX+ | White/<br>Orange |  | RJ45 Network Interface | --             |



**Figure 5-5 DB15 Cable to 6-Pin Terminal, RJ45, and DB9 Serial Port (ID2000EM Series Device)**

Refer to the table below for the pin definitions, trigger source, and the corresponding supplied cable.

**Table 5-4 Pin Definition (ID2000EM Series Device)**

| No. | Signal   | Description                          | Cable Color |                                                                                     | Supplied Cable          | Trigger Source |
|-----|----------|--------------------------------------|-------------|-------------------------------------------------------------------------------------|-------------------------|----------------|
| 1   | POWER_IN | Direct current power supply positive | Red         |  | Pin 6 of 6-pin terminal | --             |
| 2   | RS232_TX | RS-232 serial port output            | Yellow      |  | DB9 female serial port  | --             |
| 3   | RS232_RX | RS-232 serial port input             | White       |  | DB9 female serial port  | --             |
| 4   | GND      | Direct current power supply negative | Black       |  | Pin 5 of 6-pin terminal | --             |

| No. | Signal    | Description              | Cable Color      |                                                                                     | Supplied Cable          | Trigger Source |
|-----|-----------|--------------------------|------------------|-------------------------------------------------------------------------------------|-------------------------|----------------|
| 5   | OPTO_IN0  | Non-isolated input       | Blue             |    | Pin 1 of 6-pin terminal | Input: Line 0  |
| 6   | TX+       | Fast Ethernet signal TX+ | White/<br>Green  |    | RJ45 network interface  | --             |
| 7   | RX-       | Fast Ethernet signal RX- | Orange           |    | RJ45 network interface  | --             |
| 8   | OPTO_OUT0 | Non-isolated output      | Gray             |    | Pin 2 of 6-pin terminal | Output: Line 3 |
| 10  | IO_2      | Non-isolated output      | Brown            |    | Pin 3 of 6-pin terminal | Output: Line 4 |
| 13  | IO_1      | Non-isolated input       | Purple           |    | Pin 4 of 6-pin terminal | Input: Line 1  |
| 14  | TX-       | Fast Ethernet signal TX- | Green            |  | RJ45 network interface  | --             |
| 15  | RX+       | Fast Ethernet signal RX+ | White/<br>Orange |  | RJ45 network interface  | --             |

### Note

Refer to section [I/O Wiring](#) for wiring. For the device with non-isolated I/O, if you want to use the 6-pin IO box purchased from our company, refer to section [Installation Preparation](#) for details.

## 5.3 ID2000M Series Devices with USB Interface (Without I/O Function)

The ID2000M series devices with USB interface have the 17-pin M12 connector.




Figure 5-6 17-Pin Connector

The supplied cable is a 17-pin M12 cable to USB interface. It provides data communication and power supply via the USB interface, but cannot provide I/O function.

## Note

If you need to use the I/O function, refer to section [ID2000M Series Devices with USB Interface \(With I/O Function\)](#) for details.



**Figure 5-7 17-Pin M12 Cable to USB Interface**


Refer to the table below for the pin definitions and the corresponding supplied cable.

**Table 5-5 Pin Definition**

| No. | Signal   | Description                          | Supplied Cable |
|-----|----------|--------------------------------------|----------------|
| 1   | POWER_IN | Direct current power supply positive | USB            |
| 3   | USB_DM   | USB DM signal                        | USB            |
| 11  | GND      | Direct current power supply negative | USB            |
| 12  | USB_DP   | USB DP signal                        | USB            |

## 5.4 ID2000EM & ID2000EMI Series Devices with USB Interface (Without I/O Function)

The ID2000EM & ID2000EMI series devices with USB interface have the DB15 connector.




**Figure 5-8 DB15 Connector**

The supplied cable is a DB15 cable to USB interface. It provides data communication and power supply via the USB interface, but cannot provide I/O function.

## Note

If you need to use the I/O function, refer to section [ID2000EM & ID2000EMI Series Device with USB Interface \(With I/O Function\)](#) for details.



**Figure 5-9 DB15 Cable to USB Interface**

Refer to the table below for the pin definitions and the corresponding supplied cable.

**Table 5-6 Pin Definition (ID2000EMI Series Device)**


| No. | Signal   | Description                          | Supplied Cable |
|-----|----------|--------------------------------------|----------------|
| 4   | GND      | Direct current power supply negative | USB            |
| 6   | USB_DM   | USB DM signal                        | USB            |
| 9   | POWER_IN | Direct current power supply positive | USB            |
| 14  | USB_DP   | USB DP signal                        | USB            |

**Table 5-7 Pin Definition (Other Devices)**

| No. | Signal   | Description                          | Supplied Cable |
|-----|----------|--------------------------------------|----------------|
| 4   | GND      | Direct current power supply negative | USB            |
| 9   | POWER_IN | Direct current power supply positive | USB            |
| 11  | USB_DM   | USB DM signal                        | USB            |
| 12  | USB_DP   | USB DP signal                        | USB            |


## 5.5 ID2000M Series Devices with USB Interface (With I/O Function)

The ID2000M series devices with USB interface have the 17-pin M12 connector.



**Figure 5-10 17-Pin Connector**

If the I/O function is needed, it is recommended to purchase the 17-pin M12 cable to 8-pin terminal, USB, and DB9 serial port from our company.



**Figure 5-11 17-Pin M12 Cable to 8-Pin Terminal, USB, and DB9 Serial Port**

The pin definitions may differ by device type.

## ID2000M Series Auto-Focusing Devices, and ID2000M Series Manual-Focusing Devices with Long Focal Length

Refer to the table below for the pin definitions, trigger source, and the corresponding supplied cable.

**Table 5-8 Pin Definition**

| No. | Signal   | Description                          | Supplied Cable                        | Trigger Source |
|-----|----------|--------------------------------------|---------------------------------------|----------------|
| 1   | POWER_IN | Direct current power supply positive | Pin 8 of 8-pin terminal (Red)         | --             |
| 2   | OUT_COM  | Output signal ground                 | Pin 6 of 8-pin terminal (Brown)       | --             |
| 3   | USB_DM   | USB DM signal                        | USB                                   | --             |
| 4   | RS232_TX | RS-232 serial port output            | DB9 female serial port                | --             |
| 5   | RS232_RX | RS-232 serial port input             | DB9 female serial port                | --             |
| 8   | GPIO2    | Non-isolated input                   | Pin 4 of 8-pin terminal (Blue/White)  | Input: Line 2  |
| 9   | IN_COM   | Input signal ground                  | Pin 3 of 8-pin terminal (Blue)        | --             |
| 10  | GPIO3    | Non-isolated output                  | Pin 5 of 8-pin terminal (Brown/White) | Output: Line 4 |
| 11  | GND      | Direct current power supply          | • Pin 7 of 8-pin terminal (Black)     | --             |

| No. | Signal | Description                                                 | Supplied Cable                     | Trigger Source                  |
|-----|--------|-------------------------------------------------------------|------------------------------------|---------------------------------|
|     |        | negative                                                    | • USB                              |                                 |
| 12  | USB_DP | USB DP signal                                               | USB                                | --                              |
| 16  | GPIO0  | Bi-directional non-isolated I/O,<br>and input is by default | Pin 1 of 8-pin terminal<br>(Gray)  | Input: Line 0<br>Output: Line 0 |
| 17  | GPIO1  | Bi-directional non-isolated I/O,<br>and input is by default | Pin 2 of 8-pin terminal<br>(White) | Input: Line 1<br>Output: Line 1 |

The 8-pin IO box should be used with the devices. Refer to section [Installation Preparation](#) for details. If you want to use the I/O function without IO box, refer to section [I/O Wiring](#) for details.

## ID2000M Series Manual-Focusing Devices with Short Focal Length

Refer to the table below for the pin definitions, trigger source, and the corresponding supplied cable.

**Table 5-9 Pin Definition**


| No. | Signal   | Description                             | Supplied Cable                           | Trigger Source |
|-----|----------|-----------------------------------------|------------------------------------------|----------------|
| 1   | POWER_IN | Direct current power supply<br>positive | Pin 8 of 8-pin terminal<br>(Red)         | --             |
| 2   | OUT_COM  | Output signal ground                    | Pin 6 of 8-pin terminal<br>(Brown)       | --             |
| 3   | USB_DM   | USB DM signal                           | USB                                      | --             |
| 4   | RS232_TX | RS-232 serial port output               | DB9 female serial port                   | --             |
| 5   | RS232_RX | RS-232 serial port input                | DB9 female serial port                   | --             |
| 8   | GPIO2    | Non-isolated input                      | Pin 4 of 8-pin terminal<br>(Blue/White)  | Input: Line 2  |
| 9   | IN_COM   | Input signal ground                     | Pin 3 of 8-pin terminal<br>(Blue)        | --             |
| 10  | GPIO3    | Non-isolated output                     | Pin 5 of 8-pin terminal<br>(Brown/White) | Output: Line 3 |
| 11  | GND      | Direct current power supply<br>negative | Pin 7 of 8-pin terminal<br>(Black)       | --             |
| 12  | USB_DP   | USB DP signal                           | USB                                      | --             |
| 16  | GPIO0    | Bi-directional non-isolated I/O,        | Pin 1 of 8-pin terminal                  | Input: Line 0  |

| No. | Signal | Description                                                 | Supplied Cable                     | Trigger Source                  |
|-----|--------|-------------------------------------------------------------|------------------------------------|---------------------------------|
|     |        | and input is by default                                     | (Gray)                             | Output: Line 0                  |
| 17  | GPIO1  | Bi-directional non-isolated I/O,<br>and input is by default | Pin 2 of 8-pin terminal<br>(White) | Input: Line 1<br>Output: Line 1 |

The 8-pin IO box should be used with the devices. Refer to section [Installation Preparation](#) for details. If you want to use the I/O function without IO box, refer to section [I/O Wiring](#) for details.

## 5.6 ID2000EM & ID2000EMI Series Device with USB Interface (With I/O Function)

The ID2000EM & ID2000EMI series devices with USB interface have the DB15 connector.



**Figure 5-12 DB15 Connector**


If the I/O function is needed, it is recommended to purchase the DB15 cable to open line / 6-pin terminal, USB, RJ45, and DB9 serial port from our company. The cable has converted the pins of device interface for power supply, I/O, RS-232 and data communication into the open line / 6-pin terminal, USB, RJ45 network interface (not required), and DB9 serial port. You can use the cable directly without wiring.

---

### Note

The open line / 6-pin terminal, DB9 serial port, and USB interface can be used for power supply. Do not use power supply methods via open line / 6-pin terminal and DB9 serial port simultaneously. Otherwise, it may cause the burnout of the power supply. When the power supply via the USB interface is used with other two methods simultaneously, power supply via the open line / 6-pin terminal or DB9 serial port will prevail.

---




**Figure 5-13 DB15 Cable to Open Line, USB, and DB9 Serial Port (ID2000EMI Series Device)**

Refer to the table below for the pin definitions, signal source, and the corresponding supplied cable.

**Table 5-10 Pin Definition (ID2000EMI Series Device)**

| No. | Signal     | Description                          | Cable Color  |                                                                                     | Supplied Cable | Trigger Source |
|-----|------------|--------------------------------------|--------------|-------------------------------------------------------------------------------------|----------------|----------------|
| 1   | POWER_IN   | Direct current power supply positive | Red          |    | DB9, Open      | --             |
| 2   | RS232_TX   | RS-232 serial port output            | White        |  | DB9            | --             |
| 3   | RS232_RX   | RS-232 serial port input             | Green        |  | DB9            | --             |
| 4   | GND        | Direct current power supply negative | Black        |  | DB9, Open, USB | --             |
| 5   | OPTO_IN0   | Opto-isolated input                  | Blue         |  | Open           | Input: Line 0  |
| 6   | TX+        | Fast Ethernet signal TX+             | Yellow       |  | USB            | --             |
| 8   | OPTO_OUT0  | Opto-isolated output                 | Gray         |  | Open           | Output: Line 3 |
| 9   | POWER_5VIN | Direct current power supply positive | Brown /White |  | USB            | --             |
| 10  | OPTO_OUT1  | Opto-isolated output                 | Brown        |  | Open           | Output: Line 4 |
| 11  | OUT_COM    | Output signal ground                 | Pink         |  | Open           | --             |
| 12  | IN_COM     | Input signal ground                  | Light Green  |  | Open           | --             |
| 13  | OPTO_IN1   | Opto-isolated input                  | Purple       |  | Open           | Input: Line 1  |

| No. | Signal | Description              | Cable Color |                                                                                   | Supplied Cable | Trigger Source |
|-----|--------|--------------------------|-------------|-----------------------------------------------------------------------------------|----------------|----------------|
| 14  | TX-    | Fast Ethernet signal TX- | Orange      |  | USB            | --             |



**Figure 5-14 DB15 Cable to 6-Pin Terminal, USB, RJ45, and DB9 Serial Port (ID2000EM Series Device)**

Refer to the table below for the pin definitions, trigger source, and the corresponding supplied cable.

**Table 5-11 Pin Definition (ID2000EM Series Device)**

| No. | Signal    | Description                          | Supplied Cable                                                                                                  | Trigger Source |
|-----|-----------|--------------------------------------|-----------------------------------------------------------------------------------------------------------------|----------------|
| 1   | POWER_IN  | Direct current power supply positive | <ul style="list-style-type: none"> <li>Pin 6 of 6-pin terminal (Red)</li> <li>DB9 female serial port</li> </ul> | --             |
| 2   | RS232_TX  | RS-232 serial port output            | DB9 female serial port                                                                                          | --             |
| 3   | RS232_RX  | RS-232 serial port input             | DB9 female serial port                                                                                          | --             |
| 4   | GND       | Direct current power supply negative | <ul style="list-style-type: none"> <li>Pin 5 of 6-pin terminal (Black)</li> <li>DB9</li> </ul>                  | --             |
| 5   | OPTO_IN0  | Non-isolated input                   | Pin 1 of 6-pin terminal (Blue)                                                                                  | Input: Line 0  |
| 8   | OPTO_OUT0 | Non-isolated output                  | Pin 2 of 6-pin terminal (Gray)                                                                                  | Output: Line 3 |
| 9   | POWER_IN  | Direct current power supply positive | USB                                                                                                             | --             |
| 10  | IO_2      | Non-isolated output                  | Pin 3 of 6-pin terminal                                                                                         | Output: Line 4 |

| No. | Signal | Description        | Supplied Cable                      | Trigger Source |
|-----|--------|--------------------|-------------------------------------|----------------|
|     |        |                    | (Brown)                             |                |
| 11  | USB_DM | USB DM signal      | USB                                 | --             |
| 12  | USB_DP | USB DP signal      | USB                                 | --             |
| 13  | IO_1   | Non-isolated input | Pin 4 of 6-pin terminal<br>(Purple) | Input: Line 1  |

## **Note**

Refer to section [I/O Wiring](#) for wiring. For some devices, if you want to use the 6-pin IO box purchased from our company, refer to section [Installation Preparation](#) for details.

---

## Chapter 6 I/O Electrical Feature and Wiring

This section introduces the I/O electrical features and wiring methods of the device.

### Note

This section only introduces the wiring methods between the device and the other external devices. If you need to wire the device via the IO box, scan the QR codes below to get the operating guide of the IO box.

**Table 6-1 Operating Guide of IO Box**

| IO Box            | Operating Guide                                                                      |
|-------------------|--------------------------------------------------------------------------------------|
| 6-Pin IO Box      |    |
| 8-Pin IO Box V1.0 |  |
| 8-Pin IO Box V2.0 |  |

### 6.1 Opto-Isolated I/O


The ID2000EMI series fixed-focus devices have opto-isolated input × 2 (Line 0/1) and opto-isolated output × 2 (Line 3/4).

### 6.1.1 Opto-Isolated Input Circuit


The internal circuit, electrical feature, and logic level of opto-isolated input signal are as follows.

#### Note

- Make sure that the input voltage is from 5 VDC to 30 VDC.
- The breakdown voltage is 36 VDC. Keep voltage stable.



**Figure 6-1 Internal Circuit of Input Signal**



**Figure 6-2 Input Logic Level**

**Table 6-2 Input Electrical Feature**

| Parameter Name         | Parameter Symbol | Value        |
|------------------------|------------------|--------------|
| Input Logic Level Low  | VL               | 1.5 VDC      |
| Input Logic Level High | VH               | 2 VDC        |
| Input Falling Delay    | TDF              | 81.6 $\mu$ s |
| Input Rising Delay     | TDR              | 7 $\mu$ s    |

## 6.1.2 Opto-Isolated Output Circuit

The internal circuit and electrical feature of the opto-isolated output signal are as follows.

### Note

- Make sure that the output voltage is from 5 VDC to 30 VDC.
- The maximum output current is 25 mA.
- Do not directly connect with inductive load (e.g. DC motor, etc.) when outputting.




Figure 6-3 Internal Circuit of Output Signal




Figure 6-4 Output Logic Level

### Note

If the external voltage and resistance change, the corresponding current of output signal and output logic level low may differ.

Table 6-3 Output Electrical Feature

| Parameter Name          | Parameter Symbol | Value       |
|-------------------------|------------------|-------------|
| Output Logic Level Low  | VL               | 730 mV      |
| Output Logic Level High | VH               | 3.2 VDC     |
| Output Falling Delay    | TDF              | 6.3 $\mu$ s |
| Output Rising Delay     | TDR              | 68 $\mu$ s  |

| Parameter Name      | Parameter Symbol | Value      |
|---------------------|------------------|------------|
| Output Falling Time | TF               | 3 $\mu$ s  |
| Output Rising Time  | TR               | 60 $\mu$ s |

### 6.1.3 I/O Wiring

The device can receive input signals from external devices and output signals to external devices. This section introduces how to wire the device's I/O.

#### Note

- The wiring methods of input and output mentioned in this section are the same. When using the device, make sure that the signal lines should be used with their corresponding signal grounds.
- The voltage of VCC should be equal to or less than that of PWR. Otherwise, the device's output signal may have exception.
- The device figures below are for reference only, and the actual one you got should prevail.

Input/output signal wiring may differ by the type of the external device.

#### PNP Device




Figure 6-5 Connect to PNP Device

#### NPN Device

If the PWR of NPN device is 12 VDC or 24 VDC, it is recommended to use a 1 K $\Omega$  pull-up resistor.




Figure 6-6 Connect to NPN Device

## 6.2 Non Opto-Isolated I/O

The I/O electrical features and wiring methods may differ by the device model.

- ID2000EM series fixed-focus device: non opto-isolated input × 2 and non opto-isolated output × 2
- ID2000M series manual-focusing device with short focal length: non opto-isolated bidirectional I/O × 4, configuring to input or output
  - 0 and 1: Control by line0\_1, input by default (input 0/1, output 0/1)
  - 2 and 3: Control by line2\_3, output by default (input 3/4, output 3/4)
- ID2000M series auto-focusing device, and ID2000M series manual-focusing device with long focal length: non opto-isolated input × 1, non opto-isolated output × 1, and bidirectional non-isolated I/O × 2 (input by default)

### 6.2.1 Non Opto-Isolated Input Circuit

The internal circuit, electrical feature, and logic level of non opto-isolated input signal are as follows.




Figure 6-7 Internal Circuit of Input Signal




Figure 6-8 Input Logic Level

Table 6-4 Input Electrical Feature

| Parameter Name         | Parameter Symbol | Value                                                                                                                         |
|------------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Input Logic Level Low  | VL               | <ul style="list-style-type: none"> <li>• ID2000M series devices: 1 VDC</li> <li>• ID2000EM series devices: 0.6 VDC</li> </ul> |
| Input Logic Level High | VH               | 2 VDC                                                                                                                         |


| Parameter Name      | Parameter Symbol | Value     |
|---------------------|------------------|-----------|
| Input Falling Delay | TDF              | 200 ns    |
| Input Rising Delay  | TDR              | 1 $\mu$ s |

### 6.2.2 Non Opto-Isolated Output Circuit

The internal circuit and electrical feature of the non opto-isolated output signal are as follows.



**Figure 6-9 Internal Circuit of Output Signal**



**Figure 6-10 Output Logic Level**

When the pull-up voltage is 12 VDC and pull-up resistor is 1 K $\Omega$ , the output electric feature is shown below.

**Table 6-5 Output Electrical Feature**

| Parameter Name          | Parameter Symbol | Value       |
|-------------------------|------------------|-------------|
| Output Logic Level Low  | VL               | 500 mV      |
| Output Logic Level High | VH               | 12 VDC      |
| Output Falling Delay    | TDF              | 330 ns      |
| Output Rising Delay     | TDR              | 4.4 $\mu$ s |
| Output Falling Time     | TF               | 116 ns      |
| Output Rising Time      | TR               | 3.8 $\mu$ s |


Relation among different pull-up voltages, output logic level low, and output logic level high is shown below.

**Table 6-6 Parameters of Output Logic Level Low and High**

| Pull-Up Voltage | Output Logic Level Low (VL) | Output Logic Level High (VH) |
|-----------------|-----------------------------|------------------------------|
| 3.3 VDC         | 180 mV                      | 3.3 VDC                      |
| 5 VDC           | 260 mV                      | 5 VDC                        |
| 12 VDC          | 500 mV                      | 12 VDC                       |
| 24 VDC          | 900 mV                      | 24 VDC                       |


### 6.2.3 Non Opto-Isolated Bi-Directional I/O Circuit

The non opto-isolated bi-directional signal in I/O signal can be use as input signal or output signal according to demands. Its internal circuit is shown below. GPI circuit is used for input and GPO circuit for output.

**Figure 6-11 Internal Circuit of Bi-Directional Signal**

#### Configured as Input Signal

The logic level and electrical feature when the bi-directional I/O is configured as input signal are as follows.


**Figure 6-12 Input Logic Level**

**Table 6-7 Input Electrical Feature**

| Parameter Name         | Parameter Symbol | Value     |
|------------------------|------------------|-----------|
| Input Logic Level Low  | VL               | 1 VDC     |
| Input Logic Level High | VH               | 2 VDC     |
| Input Falling Delay    | TDF              | 200 ns    |
| Input Rising Delay     | TDR              | 1 $\mu$ s |

### Configured as Output Signal

When the pull-up voltage is 12 VDC and pull-up resistor is 1 K $\Omega$ , the output electric feature and logic level are shown below.


**Figure 6-13 Output Logic Level**
**Table 6-8 Output Electrical Feature**

| Parameter Name          | Parameter Symbol | Value       |
|-------------------------|------------------|-------------|
| Output Logic Level Low  | VL               | 500 mV      |
| Output Logic Level High | VH               | 12 VDC      |
| Output Falling Delay    | TDF              | 330 ns      |
| Output Rising Delay     | TDR              | 4.4 $\mu$ s |
| Output Falling Time     | TF               | 116 ns      |
| Output Rising Time      | TR               | 3.8 $\mu$ s |

Relation among different pull-up voltages, output logic level low, and output logic level high is shown below.

**Table 6-9 Parameters of Output Logic Level Low and High**

| Pull-Up Voltage | Output Logic Level Low (VL) | Output Logic Level High (VH) |
|-----------------|-----------------------------|------------------------------|
| 3.3 VDC         | 180 mV                      | 3.3 VDC                      |

| Pull-Up Voltage | Output Logic Level Low (VL) | Output Logic Level High (VH) |
|-----------------|-----------------------------|------------------------------|
| 5 VDC           | 260 mV                      | 5 VDC                        |
| 12 VDC          | 500 mV                      | 12 VDC                       |
| 24 VDC          | 900 mV                      | 24 VDC                       |

## 6.2.4 I/O Wiring

The device can receive input signals from external devices and output signals to external devices. This section introduces how to wire the device's I/O.

### Note

- The input and output signals mentioned in this section are the bi-directional I/O signal.
- The voltage of VCC should be equal to or less than that of PWR. Otherwise, the device's output signal may have exception.
- The device figures below are for reference only, and the actual one you got should prevail.

Input/output signal wiring may differ by the type of the external device.

### PNP Device

- When the bi-directional I/O is set as the non opto-isolated input signal for connecting to the PNP device, you should use a 1 K $\Omega$  pull-down resistor.




Figure 6-14 Input Signal Connecting to PNP Device

- When the bi-directional I/O is set as the non opto-isolated output signal for connecting to the PNP device, the wiring diagram is shown below.




Figure 6-15 Output Signal Connecting to PNP Device

### NPN Device

- When the bi-directional I/O is set as the non opto-isolated input/output signal for connecting to the NPN device, you should use a 1 K $\Omega$  pull-up resistor.




Figure 6-16 Input/Output Signal Connecting to NPN Device

### Switch

- When the bi-directional I/O is set as the non opto-isolated input signal for connecting to the switch, the wiring diagram is shown below.




Figure 6-17 Input Signal Connecting to Switch

## 6.3 RS-232 Serial Port

The device supports outputting data via RS-232 serial port, and you can set serial port communication via the client software. Refer to section [Set Serial](#) for details.

The supplied cable has a DB9 female serial port. Refer to the figure and table below for pin definitions.




Figure 6-18 DB9 Female Serial Port

Table 6-10 Pin Definitions

| Pin No. | Name | Description     |
|---------|------|-----------------|
| 2       | TX   | Transmits data. |

| Pin No. | Name | Description    |
|---------|------|----------------|
| 3       | RX   | Receives data. |
| 5       | GND  | Signal ground. |

## Chapter 7 Device Debugging

Device connection/debugging to the client software is required for device's configuration and remote operations. This section introduces how to install the client software, set PC and device network, connect the device to the client software, etc.

### 7.1 Debugging via Configuration Codes

---

#### Note

- Only ID2000EM & ID2000EMI series fixed-focus devices support debugging via the configuration codes.
  - Refer to section for details.
- 

The devices support configuring parameters or debugging via reading special codes that are called configuration codes. The configuration code consists of three parts.



Figure 7-1 Configuration Code

Table 7-1 Configuration Code Description

| No. | Description                                                                                                                         |
|-----|-------------------------------------------------------------------------------------------------------------------------------------|
| 1   | It is the code part of the configuration code. After reading this part, the device can finish the corresponding parameter settings. |
| 2   | ** stands for the default settings.                                                                                                 |
| 3   | It is the content of configuration code.                                                                                            |

## 7.2 Client Software Installation

IDMVS is a client software for device configuration and remote operations.


---

### Note

- The client software is compatible with 32/64-bit Windows 7/10 and 64-bit Windows 11 operating systems. Here we take Windows as an example.
  - You can get the client software installation package from <https://en.hikrobotics.com/>. It is recommended to use the client software with version of V5.0.0 and later.
  - For the devices with USB interface, only the client software with version of V2.3.0 and above in Windows system is supported.
  - The client software with version of V2.3.0 and above in Windows system has integrated the USB driver. If the driver is not recognized, you can install it.
  - The graphic user interface may differ by different versions of client software you use.
- 

### Steps

1. Double click the installation package to start installing the client software.
2. Select the language.
3. Read and check **Terms of the License Agreement**.
4. Click **Start Setup**.
5. Select installation directory and click **Next**.



**Figure 7-2 Installation Interface**


6. Finish the installation according to the interface prompts.

## 7.3 Device Connection

Device connection is a prerequisite for using the client software to perform code reading

and represents the first step after launching the client. This section provides an overview of the necessary preparations and guides you to discover and connect to the device. The connection process is primarily managed through the **Device List**. If no device is connected, you can open the floating **Device List** in either of the following ways:

- Click **+** next to **No cameras, click to add** in the upper-left corner.
- Click **Connect Camera** in the left panel.



**Figure 7-3 Open Device List**

Once the **Device List** is open, you can follow the steps below to connect to device and set basic parameters.



**Figure 7-4 Operation Flow**

### 7.3.1 Preparations

To ensure a normal connection and proper functioning of the client software, confirm that your system meets the requirements. After that, complete the hardware wiring of the device and perform the necessary environment configuration.

#### System Requirements

The PC configuration should meet the following requirements.

##### Minimum Configuration

- OS: 32/64-bit Windows 7/10 or 64-bit Windows 11
- CPU: Intel Pentium IV 2.0 GHz
- RAM: 1 GB
- NIC: Intel Pro1000, I210, or I350 series recommended
- Display resolution: 1366 × 768

##### Recommended Configuration

- OS: 32/64-bit Windows 7/10 or 64-bit Windows 11
  - CPU: Intel Pentium IV 3.0 GHz or higher
  - RAM: 4 GB or higher
  - NIC: Intel Pro1000, I210, or I350 series recommended
  - Display resolution: 1920 × 1080 or higher
- 

### Note

- The client software has integrated all necessary drivers, and there is no need to install drivers.
  - The client software relies on the system disk for operation. Please ensure sufficient space on the system drive.
  - Some antivirus programs may mistakenly identify the client software as a virus. To avoid issues, consider adding the client software to the antivirus whitelist or disabling the antivirus. It is recommended to disable 360 Security Guard if installed.
- 

## Hardware Wiring

Before using the device, you need to complete the hardware wiring for power supply, data communication, I/O, and RS-232 serial port connections. Refer to section [I/O Electrical Feature and Wiring](#) for details.

## Device Environment Configuration

To ensure stable data transmission, you should configure the firewall and PC network settings for network-type devices, or ensure the driver installation for USB-type devices.

- **For network-type devices:** Before using the client software, ensure the PC and the device are on the same LAN subnet and enable jumbo frames on the PC's Ethernet port.
  - Open the NIC Configurator. You can choose any one of the following ways to open it:
    - Go to the IDMVS installation directory and open **NIC\_Configurator**. Relative path: `.\Applications\Win64\NIC_Configurator`.
    - Right-click **GigE** in the device list and select **NIC Properties**.




Figure 7-5 NIC Configurator

- Select the target NIC at **NIC(s)**.
- Configure its parameters.

### Jumbo Frame


Enable jumbo frame for TCP/IP packets to reduce CPU usage and improve data transmission efficiency, especially when handling large packets and latency is acceptable to the user.

---

#### Note

If enabling jumbo frames fails, open **NIC Properties** → **Advanced** and check if the **Jumbo Packet** or **Jumbo Frame** is available. If available, set the value to 9 KB or 9014 Bytes. If not, update the NIC driver or use a different NIC that supports jumbo frames.

---



**Figure 7-6 Enable Jumbo Packer**

### Receive Buffers

In cases that the NIC properties meet the requirements, you can adjust the receive buffer size. A larger buffer improves reception performance but consumes more system memory.

### Transmit Buffers

In cases that the NIC properties meet the requirements, you can adjust the transmit buffer size. A larger buffer enhances transmission performance but consumes more system memory.

### NIC properties

You can view or edit the NIC configuration options. Some options may be locked by the manufacturer and cannot be changed.


### NIC Protocol Properties

You can view or modify the PC's IP address.

### Note

- To ensure stable device operation, it is recommended to set the PC's network port IP address to a static IP address.
- For device status details, refer to section [Device Discovery](#). For IP editing steps, refer to section [Pre-Connection Configuration](#).

- **For USB-type devices:** You should install a USB-to-Ethernet driver before connection.
  - Connect the USB-type devices to the PC via a USB interface.  
The Windows system will automatically detect the new hardware device and install the driver.
  - (Optional) Go to **Control Panel** → **Device Manager** → **Network adapters** to check if the driver has been installed successfully.



**Figure 7-7 Driver Installed Successfully**

### Note

If the driver installation fails (e.g., displayed  RNDIS under **Other devices** or the system does not detect the RNDIS driver), contact technical support to obtain the driver and install it manually.

## 7.3.2 Device Discovery

After environment preparations, the device can be detected in the **Device List** by using two methods: Auto/Manual Refresh or Remote Addition. The first method is applicable when the device and the PC are in the same subnet, while the second is used when they are in different subnets but their IP addresses are pingable.

### Note

The client software also supports virtual device connection for testing and debugging without physical devices.

## Discover Device

This section introduces the following two methods: Auto/Manual Refresh and Remote Addition.

### Auto/Manual Refresh

- **Auto Refresh:** When **Device List Auto-Refresh** is enabled under **Settings** → **General**, the client software periodically detects and updates the available devices on the local area network.

---

#### Note

By default, the client software refreshes automatically every 30 seconds. You may adjust this value as needed.

---

- **Manual Refresh:** Click  on the top of the **Device List** to manually refresh the device.




Figure 7-8 Auto Enumeration of Devices

### Remote Addition

Remote Addition is useful for centralized remote management in distributed or complex environments, such as production lines at different locations with minimal on-site intervention.

#### Steps

1. Ensure the device and PC can ping each other on the same network.
2. Right-click **GigE** in the **Device List**, and select **Add Remote Camera**.




Figure 7-9 Add Remote Camera

3. Select the appropriate network adapter, and enter the device's IP address.
4. Click **OK**.

### View Status and Information of Device

After the device is detected, you can check the device status and availability in the **Device List**. Different icons on the left of the device name symbolizes different status.

Table 7-2 Device Status Description

| Icon                                                                              | Status        | Description                                                                                                                                                                              |
|-----------------------------------------------------------------------------------|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Free          | The device is ready for connection. Double click it to connect and use.                                                                                                                  |
|  | Connected     | The client software has successfully connected to the device, and you can execute some operations.                                                                                       |
|  | Acquire Image | The client software has connected to the device, and starts to acquire images.                                                                                                           |
|  | In Use        | The device is in use by another software (including IDMVS client software).                                                                                                              |
|  | Unreachable   | The device is unreachable on the local area network. You need to adjust its IP address to the same network. For details, refer to section <a href="#">Pre-Connection Configuration</a> . |

In addition, select a specific device, and you can view its detailed information.




Figure 7-10 Viewing Device Information

### Note

You can right-click to copy specific data entries.

## 7.3.3 Pre-Connection Configuration

If a device is detected in the **Device List** and is not in use, you can modify its IP address or upgrade its firmware as needed.


### Modify IP Address

You may need to modify the IP address in the following cases: setting the device to a

static IP address or resolving network issues to make the device reachable. You can follow the steps below.

### Steps

1. Select the device that needs IP address change in the **Device List**.
2. Right-click the device and select **Modify IP** to enter the IP configuration interface.
3. Choose the desired IP configuration type: Static IP, DHCP (Dynamic Host Configuration IP) or LLA (Link-Local Address).



**Figure 7-11 Modify IP Address**

4. Click **OK** to apply the changes.

---

### Note

- The client software supports advanced network configuration for connected devices. In addition to IP modification, it allows you to set a fixed IP address and IP address anti-occupation (Exclusive) in **IP Address** of the Device Information. The fixed IP address function ensures long-term stable connectivity by assigning permanent addresses to devices, while the IP address anti-occupation function effectively prevents communication interruptions caused by unauthorized devices attempting to occupy assigned IP addresses. For details, refer to section [Post-Connection Configuration](#).
  - If you need to configure the IP addresses of multiple devices, go to **Tools** → **IP Configurator** in the menu bar.
- 

## Firmware Upgrade

To ensure optimal performance and access to the latest functions, you can regularly upgrade device's firmware. Contact our technical support for the latest firmware. The client software supports two upgrade methods: UDP firmware upgrade and TCP firmware upgrade.

**Table 7-3 Comparison of UDP and TCP Firmware Upgrades**

| Items        | UDP Firmware Upgrade                                                                                                                                                                                               | TCP Firmware Upgrade                                                                                                                                                                                               |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Precondition | Device should be available.                                                                                                                                                                                        | Device should be connected, and is not in grabbing status.                                                                                                                                                         |
| UI Path      | <ul style="list-style-type: none"> <li>Right-click the device name in the <b>Device List</b> and select <b>Firmware Upgrade</b>.</li> <li>Click <b>Tools</b> → <b>Firmware Updater</b> in the Menu Bar.</li> </ul> | <ul style="list-style-type: none"> <li>Right-click the device name in the <b>Device List</b> and select <b>Firmware Upgrade</b>.</li> <li>Click <b>Tools</b> → <b>Firmware Updater</b> in the Menu Bar.</li> </ul> |
| Support      | Supported by all devices.                                                                                                                                                                                          | Only supported by some device models (refer to the interface for availability).                                                                                                                                    |
| Features     | Supports firmware upgrading without device connection, and batch upgrading.<br><br>Click <b>Tools</b> → <b>Firmware Updater</b> in the Menu Bar.                                                                   | Enhanced upgrade speed, and also supports batch upgrading.<br><br>Click <b>Tools</b> → <b>Firmware Updater</b> in the Menu Bar.                                                                                    |


You can follow the steps below to upgrade UDP firmware.

### Steps

#### Note

- Please use the firmware package of the corresponding device model for upgrading.
- Do not power off the device or disconnect network during upgrading.
- The device will restart automatically after the firmware is upgraded.

1. Select the target device in the **Device List**.
2. Right-click the device, and select **Firmware Upgrade**.
3. Click  and select a .dav firmware file matching with the target device model.



**Figure 7-12 UDP Firmware Upgrade**

4. Click **Upgrade**.

Upon completion, a success notification will appear, and the device will automatically restart.

---

**Note**

If you select the wrong model during the process, the firmware upgrade fails and does not overwrite the original firmware. In such cases of upgrade failure or abnormal termination, the device will automatically restart.

---

### 7.3.4 Device Connecting

Once a device is discovered in the **Device List**, you can connect it for further operations.

#### Connect to Device

There are two ways for connection.

- Double-click the device name.
  - Click  next to the device name.
- 

**Note**

You also can click  next to the device name to disconnect.

---

#### Check and Switch Devices

After connecting, the client software's main interface will display. The upper-left device information provides the following details.



**Figure 7-13 Device Information**

- **Device Model:** You can double-click it to open the floating device list, and then refer to the steps above to connect to other devices.
- 

**Note**

If you rename the user ID in the [Post-Connection Configuration](#), the user ID will be displayed in the device information bar instead of the device model.

---

- **Current Load:** It shows the current parameter group, including default and custom settings. You can configure startup parameter loading via **Param Save** in the Quick Access Toolbar or switch parameter groups manually.

### 7.3.5 Post-Connection Configuration

After connecting to the device, you can configure basic functions, device control, static IP assignment, and IP anti-occupancy function by right-clicking the device name in the device list.

### Basic Functions

You can right-click the device name in the **Device List** or the device information in the upper-left corner of the main window to perform the following operations.

#### Start/Stop Acquisition

You can start or stop image acquisition, and can press F2 to execute this function. The shortcut can be set in **Settings** → **Shortcut** in the menu bar.

#### Rename User ID

You can set a device user's ID (up to 15 English characters). The user ID will be displayed in the **Device List** or the device information in the upper-left corner of the main window.

#### File Access

You can import or export the following device parameters.



#### Note

You can also use **File Access** in the Menu Bar to import device parameters in a batch.

---

#### User Set

You can import or export user parameters.

- Import: After importing, all user parameter sets, including quantity, name, and specific parameters, will be changed according to imported files.
- Export: After exporting, a configuration file in .mfa format (with internal system user parameters) will be generated and be exported to the selected path. The default naming rule for the .mfa file is: device model\_SerialNumber\_User Set.mfa.

#### Multi ROI

You can import or export algorithm ROI data.

- Import: You can import configuration files to edit algorithm ROI parameters in a batch, improving the efficiency of parameter configuration.
- Export: After exporting, a configuration file in .mfa format (with internal algorithm ROI data) will be generated and be exported to the selected path. The default naming rule for the .mfa file is: device model\_SerialNumber\_Multi ROI.mfa.

#### SECBIN

You can import encrypted files in .bin format. Contact technical support for more details.

#### License Notice

You can export open-source software licenses as a .txt file.

### Save GenICam XML

You can save the current device GenICam configuration as an XML file.

### Firmware Update

You can upgrade connected device's TCP firmware.

---

#### Note

- TCP firmware upgrade can be achieved via TCP packets. For a comparison between TCP and UDP upgrades, refer to section [Pre-Connection Configuration](#).
  - It is unnecessary to edit the TCP **Update Port**, and you can use the default value.
- 

### Steps

1. Click  and select a .dav firmware file matching with the target device model.
2. Click **Update**.

### Device Restart

You can execute a soft restart of the device. For batch restarting, use the IP Configurator for one-click restarting.

## Device Control

For the connected devices, you can enable **Auto Work** and **Timing** in the **Device Control**.



**Figure 7-14 Device Control**

### Auto Work

When this parameter is enabled, the device will automatically start working upon power-up if it is not connected to the client software.

---

#### Note

If the device is connected to the client software, you should manually enable this function.

---

### Timing

You can perform manual timing or NTP timing.


---

#### Note

Some connected devices support automatic time synchronization with the PC time.

---

- **Manual Timing:** After related parameters are configured, the device can either be set to the input time or synchronized with the current PC time.



**Figure 7-15 Manual Timing**

## Device Time

It displays the current time of the device.

## Setting Time

You can manually set time here. If you check **Sync with computer**, the PC time will be synchronized to the device. Both **Device Time** and **Setting Time** will be updated.


---

### Note

Only some devices support manual timing.

---

- **NTP Timing:** After the device establishes network connectivity with an NTP server, its time will be regularly synchronized according to the configured interval.



**Figure 7-16 NTP Timing**

## NTP Enable

When this parameter is enabled, the device time will be corrected according to the parameters you configure.

## IP Address


You can set the IP address of the NTP server.

## Interval (Hour/Minute)

You can set the NTP time interval. The parameter unit (hour/minute) may differ by device model.

## IP Address Configuration

The client software allows you to set a fixed IP address and IP anti-occupation (Exclusive) in **IP Address** → **Device Information**.



**Figure 7-17 Fixed IP and Exclusive**

### Fixed IP

This parameter is disabled by default. You can adjust the static IP address of the device. If it is enabled, the device IP address is fixed, and you cannot change the static IP address, or switch between dynamic IP address and static IP address.

### Exclusive

When this parameter is enabled, other applications on the PC cannot occupy or connect to the device.

## 7.3.6 Device Group

The client software supports grouping devices detected in the device list. In complex code reading scenarios with multiple devices, you can group them based on usage scenarios or tasks for centralized coordination and control.

---

### Note

- For coordination among multiple devices, you can enable multicast mode or main-sub networking function.
  - The devices can be grouped before or after connection.
- 

### Steps

1. You can click **User Defined** in the **Device List**, and right click **GigE** → **Add Group**.
  2. (Optional) Right click **New Group**. You can rename or delete the new group if needed.
  3. You can switch to specific tabs (e.g., Fixed/Handled), and right click the device. Hover over **Move To Group** and select a group name to move the device.
- 

### Note

Grouped devices can only be viewed under the tab of **User Defined**.

---

4. (Optional) Under the tab of **User Defined**, you can right click a device, and select **Remove**
-

**From Group.** The removed devices will be moved to the original tab.

---

 **Note**

If there are multiple groups, you can choose **Switch Group**.

---

## 7.4 Quick Start Guide

The **Read Config** module supports a quick code reading and fine-tuning process, helping you capture clear and complete codes.

### **Before You Start**


- Connect to the device and enter the main window. The **Fast Config** tab under **Read Config** is displayed by default.
  - Set the location for auto saving of fine-tuning parameters. You can select the current parameter or a specific polling parameter. For polling parameter, you can enter **Param Polling** on the left-side bar to view the each polling parameter.
- 

 **Note**

Polling parameters 1 to 8 are displayed by default. You can add new polling parameters in **Param Polling**, and up to 16 polling parameters can be added.

---

The flow of quick start guide is shown as below.



**Figure 7-18 Flow of Quick Start Guide**

### **Steps**

1. (Optional) Click **Real Grabbing** to adjust the test object to the proper position within the field of view.
- 

 **Note**


In trigger scenarios, you should enable **Trigger On** located on the right side of **Real Grabbing**; and in non-trigger scenarios, disable the **Trigger On**.

---

2. Click **Auto Focus**, and the device will automatically adjust to the optimal focus position.
- 

 **Note**

- If multiple planes are detected, the plane with the maximum readable codes will be selected as the focal plane.
  - For further fine-tuning of focus parameters, you can click **Focus Settings**.
-




**Figure 7-19 Auto Focus Effect**

3. Click **Self Adapt**, and the device will automatically adjust the parameters, such as exposure, gain, light source, symbology, and code quantity.

---

**Note**

- During the self-adapt process, the client software supports incremental addition of symbologies. It only adds new symbologies, and will not remove pre-configured one.
  - During the self-adapt process, Pharmacode is not compatible with 1D codes. If Pharmacode is enabled, the client software will not execute self-adapt tune on any 1D codes. If any 1D code is enabled, the client software will not execute self-adapt tune on Pharmacode.
  - If further adjustment of self-adapt parameters and light source parameters is required, you can click **Selfadapt Settings** on the right. If the desired code still cannot be read, you can click **Code Select** to select more symbologies or adjust the number of codes.
  - When setting the number of codes, the client software will execute self-adapt on 1D codes, 2D codes, and stacked codes based on the actual number of detected codes.
- 




**Figure 7-20 Self Adapt Effect**

After successful self-adapt adjustment, the parameters will automatically be saved, and you can select the polling parameter to save. After saving, enter **Param Polling** on the left-side bar to view the each polling parameter.

- If the parameter auto-saving location is **Polling ParamN**, the fine-tuned parameters can be saved to this polling parameter and the current user parameters.
- If the parameter auto-saving location is **Current Param**, the fine-tuned parameters can be saved to **Polling ParamN** under the current user parameters.

## Note

Polling parameters 1 to 8 are displayed by default. You can add new polling parameters in **Param Polling**, and up to 16 polling parameters can be added.



**Figure 7-21 Save to Polling Param**

4. Click **Start Work** or **Single Trigger** to start a single grabbing.

## Note


- If there are requirements for communication protocols, I/O, formatted output, etc., you can switch to the corresponding module through the left-side navigation bar to configure parameters.
- In normal mode, the device filters duplicate codes regardless of whether triggering is enabled.
- In test mode, duplicate codes are not filtered when triggering is disabled, or duplicate codes within a single trigger signal are filtered when triggering is enabled.

5. You can view the real-time image and execute ROI drawing in the image preview panel on the right side. The image preview panel is divided into the following parts.



**Figure 7-22 Image Preview Panel**

- **Preview Panel Toolbar:** It mainly includes image capture tools, ROI tools, and auxiliary tools.
  - **Image Display Area:** You can preview the images captured by the device here. If multiple devices are used, the image capture effects can be previewed via setting **Multi Frame**.
  - **Image Capture Data Bar:** Select the image capture data to be displayed at the bottom of the image preview panel via  in the lower left corner, including sensor rate, algorithm rate, transmission rate, image number, resolution, serial number, etc.
6. View history and statistical data.



**Figure 7-23 View Decoding Information**

7. After settings, you should click  to save parameters to user parameter sets. Otherwise, the settings will be lost after device restart.
8. After settings and preview, if you want to save the images, there are three ways for saving.
  - **Client Image Storage:** Save the device images to the local PC through the client software.
  - **Camera Image Storage:** Save images to storage medium inside the device.
  - **FTP Image Storage:** Set up the local PC as an FTP server and the device as an FTP client, transferring the device images or decoding results to the local PC through the FTP service.

## Chapter 8 Configuration Codes

Via reading configuration codes, the device can realize the following functions. Refer to the sections in this chapter.

### Note

Only ID2000EM & ID2000EMI series fixed-focus devices support reading the configuration codes.

Before setting parameters via the configuration codes, you should scan Enable Settings code to enable the configuration codes, or scan Disable Settings code to disable this function.

**Table 8-1 Set Enabling/Disabling Configuration Codes**

| Function        | Configuration Codes                                                                | Function         | Configuration Codes                                                                  |
|-----------------|------------------------------------------------------------------------------------|------------------|--------------------------------------------------------------------------------------|
| Enable Settings |  | Disable Settings |  |

### 8.1 Set Configuration Codes of Code Type

The device can be set what code type to be read via reading specific configuration codes. Currently, the device supports Code 39, Code 93, Code 128, CodeBar, ITF 25, ITF 14, EAN 8, EAN 13, UPCA, UPCE, QR Code, Data Matrix, MicroQR, GS1-128, and PDF417.

**Table 8-2 Set Configuration Codes of Code Type**

| Function            | Configuration Codes                                                                 | Function             | Configuration Codes                                                                   |
|---------------------|-------------------------------------------------------------------------------------|----------------------|---------------------------------------------------------------------------------------|
| Enable All 1D Codes |  | Disable All 1D Codes |  |
| Enable All 2D Codes |  | Disable All 2D Codes |  |

| Function        | Configuration Codes                                                                 | Function         | Configuration Codes                                                                   |
|-----------------|-------------------------------------------------------------------------------------|------------------|---------------------------------------------------------------------------------------|
| Enable Code 39  |    | Disable Code 39  |    |
| Enable Code 93  |    | Disable Code 93  |    |
| Enable Code 128 |    | Disable Code 128 |    |
| Enable CodeBar  |   | Disable CodeBar  |   |
| Enable ITF 14   |  | Disable ITF 14   |  |
| Enable ITF 25   |  | Disable ITF 25   |  |
| Enable EAN 8    |  | Disable EAN 8    |  |

| Function           | Configuration Codes                                                                 | Function            | Configuration Codes                                                                   |
|--------------------|-------------------------------------------------------------------------------------|---------------------|---------------------------------------------------------------------------------------|
| Enable EAN 13      |    | Disable EAN 13      |    |
| Enable UPCA        |    | Disable UPCA        |    |
| Enable UPCE        |    | Disable UPCE        |    |
| Enable QR Code     |   | Disable QR Code     |   |
| Enable Data Matrix |  | Disable Data Matrix |  |
| Enable MicroQR     |  | Disable MicroQR     |  |
| Enable GS1-128     |  | Disable GS1-128     |  |

| Function      | Configuration Codes                                                               | Function       | Configuration Codes                                                                 |
|---------------|-----------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------|
| Enable PDF417 |  | Disable PDF417 |  |

## 8.2 Set Configuration Codes of Code Scanning Mode

The device supports setting different code scanning modes via scanning configuration codes, including common mode, accurate mode, continuous mode, and batch mode.

**Table 8-3 Set Configuration Codes of Code Scanning Mode**

| Function        | Configuration Codes                                                                 | Function      | Configuration Codes                                                                   |
|-----------------|-------------------------------------------------------------------------------------|---------------|---------------------------------------------------------------------------------------|
| Common Mode     |   | Accurate Mode |   |
| Continuous Mode |  | Batch Mode    |  |

## 8.3 Set Configuration Codes of Code Color

You can set the device's code color via scanning the specific configuration codes as

shown below.

**Table 8-4 Set Configuration Codes of Code Color**

| Function                                | Configuration Codes                                                                | Function                                | Configuration Codes                                                                 |
|-----------------------------------------|------------------------------------------------------------------------------------|-----------------------------------------|-------------------------------------------------------------------------------------|
| Black Code on White Background          |   | White Code on Black Background          |  |
| Self-Adaption                           |   | Black Code on White Background (Backup) |  |
| White Code on Black Background (Backup) |  | /                                       | /                                                                                   |

#### **Note**

- The Code 128 codes and 2D codes can be recognized in all code color modes.
- The PDF417 codes (white code on black background) cannot be recognized when the code color mode is White Code on Black Background or Self-Adaption.

## 8.4 Set Configuration Codes of Code Reading Quantity

You can set the device's code reading quantity via scanning the specific configuration codes as shown below.

### **Steps**

1. Read configuration codes of code reading quantity.



**Figure 8-1 Code Reading Quantity**

2. Read the corresponding digital codes according to actual demands.

## Note

- The code reading quantity is supported when the code scanning mode is batch mode.
- When the code scanning mode is batch mode and the code reading quantity is no greater than 20, you should scan the digital code of tens digit first, and then scan the single digit. If the code reading quantity is single digit, the digital code of tens digit is 0. For example, if the code reading quantity is 12, scan the digital code of 1 first, and then scan 2.

**Table 8-5 Digital Codes**

| Function       | Configuration Codes                                                                 | Function       | Configuration Codes                                                                   |
|----------------|-------------------------------------------------------------------------------------|----------------|---------------------------------------------------------------------------------------|
| Digital Code 0 |    | Digital Code 1 |    |
| Digital Code 2 |   | Digital Code 3 |   |
| Digital Code 4 |  | Digital Code 5 |  |
| Digital Code 6 |  | Digital Code 7 |  |
| Digital Code 8 |  | Digital Code 9 |  |

| Function       | Configuration Codes                                                               | Function       | Configuration Codes                                                                 |
|----------------|-----------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------|
| Digital Code A |  | Digital Code B |  |
| Digital Code C |  | Digital Code D |  |
| Digital Code E |  | Digital Code F |  |

3. Read the configuration codes of saving to save the parameter settings.



Figure 8-2 Configuration Codes of Saving

## 8.5 Set Configuration Codes of Data Processing

You can set the device's output code results via scanning the specific configuration codes as shown below.

### Configuration Codes of Prefix or Suffix

**Table 8-6 Configuration Codes of Prefix or Suffix**

| Function          | Configuration Codes                                                                 | Function           | Configuration Codes                                                                   |
|-------------------|-------------------------------------------------------------------------------------|--------------------|---------------------------------------------------------------------------------------|
| Enable Prefix     |    | Disable Prefix     |    |
| Edit Prefix       |    | Enable Suffix      |    |
| Disable Suffix    |    | Edit Suffix        |    |
| Enable Terminator |  | Disable Terminator |  |
| Edit Terminator   |  | /                  | /                                                                                     |

### Configuration Codes of Carriage Return or New Line

**Table 8-7 Configuration Codes of Carriage Return or New Line**

| Function               | Configuration Codes                                                               | Function                | Configuration Codes                                                                 |
|------------------------|-----------------------------------------------------------------------------------|-------------------------|-------------------------------------------------------------------------------------|
| Enable Carriage Return |  | Disable Carriage Return |  |
| Enable New Line        |  | Disable New Line        |  |

## 8.6 Set Configuration Codes of Aiming System

The aiming system is used to locate codes in the field of view to help read codes easily. The configuration codes can enable and disable the aiming system.

**Table 8-8 Configuration Codes of Aiming System**

| Function             | Configuration Codes                                                                 | Function              | Configuration Codes                                                                   |
|----------------------|-------------------------------------------------------------------------------------|-----------------------|---------------------------------------------------------------------------------------|
| Enable Aiming System |  | Disable Aiming System |  |

## 8.7 Set Configuration Codes of Light Source

The configuration codes of light source can enable/disable the light source, or change the light color.

---

**Note**

The supported configuration codes of light source may differ by device models or firmware versions.

---

Table 8-9 Configuration Codes of Light Source

| Function             | Configuration Codes                                                               | Function           | Configuration Codes                                                                 |
|----------------------|-----------------------------------------------------------------------------------|--------------------|-------------------------------------------------------------------------------------|
| Disable Light Source |  | Enable Solid Light |  |
| Enable Strobe Light  |  | Enable White Light |  |
| Disable White Light  |  | /                  | /                                                                                   |

## 8.8 Set Configuration Codes of Buzzer

The configuration codes of buzzer can enable or disable the buzzer function, set its duration, etc.

### Note

The supported configuration codes of buzzer may differ by device models or firmware versions.

Table 8-10 Set Configuration Codes of Buzzer

| Function                    | Configuration Codes                                                                 | Function                     | Configuration Codes                                                                   |
|-----------------------------|-------------------------------------------------------------------------------------|------------------------------|---------------------------------------------------------------------------------------|
| Enable Buzzer When Power On |  | Disable Buzzer When Power On |  |

| Function                                       | Configuration Codes                                                                | Function                                       | Configuration Codes                                                                  |
|------------------------------------------------|------------------------------------------------------------------------------------|------------------------------------------------|--------------------------------------------------------------------------------------|
| Set Buzzer Duration 1 Sec When Power On        |   | Set Buzzer Duration 2 Sec When Power On        |   |
| Set Buzzer Duration 3 Sec When Power On        |   | Enable Buzzer When Decoding Codes              |   |
| Disable Buzzer When Decoding Codes             |   | Set Buzzer Duration 50 ms When Decoding Codes  |   |
| Set Buzzer Duration 100 ms When Decoding Codes |  | Set Buzzer Duration 150 ms When Decoding Codes |  |

## 8.9 Set Configuration Codes of USB Communication

The configuration codes of USB communication can enable or disable the USB communication function.

---

### Note

- Only the USB type device supports the USB communication.
  - The supported configuration codes of USB communication may differ by device models or firmware versions.
-

**Table 8-11 Set Configuration Codes of USB Communication**

| Function                   | Configuration Codes                                                                 | Function                    | Configuration Codes                                                                   |
|----------------------------|-------------------------------------------------------------------------------------|-----------------------------|---------------------------------------------------------------------------------------|
| Enable USB Communication   |    | Disable USB Communication   |    |
| USB HID Communication Mode |    | USB CDC Communication Mode  |    |
| Set USB Baud Rate as 4800  |    | Set USB Baud Rate as 9600   |    |
| Set USB Baud Rate as 19200 |   | Set USB Baud Rate as 38400  |   |
| Set USB Baud Rate as 57600 |  | Set USB Baud Rate as 115200 |  |
| USB Multi-Mode Driver      |  | USB HID Driver Mode         |  |

## 8.10 Set Configuration Codes of Serial Port

The configuration codes of serial port can enable or disable serial port function, set the

baud rate, parity bit, and stop bit.

**Table 8-12 Set Configuration Codes of Serial Port**

| Function                           | Configuration Codes                                                                 | Function                            | Configuration Codes                                                                   |
|------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------|---------------------------------------------------------------------------------------|
| Enable Serial Port Function        |    | Disable Serial Port Function        |    |
| Set Serial Port Baud Rate as 4800  |    | Set Serial Port Baud Rate as 9600   |    |
| Set Serial Port Baud Rate as 19200 |   | Set Serial Port Baud Rate as 38400  |   |
| Set Serial Port Baud Rate as 57600 |  | Set Serial Port Baud Rate as 115200 |  |
| Set None Parity                    |  | Set Odd Parity                      |  |
| Set Even Parity                    |  | Set Stop Bit 1                      |  |

| Function       | Configuration Codes                                                               | Function | Configuration Codes |
|----------------|-----------------------------------------------------------------------------------|----------|---------------------|
| Set Stop Bit 2 |  | /        | /                   |

## 8.11 Set Configuration Codes of Sending Device Information

The device can send its information to the PC via reading specific configuration codes, and the device information includes name, version, algorithm version, firmware version, and serial number.

**Table 8-13 Set Configuration Codes of Sending Device Information**

| Function                                              | Configuration Codes                                                                 | Function              | Configuration Codes                                                                   |
|-------------------------------------------------------|-------------------------------------------------------------------------------------|-----------------------|---------------------------------------------------------------------------------------|
| Send Device Name<br>(Communication Protocols Enabled) |   | Get Device Version    |   |
| Get Firmware Version                                  |  | Get Algorithm Version |  |
| Get Serial Number                                     |  | /                     | /                                                                                     |

## 8.12 Set Configuration Codes of Trigger

The configuration codes of trigger can let the device switch the trigger mode, including software trigger, button trigger, self-trigger, brightness trigger, serial port trigger, and

support disabling trigger mode.

**Table 8-14 Set Configuration Codes of Trigger**

| Function            | Configuration Codes                                                                | Function             | Configuration Codes                                                                  |
|---------------------|------------------------------------------------------------------------------------|----------------------|--------------------------------------------------------------------------------------|
| Software Trigger    |   | Self-Trigger         |   |
| Button Trigger      |   | Brightness Trigger   |   |
| Serial Port Trigger |  | Disable Trigger Mode |  |

## 8.13 Set Configuration Codes of Management

The configuration codes of management can load default settings, save settings, or restore to default settings.

**Table 8-15 Set Configuration Codes of Management**

| Function                            | Configuration Codes                                                                 | Function                                 | Configuration Codes                                                                   |
|-------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------|---------------------------------------------------------------------------------------|
| Load Default Settings               |  | Save Settings                            |  |
| Address of Loading Default Settings |  | Request of Restoring to Default Settings |  |

| Function                                      | Configuration Codes                                                               | Function                                 | Configuration Codes                                                                 |
|-----------------------------------------------|-----------------------------------------------------------------------------------|------------------------------------------|-------------------------------------------------------------------------------------|
| Confirmation of Restoring to Default Settings |  | Device Reset                             |  |
| Address of Device Reset                       |  | Address of Restoring to Default Settings |  |
| Address of Serial Port Picture Trigger        |  | /                                        | /                                                                                   |

## 8.14 Set Configuration Codes of Log

The configuration codes of log are used for settings of serial port log, system log, algorithm log, and DSP log.

**Table 8-16 Set Configuration Codes of Log**

| Function               | Configuration Codes                                                                 | Function                | Configuration Codes                                                                   |
|------------------------|-------------------------------------------------------------------------------------|-------------------------|---------------------------------------------------------------------------------------|
| Enable Serial Port Log |  | Disable Serial Port Log |  |
| System Debugging Log   |  | System Information Log  |  |

| Function                  | Configuration Codes                                                                 | Function                | Configuration Codes                                                                   |
|---------------------------|-------------------------------------------------------------------------------------|-------------------------|---------------------------------------------------------------------------------------|
| System Alarm Log          |    | System Error Log        |    |
| System Shell Log          |    | Algorithm Debugging Log |    |
| Algorithm Information Log |    | Algorithm Alarm Log     |    |
| Algorithm Error Log       |   | Algorithm Shell Log     |   |
| DSP Debugging Log         |  | DSP Information Log     |  |
| DSP Alarm Log             |  | DSP Error Log           |  |
| DSP Shell Log             |  | /                       | /                                                                                     |

## 8.15 Set Configuration Codes of Power Management

The configuration codes of power management are used for settings of auto shutdown of the device.

**Table 8-17 Set Configuration Codes of Power Management**

| Function                | Configuration Codes                                                                 | Function                | Configuration Codes                                                                   |
|-------------------------|-------------------------------------------------------------------------------------|-------------------------|---------------------------------------------------------------------------------------|
| Shut Down After 30 Sec  |    | Shut Down After 60 Sec  |    |
| Shut Down After 180 Sec |    | Shut Down After 300 Sec |    |
| Shut Down After 420 Sec |   | Shut Down After 600 Sec |   |
| Shut Down After 720 Sec |  | Shut Down After 900 Sec |  |

## Chapter 9 Device Settings

---

### Note

- The device now supports IDMVS client software V5.0.0 and above, which features significant changes in UI. For detailed information on the new client software, please refer to the latest version of **IDMVS Client Software User Manual**. The following descriptions are still based on the older version of client software.
  - The functions such as [Characters Replace](#), [Multi-Reader Synchronization](#), [Lua Script](#), and [Set Parameter Polling](#) should be used in IDMVS V5.0.0 and above.
- 



Figure 9-1 IDMVS Client Software User Manual

### 9.1 Feature Tree

After the device is connected to the client software, and you can right click the device in **Device Connection**, and click **Feature Tree**.

---

### Note

The parameters of the feature tree may differ by device models and firmware versions.

---


Table 9-1 Feature Tree Description

| Name              | Description                                                                        |
|-------------------|------------------------------------------------------------------------------------|
| Device Control    | It allows you to view the device's information, edit its name, and restart device. |
| Read Setting      | It allows you to set the device's running mode and select code types.              |
| Image Setting     | It allows you to set frame rate, exposure, gain, Gamma, etc.                       |
| Algorithm Control | It allows you to set algorithm-related parameters.                                 |
| Focus Control     | It allows you to set the device's focus mode and related parameters.               |

| Name                   | Description                                                                                                                                                                 |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SelfAdapt Param        | It allows the device to automatically adjust exposure, gain, Gamma and other parameters to have a better code reading effect.                                               |
| LightSource Control    | It allows you to set the light source's parameters.                                                                                                                         |
| LineMode Control       | It allow you to customize the specific line as input or output according to actual demands.                                                                                 |
| Trigger and IO Control | It allows you to set parameters of input and output.                                                                                                                        |
| Stop Trigger Control   | It allows you to stop device trigger via TCP, UDP, I/O, serial port and USB. You can also set code reading timeout duration or max. code amount to be read to stop trigger. |
| Filter Rules           | It allows you to set the filtering rule of codes.                                                                                                                           |
| Communication Control  | It allows you to set parameters related to different communication protocols.                                                                                               |
| MultiCamera Control    | It allows you to set parameters of multi-camera to let them operate in a collaborative way.                                                                                 |
| Result Setting Control | It allows you to set parameters of outputted contents.                                                                                                                      |
| User Set Control       | It allows you to save and load configured user set.                                                                                                                         |

## 9.2 Running Mode Settings

After connecting the device, go to the left corner of live view window, and select the running mode.



**Figure 9-2 Select Running Mode**

**Table 9-2 Running Mode Description**

| Device Mode | Description                                                                                                                  |
|-------------|------------------------------------------------------------------------------------------------------------------------------|
| Test Mode   | It is used during device debugging. The device outputs images that are acquired in real time, and displays code information. |
| Normal Mode | It is used during device normal operation. After reading code in                                                             |

| Device Mode | Description                                                                                      |
|-------------|--------------------------------------------------------------------------------------------------|
|             | image, the device outputs image and code information.                                            |
| Raw Mode    | It is used during image data testing. The device outputs raw data and displays code information. |

---

 **Note**

Stopping the real-time acquisition is required before selecting the running mode.

---

## 9.3 Image Quality Settings

This section introduces how to set image-related parameters of the device via client software.

### 9.3.1 Set Image

You can set parameters like exposure time, gain, Gamma, acquisition frame rate, acquisition burst frame count, etc. in **Image Settings** area.

---


 **Note**

- For specific parameter range like exposure time, gain and acquisition frame rate, refer to the device's specification for details.
  - Specific parameters of this function may differ by device models.
- 

**Table 9-3 Set Image Parameters**

| Name                                    | Description                                                                                                                                                                                                                                                                      |
|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Exposure Time(<math>\mu</math>s)</b> | You can increase exposure time to improve image brightness.<br> <b>Note</b><br>To some extent, increasing the exposure time will reduce the acquisition frame rate, and impact image quality. |
| <b>Gain(dB)</b>                         | You can increase gain to improve image brightness.<br> <b>Note</b><br>Increasing gain will create more image noises, and impact image quality.                                                |
| <b>Gamma</b>                            | Gamma allows you to adjust the image contrast. It is recommended to reduce Gamma to increase brightness in dark background.                                                                                                                                                      |

| Name                                 | Description                                                                                                                                                                                                                                                                                                                                        |
|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Acquisition Frame Rate(fps)</b>   | Acquisition frame rate refers to the image quantity that is acquired by the device per second.<br> <b>Note</b><br>Increasing the exposure time will reduce the acquisition frame rate, and decreasing the exposure time will increase the acquisition frame rate. |
| <b>Acquisition Burst Frame Count</b> | Acquisition burst frame count refers to the output image quantity when the device is triggered once.                                                                                                                                                                                                                                               |
| <b>Polling Enable</b>                | It enables the polling function, and you can select off, single or multiple mode.<br> <b>Note</b><br>The parameter of polling enable will be displayed only when the trigger mode is on. Refer to section <a href="#">Set Parameter Polling</a> for details.      |


**Figure 9-3 Set Image Parameters**

### Note

The value range of exposure time and gain, and the maximum value of acquisition frame rate are related to the device model. Refer to the device's specifications for specific parameters.

## 9.3.2 Set Parameter Polling

### Note

The following descriptions are based on the IDMVS V5.0.0 and above.

For dynamic and complex code-reading scenarios (e.g., varying code positions or fluctuating lighting), the parameter polling function allows you to preconfigure multiple

sets of imaging parameters. As the code reader executes grabbing, it automatically switches among these parameter sets to adapt to environmental changes, ensuring stable and accurate code recognition in dynamic scanning scenarios. This section takes multiple parameter polling as an example to introduce this function.

## Before You Start

- You should disable **Real Grabbing** of the code reader.

## Note

If **Real Grabbing** is enabled, parameter polling cannot be configured.

- The **Trigger Mode** has been enabled, and the **Trigger In Source** is not **Brightness**.


## Steps

- In the main interface navigation bar of IDMVS, select **Param Polling**.
- From the dropdown menu at the top of the **Param Polling** page, choose **Multiple Polling**.



**Figure 9-4 Parameter Rolling**

You should enable any two or more polling parameters. The code reader can alternately apply the enabled polling parameters for code reading until a code is successfully captured, and then the polling stops. The polling sequence between the 8 sets of parameters is shown in the following figure. The polling rule begins with the optimal parameter group and proceeds through the enabled parameter groups in ascending order. For example, if the enabled polling parameters are 1, 2, 3, 4, 5, and the current parameter is 3 (i.e., group 3 is set as the optimal group), the polling sequence will be 3, 4, 5, 1, 2, which constitutes one polling cycle.



**Figure 9-5 Polling Diagram**

## Note

If you need to execute single polling, select **Param \*** (\* is the polling group number) to apply a specific parameter group. The current parameter polling interface only supports configuring parameters of the selected group, and parameters of other polling groups are unavailable. The code reader will apply the currently selected polling parameters during operation.

3. Configure the target polling parameters. The descriptions of polling parameters are as follows:

## Note

- The polling parameters may differ by device firmware version.
- The modified parameter cells are highlighted in purple.
- The parameters for single-group parameter polling are similar to those for multi-group parameter polling, so this content will take the multiple-group parameter polling parameters as an example.
- **Polling Param Name:** Customize the name of the polling parameter.
- **Polling Param ChgTime:** Display the last editing time of polling parameters. If there is no editing, 1970-01-01 is displayed by default.
- **Polling Param Enable:** Enable/disable the current polling param in the polling sequence of the code reader.

## Note

It is only available for **Multiple Polling**. At least 2 polling parameters are required.

- **Polling SingleParam Timeout(ms):** Set the maximum waiting time for code reading in the current polling parameter. If no codes are read during this period, the code reader will stop reading codes and apply the next polling parameter.

- **Polling SingleParam Period:** Configure frame output quantity during code reading with the current polling parameter.
  - **Polling ROI Region Index:** Set the ROI index for the code reader to read codes by applying the current polling parameter. If 0 or an invalid index is set, the code reader will read all codes in the field of view.
  - **Code Info Settings:** Click **Part Code** to select code types on the **Bar Code Info Setting** page, and configure their valid bit ranges.
- 

### **Note**

At the top of the **Bar Code Info Setting** page, you can select all code types at once by checking the **All** button.

---

- **Internal Light Source:** Enable light channels on the light source diagram of the code reader. Click **All** to turn on all lights. After turned on, the lights are in green color.
- 

### **Note**

The light source diagram corresponds to the built-in light source on the code reader.

---

- **External Light Source:** If the code reader is connected to external light sources through I/O pins, you can select pin No. and enable light sources.
  - **Image Setting:** Refer to section [Image Quality Settings](#) for details of image-related parameters.
  - **Polling Focus Pos Enable:** Enable/disable focal length configuration during parameter polling. When it is enabled, set the lens focal length of the code reader through **Polling Focus Pos**.
  - **Polling Time (ms):** Set the polling duration. The polling mode requires at least 2 output frames to determine the polling stopping status.
- 

### **Note**

You can configure the parameter at the bottom of the **Param Polling** page only when multiple polling is selected.

---

- **Polling Period:** Set the number of periods for parameter polling operation. All enabled polling parameters constitute a polling cycle.
- 

### **Note**

You can configure the parameter at the bottom of the **Param Polling** page only when multiple polling is selected.

---

- **Polling Stop Trigger Enable:** Whether to configure a stop condition for triggered parameter polling. When it is enabled, stop conditions can be set through the **Polling Stop Condition**. Available options are as follows.
    - **Single Polling Frame:** Stop current parameter polling based on the number of codes read within a single frame image. After selection, the number of codes can be specified through **Polling Code Num** to trigger the stop.
    - **Whole Polling Period:** Specify the number of codes read within the whole polling
-

period. After selection, the number of codes can be specified through **Polling Code Num** to trigger the stop.

---

### **Note**

You can configure the parameter at the bottom of the **Param Polling** page only when multiple polling is selected.

---

4. Repeat Step 3 to configure the parameters of the target polling group. You can use the following functions when configuring the parameters of other groups.

- **Search:** Support parameter searching based on input content. If a parameter contains the input content, the corresponding parameter is highlighted in orange.
- 

### **Note**

Searching function is case-sensitive.

---

- **Add Param:** Support adding a new group of polling parameters.
- 

### **Note**

Only some code reader models with firmware version V4.0.0 and above support adding polling parameter groups. Up to 8 groups can be added (16 groups in total). Refer to the actual interface for details.

---

- **Restore Default:** Restore all parameters of the current polling group to default values.
- : Click this icon to set the current polling group as follows.
  - **Col Restored Default:** Restore all parameters of the current polling group to default values.
  - **Apply To All:** Apply the parameters of the current polling group to other polling groups.
  - **Apply To Other:** Apply the parameters of the current polling group to the specified polling group.

5. Click **Save** at the top of the **Param Polling** page. Once saved, the polling parameters will be triggered when the code reader starts operation.

---

## 9.3.3 Set Light Source

Light source control allows you to enable the device's aiming system and light source, and set related parameters according to actual demands.

---

### **Note**

- Light source parameters may differ by device models.
  - Make sure you have selected the device to be set in **Device Connection** before setting light source parameters.
-

**Steps**


1. Go to **Image Settings** → **Light**, and enable **AimingLight Enable** according to actual demands.
- 

 **Note**

After this function is enabled, the device's aiming light will turn on immediately upon power-up, regardless of the streaming mode, running mode, or trigger mode.

---

2. Enable **Lighting Enable** to enable the light source according to actual demands.
3. (Optional) Set **Lighting Duration** and **Precharge Time** if **Lighting Enable** is enabled.



**Figure 9-6 Set Light Source**

### 9.3.4 Set Smart Tune

The smart tune function allows you to adjust the device's focus position, exposure, gain, etc. by one-key operation, and supports self-adaptive adjustment.

The smart tune function has two methods to be realized, including smart tune by pressing tune button and smart tune via the client software.

---

 **Note**

The smart tune function is supported by some device models and firmware versions.

---

#### Smart Tune by Pressing Tune Button


---

 **Note**

- The parameters of the smart tune may differ by device models and firmware versions.
  - During the process of smart tune, the focus parameters and self-adaptive parameters will be adjusted in turn.
- 

**Steps**

1. Go to **Image Settings**, click **All Features** on the right corner, and find **SmartTuneControl**.
2. Enable **Button Tune**, and disconnect the device from the client software.



**Figure 9-7 Button Tune**

---

**Note**

Smart tune by pressing the tune button is not supported if the device is connected via the client software.

---

3. Hold the tune button for 3 seconds, and the device starts smart tune.
  - During smart tune process, the status indicator flashes in green and red colors alternatively.
  - If smart tune succeeds, the status indicator is solid green lasting 3 seconds and then restores.
  - If smart tune fails, the status indicator is solid red lasting 3 seconds and then restores.
4. (Optional) Hold the button for 3 seconds again during smart tune process, and the smart tune will be cancelled.

## Smart Tune via Client Software


Apart from pressing tune button to realize smart tune, you can also configure parameters via the client software to realize it.

### **Before You Start**

Make sure that the device is not in trigger mode, and its running mode is test.


### **Steps**

1. Go to **Image Settings**, click **All Features** on the right corner, and find **SmartTuneControl**.



**Figure 9-8 Smart Tune Control**

2. (Optional) Set **Tune Timeout**. If the self-adaptive adjustment exceeds configured value, and it will stop automatically and show the timeout information.
3. Click **Execute** in **Smart Tune Start** to let the device start smart tune, and a window of smart tune will be displayed for you to view the effect.



**Figure 9-9 Smart Tune Start**

4. (Optional) View smart tune process via **Smart Tune Status**.
5. (Optional) Click **Execute** in **Stop Tune** to stop smart tune process.
6. (Optional) You can set focus-related parameters and self-adaption parameters via **Focus Param** and **SelfAdapt Param**.

---

### **Note**

Refer to section [Set Focus](#) and section [Set Self-Adaptive Adjustment](#) for details.

---

## 9.3.5 Set Focus

The device supports the focus function according to the code position in the field of view. Currently, three types of focus are supported, including global auto focus, global manual focus, and ROI focus.

---

### **Note**


- Make sure that the device's running mode is test before performing focus, and switch to the normal running mode after the focus is completed.
  - The focus function may differ by device models.
-

## Global Auto Focus

The global auto focus allows you to adjust lens focus in a global field of view just by once.

### Steps

1. Go to **Image Settings** → **SmartTuneControl** → **Focus Param** → **Focus Mode Selector**, and select **Whole Area Focus** as **Focus Mode Selector**.



**Figure 9-10 Global Auto Focus**

2. Click  in the live view window, and click it again to stop acquisition and make sure there is an image in the window.
3. Select the focus mode in **Auto Config**:
  - **Full Auto**: In this mode, the device will automatically change parameters like focus position, exposure, gain, Gamma and light source when adjusting focus.
  - **Motor Only**: In this mode, the device will change focus position only when adjusting focus.
  - **Auto and Restore**: In this mode, the device will automatically change parameters like focus position, exposure, gain, Gamma and light source when adjusting focus, and keep focus position and restore other parameters after completing focus adjustment.
4. Click **Execute** in **Focus Mode**, and the device starts to adjust focus automatically.

---

### Note

Focus-related parameters cannot be configured during auto focus process, and after the process, parameters can be configured again.

---

5. (Optional) Select the position parameter from **Focus Position**, and click **Execute** in **Focus Position Save** to save the focus position after adjusting focus.
6. (Optional) View **Focus Score** to know the score of the focus adjustment.

## Global Manual Focus

The global manual focus requires manual focus according to the images displayed in the live view window.

### Steps

1. Go to **Image Settings** → **Smart Tune Control** → **Focus Param** → **Focus Mode Selector**, and select **Whole Area Focus** as **Focus Mode Selector**.
2. Click  in the live view window, and click it again to stop acquisition and make sure there is an image in the window.
3. Select **Focus Position** according to actual demands and **Focus Position Param**.
4. Set **Focus Step** according to actual demands.
5. Click **Execute** in **Focus Positive Execute** and **Focus Negative Execute** to adjust focus position.
6. (Optional) View **Focus Score** to know the score of the focus adjustment.
7. (Optional) Select the position parameter from **Focus Position**, and click **Execute** in **Focus Position Save** to save the focus position after adjusting focus.
8. (Optional) Click **Execute** in **Original Focus Execute** to let the focus back to its original position.

## ROI Focus

The ROI focus allows you to adjust lens focus regarding the ROI area by drawing specific area.

---


### Note

The ROI focus is applicable to the scenario where multiple codes with different depth of fields are existing.

---


### Steps

1. Go to **Image Settings** → **Smart Tune Control** → **Focus Param** → **Focus Mode Selector**, and select **ROI Area Focus** as **Focus Mode Selector**.



**Figure 9-11 ROI Focus**

2. Click  in the live view window, and click it again to stop acquisition and make sure there is image in the window.
3. Click **Draw** in **Draw Focus ROI**, and draw ROI by dragging the mouse in live view window.



**Figure 9-12 Draw Focus ROI**

4. (Optional) Set the following parameters to adjust ROI size and position.
  - **AF Offsex X**: It is X coordinate of the upper-left corner in ROI where executes auto focus.
  - **AF Offsex Y**: It is Y coordinate of the upper-left corner in ROI where executes auto focus.
  - **AF Width ROI**: It refers to the width in ROI where executes auto focus.
  - **AF Height ROI**: It refers to the height in ROI where executes auto focus.
5. (Optional) Click **Execute** in **Max. Focus ROI** to have a global focus.
6. (Optional) Repeat step 3 if you want to set multiple ROIs.

## 9.3.6 Set Self-Adaptive Adjustment

The function of self-adaptive adjustment can automatically adjust exposure, gain, Gamma

and other parameters to have a better code reading effect.

---

### **Note**

The function and parameters of self-adaptive adjustment may differ by device models.


---

### **Before You Start**

Make sure you have connected the device to the client software and have stopped acquisition.


### **Steps**

1. Go to **Image Settings** → **SmartTuneControl** → **SelfAdapt Adjust**, and unfold **Self Adapt Adjust**.
2. Select an adjustment mode.
  - **High Quality**: If you select this mode, exposure will be adjusted in priority. The acquired picture will have a smaller gain and noise, which makes a higher picture quality. It is suitable for objects with a slow moving speed.
  - **High Speed**: If you select this mode, gain will be adjusted in priority. There may be more noise on the picture. It is suitable for objects with a fast moving speed.
3. Select **Adjust Source** according to actual demands.



**Figure 9-13 Select Adjust Source**

- **Default Param**: It adjusts the default parameters.
- **Polling Param**: It adjusts parameters configured in polling. After **Polling Param** is selected as **Adjust Source**, you should select a polling parameter group from **Polling Param** and enable or disable **Focus Enable**.



**Figure 9-14 Polling Parameter**

4. (Optional) Set light source parameters in **Lighting Mode**.
  - **Light Adapt**: The client software will select the best one from all lighting options during the self-adaptive adjustment.
  - **All Light Enable**: All light sources will be turned on during self-adaptive adjustment process.
  - **All Light Disable**: All light sources will be turned off during self-adaptive adjustment process.
5. (Optional) Set self-adaptive code type in **Code Type Mode**.
  - **Code SelfAdapt**: All code types added in field of view will be self-adaptive.
  - **1D Code**: 1D code types added in field of view will be self-adaptive.
  - **2D Code**: 2D code types added in field of view will be self-adaptive.
  - **Stacked Code**: Stacked code types added in field of view will be self-adaptive.
6. (Optional) Set **Exposure Max** or **Gain Max** according to actual demands.
  - **Exposure Max**: It sets the max. exposure in the high speed mode.
  - **Gain Max**: It sets the max. gain in the high quality mode.
7. Click **Execute** in **Adjust Start**. The device will automatically acquire images and perform self-adaptive adjustment, and stop acquisition after adjustment is completed.

---

 **Note**

If the adjustment is completed, the client software displays the spent time and prompts adjustment succeeded, and the exposure and gain are the values configured in the self-adaptive adjustment. If the adjustment failed or is timeout, the client software prompts adjustment failure or timeout.

---

### 9.3.7 Set Mirror X

The device supports the mirror X functions.

Go to **Image Settings** → **Other Features** to set **Mirror X** according to actual demands. If the parameter is enabled, the image will be reversed in a horizontal way.

---

 **Note**

The **Mirror X** is enabled by default, and it may differ by device models.

---

### 9.3.8 Set Test Pattern

Test pattern helps troubleshooting image problems and images in the test pattern are only for test. When exceptions occur in images acquired by the device in real time, you can check if images in the test pattern have similar problems to determine the cause of an exception.

---

#### Note

Specific parameters of this function may differ by device models.

---

Go to **Image Settings** → **Other Features**, and set **Test Pattern** according to actual demands.




Figure 9-15 Set Test Pattern

## 9.4 Code Algorithm Settings

The code reader supports reading multiple types of 1D code, 2D code, and stacked codes, and you can add and set code parameters via the client software.

### 9.4.1 Add Code

Adding code before you set code parameters via the client software. In **Algorithm Settings**, you can add different types of codes according to actual demands.

In **Algorithm Settings**, you can select types of codes to be read, and set the **Number of 1D Code**, **Number of 2D Code**, or **Number of Stack Code** according to actual demands.

---

#### Note

- For different models of the device, the specific parameters may differ, and the actual device you purchased shall prevail.
  - The number of selected symbologies and codes may affect the code recognition time. More symbologies or more codes selected may consume more time to recognize codes in the image. Please select code according to the actual demands.
  - The code reader may output actual code quantity when the actual code quantity is less than the code quantity set in the client software.
-

## 9.4.2 Set Code Reading ROI

Algorithm ROI (Region of Interest) allows the device to execute algorithms and read codes on the specific area you selected, and thus improving code reading efficiency.

Currently, multiple ROIs can be configured, and the device outputs codes according to the number of ROI (e.g. Region 1, Region 2, and Region 3...) in turn. The client software supports drawing single group of ROI and drawing ROI via chessboard.

---


### Note

- If no code is recognized in the algorithm ROI, and the device will output “noread”.
  - Before drawing ROIs, make sure that there are images in the live view window after stopping preview.
  - If no algorithm ROI is enabled, and the full screen is the algorithm ROI by default.
  - This function may differ by device models.
- 

## Draw Single Group of ROI

### Steps

1. Go to **Algorithm Settings**, and find **Algorithm ROI**.
2. Click **Draw** in **Draw ROI** to draw the ROI in the live view window.



**Figure 9-16 Draw ROI**

3. (Optional) Repeat the above step to draw multiple ROIs according to actual demands.

---

### Note

The client software only parse codes in the ROI you drawn.

---

4. (Optional) Set other ROI-related parameters according to the actual demands.
  - **ROI Index:** It indicates different ROIs and ranges from 0 to 149 corresponds 1 to 150 ROIs.

- **AlgoRegionWidth**: It refers to the width in algorithm ROI.
- **AlgoRegionHeight**: It refers to the height in algorithm ROI.
- **AlgoRegionLeftX**: It refers to the X coordinate of the upper-left corner in algorithm ROI.
- **AlgoRegionLeftY**: It refers to the Y coordinate of the upper-left corner in algorithm ROI.

|                  |     |
|------------------|-----|
| ROI Index        | 3   |
| AlgoRegionWidth  | 979 |
| AlgoRegionHeight | 792 |
| AlgoRegionLeftX  | 469 |
| AlgoRegionLeftY  | 709 |


**Figure 9-17 ROI Parameters**

5. (Optional) Click **Execute** in **Restore Max. Algorithm ROI** to restore the ROI to the full screen.
6. (Optional) Click **Execute** in **Clear All ROI** to delete all ROIs.
7. (Optional) Right-click the ROI and click **Delete** to delete the selected ROI.
8. (Optional) After you enable the **ROI Link IO Enable** in **Feature Tree** → **Trigger and IO Control**, and when the code is not read in any ROI, the linked output device will output a message.

## Draw ROI via Chessboard

### Steps


1. Go to **Algorithm Settings**, and find **Algorithm ROI**.
2. Click **Execute** in **Chessboard ROI**, set parameters, and click **OK** after setting.



The dialog box titled "Create Chessboard ROI" has a close button (X) in the top right corner. It contains two input fields: "Rows Number" with a value of 2 and "Columns Number" with a value of 2. Below these fields, there are two lines of text: "\*Maximum Rows:12" and "\*Maximum Columns:16". At the bottom of the dialog, there are two buttons: "OK" and "Cancel".

**Figure 9-18 Create Chessboard ROI**

3. (Optional) Click  to restore the ROI to full screen, and click  to clear all ROIs.
4. Click  after creating ROI, and the red frame becomes green as shown below.



**Figure 9-19 Draw ROI via Chessboard**

5. Repeat other optional steps mentioned in drawing single group of ROI.
6. (Optional) Enable **ROI Link IO Enable** in **Algorithm Control**, and there will be prompts by the output device when codes are not read in any ROI.

---

 **Note**

- The figures above are for reference only. Refer to the actual conditions.
  - When no ROIs are enabled, the current ROI defaults to full screen.
  - When some ROIs are enabled, the disabled ROI is located at the top-left corner (0, 0) with a size of 128 × 128 pixels.
- 

### 9.4.3 Set Algorithm Parameter

In **Algorithm Parameter**, select **1DCode** or **2DCode** as **Arithmetic Type**, and then you can set the related parameters.

---

 **Note**

- You should have selected at least one type of 1D code or 2D code.
  - For different models of the device, the specific parameters may differ, and the actual device you purchased shall prevail.
-

## Set 1D Code

### Waiting Time

Waiting time refers to the maximum running time of algorithm, and its unit is ms. The code reader will stop parsing the images and return results if the time is exceeded the waiting time configured. When the value is set as 0, the actual running time of algorithm will prevail.

### Code Color

It defines the readable code color. **WhiteCodeOnBlackWall** means that the client software can recognize the white code with black background. **BlackCodeOnWhiteWall** means that the client software can recognize the black code with white background. **Adaptive** means that the device can recognize both types of codes mentioned above. However, the reading time will be longer compared with the above two modes.

### Code 39 Check

Enable this parameter if Code 39 uses the parity bit.



#### Note

You need to select **Code 39** in **Select Code**.

---

### ITF 25 Check

Enable this parameter if ITF 25 uses the parity bit.



#### Note

You need to select **ITF 25** in **Select Code**.

---

### Code Score Enable

If it is enabled, the client software will evaluate the code reading environment for 1D code and output code score.

### Accurate Timeout Enable

If it is enabled, the accuracy of algorithm timeout will improve.

## Set 2D Code

### Waiting Time

Waiting time refers to the maximum running time of algorithm, and its unit is ms. The code reader will stop parsing the images and return results if the time is exceeded the waiting time configured. When the value is set as 0, the actual running time of algorithm will prevail.

### Algorithm Running Mode

It is used to be set the algorithm operating mode. It includes **HighSpeed**, **HighPerformance**, and **Balance**. **HighSpeed** focuses on recognition speed, and the

algorithm can recognize the code rapidly, while **HighPerformance** refers to the algorithm can recognize the code that has distortion, spot or white gap, but its recognition speed is slow. **Balance** refers to the algorithm makes a balance between speed and performance.

### 2D Code Max. Size

It refers to the max. recognizable code width. The 2D code will not be recognized if its width exceeds the configured value.

### Mirror Mode

It is useful when the recognized image is a mirror one, mirroring in X coordinate. Three modes are available: **Adaptive**, **Mirror**, and **NonMirror**.

### Downsampling Level

It refers to the pixel sample size that the code reader takes. Increasing this parameter will improve the code reading efficiency at the expense of code recognition rate.

### Code Color

It defines the readable code color. **WhiteCodeOnBlackWall** means that the client software can recognize the white code with black background. **BlackCodeOnWhiteWall** means that the client software can recognize the black code with white background. **Adaptive** means that the device can recognize both types of codes mentioned above. However, the reading time will be longer compared with the above two modes.

### Discrete Flag

**Continuous** stands for the minimum units in the "L" shaped sides of the DM code are continuous, or the minimum units in the concentric square like  or  in the QR code are continuous. Usually the continuous code uses squares as the minimum units.

**Discrete** stands for the minimum units in the "L" shaped sides of the DM code are discrete, or the minimum units in the concentric square like  or  in the QR code are discrete. Usually the discrete code uses dots as the minimum units.

**Adaptive** stands for the device can recognize both continuous code and the discrete code.

### QR Distortion Correction

If the QR code or DM code is distorted, you can enable this parameter to improve code recognition rate. The parameter is disabled by default.

---

#### Note

If you enable this parameter, the more time will be consumed to recognize the codes in the image.

---

### DM Code Shape

It defines the recognizable code shape. **Square** stands for square mode: If the 2D code is square shaped, it can be recognized by the device. **Rectangle** stands for rectangle mode: If the 2D code is rectangle shaped, it can be recognized by the device. **Adaptive** stands for compatible mode: The device can recognize 2D codes of both the above-

mentioned two shapes.

### **DM Code Type**

It includes **All**, **ECC140**, and **ECC200**.

### **2D Code Quality Enable**

If it is enabled, the client software will judge the quality of 2D code and output overall grade. Currently, this parameter is only applicable to DM code and QR code.

### **Code Score Enable**

If it is enabled, the client software will evaluate the code reading environment for 2D code and output code score.

### **Accurate Timeout Enable**

If it is enabled, the accuracy of algorithm timeout will improve.

## **9.4.4 Set Code Quality Evaluation**

The code quality evaluation function judges the quality of codes and outputs overall grade. Currently, only DM code supports code quality evaluation.

---

### **Note**

- The function of code quality evaluation may differ by device models.
  - In test operation mode, this function is enabled by default. In normal mode, you need to enable it manually.
  - This function is also supported for multiple codes in the field of view.
- 

### **Before You Start**

Make sure that the device's operation mode is normal.

### **Steps**

1. Go to **Algorithm Settings**, and select **2DCode** as **Arithmetic Type**.
2. Enable **2D Code Quality Enable**.
3. Set **Iso Edition**, including Iso15415 and Iso29158
  - Iso15415 is applicable to the quality evaluation for label 2-dimensional codes.
  - Iso29158 is applicable to the quality evaluation for DPM format 2-dimensional codes.
4. Set **Verify Edition**, including standard mode and HIK mode.
  - Standard mode is a standard quality evaluation mode.
  - HIK mode is a professional quality evaluation mode.
5. Select the evaluation criteria based on your actual demands. If enabled, the rating standard is used to evaluate the code quality.

**Table 9-4 Code Quality Evaluation Standards**

| Parameter  | Description                                  |
|------------|----------------------------------------------|
| TDCRDecode | It evaluates whether the code recognition is |

| Parameter                 | Description                                                                                                   |
|---------------------------|---------------------------------------------------------------------------------------------------------------|
|                           | successful or not.                                                                                            |
| TDCRSymbolContrast        | It evaluates the difference between the max. brightness value and the min. brightness value of the code area. |
| TDCRModulation            | It evaluates the degree of change in terms of brightness.                                                     |
| TDCRFixedPatternDamage    | It evaluates the damage of code formats.                                                                      |
| TDCRAXialNonuniformity    | It evaluates the distortion degree of the code's vertical and horizontal sizes.                               |
| TDCRUnusedErrorCorrection | It evaluates the code for grid damage which might reduce the error correction capability of the code.         |
| TDCRGridNonuniformity     | It evaluates the distortion of the grids in the code.                                                         |
| TDCRPrintGrowth           | It evaluates whether the size of each unit of the code is uniform                                             |

6. Set the evaluation value for A/B/C/D grade according to actual demands.
- If the actual code reading value is greater than the grade A evaluation value, the evaluation standard is grade A.
  - If the actual code reading value is between grade A and grade B, the evaluation standard is grade B.
  - If the actual code reading value is between grade B and grade C, the evaluation standard is grade C.
  - If the actual code reading value is between grade C and grade D, the evaluation standard is grade D.
  - If the actual code reading value is lower than the grade D evaluation value, the evaluation standard is grade F.
  - The client software selects the worst grade among all the evaluation standards as the grade judgment result of the code. The A grade means that the code quality is best, and F grade means that code quality is worst.

### 9.4.5 Set Code Score

The code score function evaluates the code-reading environment for codes and outputs code score.

---


#### Note

- The function of code score may differ by device models.
- In test mode, this function is enabled by default. In normal mode, you need to enable it manually.

- The code score is determined by two factors including image quality and print quality of codes. The range of code score is between 0 and 100, and the higher the score, and easier the code can be read.

## Steps

1. Go to **Algorithm Settings**, and enable **Code Score Enable**.



**Figure 9-20 Enable Code Score Enable**

2. Click  to start acquisition, and the client software will display specific code score in the history record area.

| History |                        | Image Cache      |               |     |              |         |                    |            |            |
|---------|------------------------|------------------|---------------|-----|--------------|---------|--------------------|------------|------------|
| No.     | Read Time              | Output Total Cos | Cost Time(ms) | PPM | Barcode Type | Waybill | Barcode Content    | Overall Gr | Code Score |
| 134     | 2023/6/25 17:13:38:344 | 5025673          | 107           | 15  | QRCode       |         | 313200953002023... | ▲          | 62         |
| 133     | 2023/6/25 17:13:38:344 | 5025673          | 107           | 5.8 | Code 128     |         | 1.000              | F          | 64         |
| 132     | 2023/6/25 17:13:38:344 | 5025673          | 107           | 5.9 | Code 128     |         |                    | F          | 66         |

**Figure 9-21 Code Score**

3. (Optional) If the code score is low, go to **Image Settings**, and adjust parameters such as exposure time, gain, Gamma, and light source.

## Note

If the code score is still low after adjusting, the code may have poor printing quality.

## 9.5 Input/Output Settings

### 9.5.1 Line Mode Settings

Line mode settings allow you to customize the specific line as input or output according to


actual demands.

Go to **I/O Control Settings** → **Line Mode Control**, and set **Input** or **Output** according to actual demands.

---

#### **Note**

- If the device has 4 bi-directional I/Os, Line 0 and Line 1 are input, and Line 2 and Line 3 are output by default.
  - Line 0 should be same with Line 1 as input or output, and Line 2 should be same with Line 3 as input or output.
  - Refer to section [I/O Electrical Feature and Wiring](#) for I/O details.
- 



**Figure 9-22 Set Line Mode**

## 9.5.2 Signal Input Settings

In the signal input module, you can set the trigger-related parameters. You can enable trigger mode to let the acquisition of image data occur only when the trigger source is generated.

---

#### **Note**

- The specific function may differ by device models. Refer to the actual device you got.
  - The device trigger via pressing trigger button is supported by default. You can go to **Feature Tree** → **Trigger and IO Control** → **TRIG Button Enable** to set it.
- 

#### **Steps**


1. Click **I/O Control Settings** on the navigation bar to enter the I/O Control Settings panel.
  2. Click **Input** → **Trigger Mode**, and select **On** as **Trigger Mode**.
  3. Select a source type from the drop-down list of **Trigger Source**.
- 

#### **Note**

- The trigger source includes Software, LineIn 0/1/2/3, Counter 0, TCP Start, UDP Start, Serial Start, USB Start, and Self Trigger.
  - The device with USB interface supports two trigger sources (USB Start and Software) only, and the device with network interface supports all trigger sources apart from USB Start.
  - For specific trigger source, refer to the actual device you got.
- 

4. Set **Trigger Delay** according to the needs. The trigger delay function allows the device to add a delay between the receipt of trigger signal and the moment the trigger becomes active.

It is 0 by default and the unit is  $\mu\text{s}$ . The sequence diagram of trigger delay is shown below.



**Figure 9-23 Sequence Diagram of Trigger Delay**

5. Configure trigger-related parameters according to the selected trigger source. Refer to the section below.


## Set and Execute Software Trigger Mode

In software trigger, the software sends trigger signal to the device via I/O interface to acquire images.

### Steps

1. Click **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.
3. Select **Software** as **Trigger Source**.
4. Click **Execute** in **Trigger Source** to send trigger commands.

You can also enter **Auto Trigger Time**, and then enable **Enable Auto Trigger** to let the client software automatically send trigger signal to device according to the interval you set.




**Figure 9-24 Set and Execute Software Trigger Mode**

## Set and Execute Hardware Trigger Mode

### Steps

1. Go to **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.

3. Select the specific line as **Trigger Source** according to the actual demands.
  4. Set **Debounce Time**, **Trigger Block**, and **Trigger Activation** according to the actual demands.
- **Trigger debounce:** The trigger debounce function allows the device to filter out unwanted short external trigger signal that is input to the device. The sequence diagram of trigger delay is shown below.



**Figure 9-25 Sequence Diagram of Trigger Debounce**

- **Trigger block:** Once this function is enabled, the device will ignore trigger signals within a specified time period after a successful trigger. You can set **Trigger Block Time** as needed.

Input

Trigger Mode

On

Trigger Source

LineIn 0

Trigger Delay(us)

0.00

Debounce Time(us)

1000

Trigger Block

☒

Trigger Block Time(ms)

500

Trigger Activation

Rising Edge

**Figure 9-26 Set Trigger Block**

- **Trigger activation:** When selecting **Rising Edge** or **Falling Edge** as **Trigger Activation**, you can set **Trigger Delay**. When selecting **Level High** or **Level Low** as **Trigger Activation**, you can set **Start Delay Time** and **End Delay Time**.

Input

|                      |            |
|----------------------|------------|
| Trigger Mode         | On         |
| Trigger Source       | LineIn 0   |
| Debounce Time(us)    | 1000       |
| Start Delay Time(us) | 0          |
| End Delay Time(us)   | 0          |
| Trigger Activation   | Level High |

Figure 9-27 Set Trigger Activation

## Set and Execute Counter Trigger Mode

Counter specifies that the trigger source will be generated after the set number of valid signals appears. For example, if you set the **Count Number** to **3**, the trigger source will be generated after 3 signals appear.

### Steps

1. Go to **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.
3. Select **Counter 0** as **Trigger Source**.
4. Set **Trigger Delay**, **Count Number**, **Count Source**, and **Trigger Activation**

Input

|                    |                          |
|--------------------|--------------------------|
| Trigger Mode       | On                       |
| Trigger Source     | Counter 0                |
| Trigger Delay(us)  | 0.00                     |
| Count Number       | 1                        |
| Count Source       | Off                      |
| Trigger Activation | Rising Edge              |
| Trigger Cache      | <input type="checkbox"/> |

Figure 9-28 Set and Execute Counter Trigger Mode

## Set and Execute TCP Trigger Mode

TCP start specifies the TCP server as the source for the trigger signal. When the server receives the specified string text, the trigger signal will be output.

### Steps

1. Go to **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.
3. Select **TCP Start** as **Trigger Source**.

4. Set following parameters according to actual demands.

- **TCP Trigger Port:** It sets the port No. of the server.

---

 **Note**


- The port No. configured here should differ from that in the TCP server port in the communication settings. Otherwise, parameter configuration will fail.
  - This function shares the same port No. with the trigger stopping via TCP, and the settings for both will take effect.
- 
- **TCP Trigger Text Format:** When receiving the specified trigger text, the server will output a trigger signal. You can select the text format from **Str** or **Hex**.
    - If **Str** is selected, enter the text in string format in the box next to **TCP Start Trigger Text**.
    - If **Hex** is selected, enter the text in hexadecimal format in the box below **TCP Trigger Start String**. If needed, you can click  to open the ASCII Cross Reference Table and click a table cell to add the corresponding content to the text box.
  - **TCP Start Trigger Text:** It sets the trigger text of TCP Start, and it is **Start** by default.

---

 **Note**

You can also configure the string text for sending a TCP handshake request and receiving a TCP handshake response via **Trigger and IO Control** module on the feature tree.

---



The screenshot shows a configuration window titled 'Input' with a dropdown arrow. It contains the following settings:

| Parameter               | Value            |
|-------------------------|------------------|
| Trigger Mode            | On               |
| Trigger Source          | TCP Server Start |
| Trigger Delay(us)       | 0.00             |
| TCP Trigger Port        | 2001             |
| TCP Trigger Text Format | Str              |
| TCP Start Trigger Text  | start            |

**Figure 9-29 Set and Execute TCP Trigger Mode**

## Set and Execute UDP Trigger Mode

UDP start specifies the UDP server as the source for the trigger signal. When the server receives the specified string text, the trigger signal will be outputted.

### Steps

1. Go to **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.
3. Select **UDP Start** as **Trigger Source**.
4. Set following parameters according to actual demands.


- **UDP Trigger Port:** It sets the port No. of the server.

- **UDP Trigger Text Format:** When receiving the specified trigger text, the server will output a trigger signal. You can select the text format from **Str** or **Hex**.
    - If **Str** is selected, enter the text in string format in the box next to **UDP Start Trigger Text**.
    - If **Hex** is selected, enter the text in hexadecimal format in the box below **UDP Trigger Start String**. If needed, you can click **+** to open the ASCII Cross Reference Table and click a table cell to add the corresponding content to the text box.
  - **UDP Start Trigger Text:** It sets the trigger text of UDP Start, and it is **Start** by default.
- 

#### **Note**

You can also configure the string text for sending a UDP handshake request and receiving a UDP handshake response via **Trigger and IO Control** module on the feature tree.

---



|                         |           |
|-------------------------|-----------|
| ▼ Input                 |           |
| Trigger Mode            | On        |
| Trigger Source          | UDP Start |
| Trigger Delay(us)       | 0.00      |
| UDP Trigger Port        | 2002      |
| UDP Trigger Text Format | Str       |
| UDP Start Trigger Text  | start     |

Figure 9-30 Set and Execute UDP Trigger Mode

## Set and Execute Serial Port Trigger Mode

Serial start specifies the serial port as the source for the trigger signal. When the serial port receives the specified string text, the trigger signal will be output.


### Steps

1. Go to **I/O Control Settings** → **Input** → **Trigger Mode**.
  2. Select **On** as **Trigger Mode**.
  3. Select **Serial Start** as **Trigger Source**.
  4. Set **Serial Baudrate**, **Serial Data Bits**, **Serial Parity**, and **Serial Stop Bits**.
  5. Set following parameters according to actual demands.
- **Serial Trigger Text Format:** When receiving the specified trigger text, the server will output a trigger signal. You can select the text format from **Str** or **Hex**.
    - If **Str** is selected, enter the text in string format in the box next to **Serial Start Trigger Text**.
    - If **Hex** is selected, enter the text in hexadecimal format in the box below **Serial Trigger Start String**. If needed, you can click **+** to open the ASCII Cross Reference Table and click a table cell to add the corresponding content to the text box.
  - **Serial Start Trigger Text:** It sets the trigger text of Serial Start, and it is **Start** by default.

**Note**

You can also configure the string text for sending a serial handshake request and receiving a serial handshake response via **Trigger and IO Control** module on the feature tree.

---



| ▼ Input                    |              |
|----------------------------|--------------|
| Trigger Mode               | On           |
| Trigger Source             | Serial Start |
| Trigger Delay(us)          | 0.00         |
| Serial Baudrate            | 9600         |
| Serial Data Bits           | 8            |
| Serial Parity              | No Parity    |
| Serial Stop Bits           | 1            |
| Serial Trigger Text Format | Str          |
| Serial Start Trigger Text  | start        |

Figure 9-31 Set and Execute Serial Port Trigger Mode

## Set and Execute USB Trigger Mode

### Steps


1. Go to **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.
3. Select **USB Start** as **Trigger Source**.
4. Set **USB Baudrate**, **USB Data Bits**, **USB Parity**, **USB Stop Bits**, and **USB Start Trigger Text** according to actual demands.

## Set and Execute Self Trigger Mode

Self trigger allows you to trigger the device according to the trigger period you configured.

### Steps

1. Click **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.
3. Select **Self Trigger** as **Trigger Source**.
4. Set **Self Trigger Period** and **Self Trigger Count** according to the actual demands.



**Figure 9-32 Set and Execute Self Trigger Mode**

---

**Note**

- If the self-trigger count is set to 0, and it means that it can be triggered indefinitely until the execution of self-trigger stops.
  - The self-trigger time shall be set to be greater than the reciprocal of the actual frame rate.
- 

### Set and Execute Brightness Trigger

When the brightness of the field of view changes, the code reader is triggered to acquire images and output code information automatically. The code reader monitors the change of image brightness value in real time and starts code reading when the change exceeds the configured sensitivity threshold.

#### Steps

1. Click **I/O Control Settings** → **Input** → **Trigger Mode**.
2. Select **On** as **Trigger Mode**.
3. Select **Brightness** as **Trigger Source**.
4. Set **Brightness Sensitivity** according to the actual demands.

### 9.5.3 Stop Trigger

The device supports stopping trigger via TCP, UDP, I/O, serial port, and USB. You can also set code reading timeout duration or max. code amount to be read to stop trigger. After stopping trigger is completed, the device cannot make response to trigger again.

---

**Note**

- The device with USB interface supports stopping trigger via USB only, and the device with network interface supports all stop trigger methods apart from USB method.
  - For specific trigger stopping methods, refer to the actual device you got.
-

## Stop Trigger via TCP

When the TCP server receives the specified string text, the trigger will be stopped.


### Steps

1. Go to **I/O Control Settings** → **Stop Trigger**.
2. Enable **TCP Stop Trigger Enable**.
3. Set following parameters according to actual demands.
  - **TCP Trigger Port**: It is 2001 by default.

---

### Note

- The port No. configured here should differ from that in the TCP server port in the communication settings. Otherwise, parameter configuration will fail.
  - This function shares the same port No. with the TCP Trigger Mode, and the settings for both will take effect.
- 
- **TCP End Trigger Format**: You can select the text format from the drop-down list, including **Str** and **Hex**.
    - If **Str** is selected, enter the text in string format in the box next to **TCP Stop Trigger Text**.
    - If **Hex** is selected, enter the text in hexadecimal format in the box below **TCP Trigger End String**. If needed, you can click  to open the ASCII Cross Reference Table and click a table cell to add the corresponding content to the text box.
  - **TCP Stop Trigger Text**: It sets the stop trigger text, and it is **stop** by default.



|                         |                                     |
|-------------------------|-------------------------------------|
| TCP Stop Trigger Enable | <input checked="" type="checkbox"/> |
| TCP Trigger Port        | 2001                                |
| TCP End Trigger Format  | Str                                 |
| TCP Stop Trigger Text   | stop                                |

Figure 9-33 Stop Trigger via TCP

## Stop Trigger via UDP


When the UDP receives the specified string text, the trigger will be stopped.

### Steps

1. Go to **I/O Control Settings** → **Stop Trigger**.
2. Enable **UDP Stop Trigger Enable**.
3. Set following parameters according to actual demands.
  - **UDP Trigger Port**: It is 2002 by default.
  - **UDP End Trigger Format**: You can select the text format from the drop-down list, including **Str** and **Hex**.
    - If **Str** is selected, enter the text in string format in the box next to **UDP Stop Trigger Text**.
    - If **Hex** is selected, enter the text in hexadecimal format in the box below **UDP Trigger**

**End String.** If needed, you can click **+** to open the ASCII Cross Reference Table and click a table cell to add the corresponding content to the text box.

- **UDP Stop Trigger Text:** It sets the stop trigger text, and it is **stop** by default.



The screenshot shows a settings panel for UDP Stop Trigger. It contains four items: 'UDP Stop Trigger Enable' with a toggle switch set to 'On' (orange), 'UDP Trigger Port' with a dropdown menu showing '2002', 'UDP End Trigger Format' with a dropdown menu showing 'Str', and 'UDP Stop Trigger Text' with a text input field containing 'stop'.

**Figure 9-34 Stop Trigger via UDP**

## Stop Trigger via I/O

Stopping trigger via I/O allows you to select hardware or software trigger source to stop the device from acquiring images.

---


### Note

The output signal may differ by the device models.

---

### Steps


1. Go to **I/O Control Settings** → **Stop Trigger**.
2. Enable **IO Stop Trigger Enable**.
3. Select sources from **LineIn 0/1/2/3** and **SoftwareTriggerEnd** as **IO Stop Trigger Selector**.
4. (Optional) Set trigger polarity (rising edge and falling edge) if **LineIn 0/1/2/3** is selected as **IO Stop Trigger Selector**. If the trigger source of the input signal is the same as that of the trigger stopping via I/O, there is no need to select.



The screenshot shows a settings panel for IO Stop Trigger. It contains three items: 'IO Stop Trigger Enable' with a toggle switch set to 'On' (orange), 'IO Stop Trigger Selector' with a dropdown menu showing 'LineIn0', and 'Stop Trigger In Polarity' with a dropdown menu showing 'Rising Edge'.

**Figure 9-35 Stop Trigger via I/O**

5. (Optional) Click **Execute** in **Software Stop Trigger** to stop trigger if **Software Trigger End** is selected as **IO Stop Trigger Selector**.



The screenshot shows a settings panel for Software Stop Trigger. It contains three items: 'IO Stop Trigger Enable' with a toggle switch set to 'On' (orange), 'IO Stop Trigger Selector' with a dropdown menu showing 'SoftwareTriggerEnd', and 'Software Stop Trigger' with a button labeled 'Execute'.

**Figure 9-36 Software Trigger End**

## Stop Trigger via Serial Port

When the specified serial port receives the specified string text, the trigger will be stopped.

### Steps

1. Go to **I/O Control Settings** → **Stop Trigger**.
2. Enable **Serial Stop Trigger Enable**.
3. Set following parameters according to actual demands.
  - **Serial End Trigger Format**: When receiving the specified trigger text, the server will output a trigger signal. You can select the text format from **Str** or **Hex**.
    - If **Str** is selected, enter the text in string format in the box next to **Serial Stop Trigger Text**.
    - If **Hex** is selected, enter the text in hexadecimal format in the box below **Serial Trigger Stop String**. If needed, you can click  to open the ASCII Cross Reference Table and click a table cell to add the corresponding content to the text box.


---

### Note

**Hex** is supported only when the data bits of the serial port is 8.

---

- **Serial Stop Trigger Text**: It sets the trigger text of serial port stop, and it is **stop** by default.
- **Serial Baudrate**: It sets the baud rate of the serial port, and it is 9600 by default.
- **Serial Data Bits**: It sets the data bits of the serial port, and it is 8 by default.
- **Serial Parity**: It sets the parity of the serial port, and it is **No Parity** by default.
- **Serial Stop Bits**: It sets the stop bits of the serial port, and it is 1 by default.



|                            |                                     |
|----------------------------|-------------------------------------|
| Serial Stop Trigger Enable | <input checked="" type="checkbox"/> |
| Serial End Trigger Format  | Str                                 |
| Serial Stop Trigger Text   | stop                                |
| Serial Baudrate            | 9600                                |
| Serial Data Bits           | 8                                   |
| Serial Parity              | No Parity                           |
| Serial Stop Bits           | 1                                   |


Figure 9-37 Stop Trigger via Serial Port

## Stop Trigger via USB

The USB stop trigger function means that the device receives USB commands from the external device to stop image acquisition. At this time, the device acts as a USB server to receive commands, and the external device communicating with it acts as a USB client to send commands.

Go to **Feature Tree**, find **Stop Trigger Control**, enable **USB Stop Trigger Enable**, and set **USB Stop Trigger Text**, **USB Baudrate**, **USB Data Bits**, **USB Parity**, and **USB Stop Bits** according

to actual demands.



**Figure 9-38 Stop Trigger via USB**

---

### Note

The parameter settings in trigger stopping via USB are similar to those in trigger stopping via serial port. Refer to section [Stop Trigger via Serial Port](#) for details.

---

## Stop Trigger via Timeout Duration

---

### Note

**TimeOut Stop Trigger Enable** is only available when the device running mode is set to Normal and the Trigger Mode is On.

---


When the trigger time reaches the specified maximum value (ms), the trigger will be stopped. You can enable **TimeOut Stop Trigger Enable**, and set **Maximum Output Limited Time** according to actual demands.

---

### Note

The range of **Maximum Output Limited Time** is between 0 ms and 10000 ms.

---



**Figure 9-39 Stop Trigger via Timeout Duration**

## Stop Trigger via Code Number

---

### Note

**CodeNum Stop Trigger Enable** is only available when the device running mode is set to Normal and the Trigger Mode is On.

---

This function means that the code quantity output by the device is restricted to the settings you configured here.

You can enable **CodeNum Stop Trigger Enable**, and set **CodeNum Stop Trigger Min** and **CodeNum Stop Trigger Max** according to actual demands.

---

### Note

- If the number of outputted codes is less than the value configured for **CodeNum Stop Trigger Min**, the device will output codes continuously.
  - If the number of outputted codes is greater than the value configured for **CodeNum Stop Trigger Max**, the device will stop outputting codes.
  - If the number of outputted codes is between the values configured for **CodeNum Stop Trigger Min** and **CodeNum Stop Trigger Max**, the device will read and output codes according to trigger signals.
  - If **CodeNum Stop Trigger Min** is the same as the **CodeNum Stop Trigger Max**, the device will stop outputting codes when the number of outputted codes reaches the configured number.
- 




Figure 9-40 Stop Trigger via Code Number

## 9.5.4 Signal Output Settings

### Select Output Signal

The device's output signal can control external devices like PLC, flashing light, etc. Click **I/O Control Settings** → **Output** → **Line Out Selector** to select output signal.

---

### Note

The specific output signals may differ by device models.

---




Figure 9-41 Select Output Signal

## Set Event Source

---

### Note

The specific event sources may differ by device models and firmware versions.

The device supports outputting different trigger signals according to the event source you select. Click **I/O Control Settings** → **Output** → **Line Out Activation Event** to select event source.

The device supports following event sources, including **Off**, **NoCodeRead**, **ReadSuccess**, **CompareSuccess**, **CompareFail**, and **CommandControlIO**.

---

### Note

- **Off** refers to no event source.
- You need to set different parameters when selecting various event sources.
- **NoCodeRead**: If no code read by the device, the output signal will be triggered.
- **ReadSuccess**: If the code is read by the device, the output signal will be triggered.
- **CompareSuccess**: If data comparison is successful, the output signal will be triggered.
- **CompareFail**: If data comparison is failed, the output signal will be triggered.
- **CommandControlIO**: It is controlled by the communication strings.

### Select No Code Read

If you select **NoCodeRead** as **Line Out Activation Event**, and you can set its output delay time and duration.

- **Line Out Delay Time**: It sets the delay time for outputting the output signal.
- **Line Out Duration**: It sets the time duration of the output signal.

The screenshot shows a configuration window titled 'Output'. It contains five settings: 'Line Out Selector' is a dropdown menu set to 'LineOut 0'; 'Line Out Inverter' is a toggle switch currently turned off; 'Line Out Activation Event' is a dropdown menu set to 'NoCodeRead'; 'Line Out Delay Time(us)' is a numeric input field set to '0'; and 'Line Out Duration(us)' is a numeric input field set to '10000'.

**Figure 9-42 Select No Code Read**

### Select Read Success

If you select **ReadSuccess** as **Line Out Activation Event**, and you can set its output delay time and duration.

- **Line Out Delay Time:** It sets the delay time for outputting the output signal.
- **Line Out Duration:** It sets the time duration of the output signal.

The screenshot shows the same configuration window as Figure 9-42, but with the 'Line Out Activation Event' dropdown menu set to 'ReadSuccess'. All other settings remain the same: 'Line Out Selector' is 'LineOut 0', 'Line Out Inverter' is off, 'Line Out Delay Time(us)' is '0', and 'Line Out Duration(us)' is '10000'.

**Figure 9-43 Select Read Success**

### Select Compare Success

If you select **Compare Success** as **Line Out Activation Event**, and you can set its output delay time and duration.

- **Line Out Delay Time:** It sets the delay time for outputting the output signal.
- **Line Out Duration:** It sets the time duration of the output signal.

The screenshot shows the same configuration window, but with the 'Line Out Activation Event' dropdown menu set to 'CompareSucces'. All other settings remain the same: 'Line Out Selector' is 'LineOut 0', 'Line Out Inverter' is off, 'Line Out Delay Time(us)' is '0', and 'Line Out Duration(us)' is '1000'.

**Figure 9-44 Select Compare Success**

### Select Compare Fail

If you select **Compare Fail** as **Line Out Activation Event**, and you can set its output delay time and duration.

- **Line Out Delay Time:** It sets the delay time for outputting the output signal.
- **Line Out Duration:** It sets the time duration of the output signal.

The screenshot shows a configuration window titled 'Output' with a dropdown arrow. It contains five settings: 'Line Out Selector' is set to 'LineOut 0'; 'Line Out Inverter' is a toggle switch currently turned off; 'Line Out Activation Event' is set to 'CompareFail'; 'Line Out Delay Time(us)' is set to '0'; and 'Line Out Duration(us)' is set to '1000'.

Figure 9-45 Select Compare Fail

### Select Command Control IO

If you select **CommandControlIO** as **Line Out Activation Event**, and you do not need to set any parameters.

- **Control Start Str:** It sets the start string of command control.
- **Control Stop Str:** It sets the stop string of command control.
- **Line Out Delay Time:** It sets the delay time for outputting the output signal.
- **Line Out Duration:** It sets the time duration of the output signal.

The screenshot shows a configuration window titled 'Output' with a dropdown arrow. It contains seven settings: 'Line Out Selector' is set to 'LineOut 3'; 'Line Out Inverter' is a toggle switch currently turned off; 'Line Out Activation Event' is set to 'CommandControlIO'; 'Control Start Str' is an empty text field; 'Control Stop Str' is an empty text field; 'Line Out Delay Time(us)' is set to '0'; and 'Line Out Duration(us)' is set to '1000'.

Figure 9-46 Select Command Control IO

### Enable Line Inverter

The line inverter function allows the device to invert the electrical signal level of an I/O line,

and meets requirements of different devices for high or low electrical signal level. You can go to **I/O Control Settings** → **Output** → **Line Out Inverter** to enable it.

**Note**

The **Line Out Inverter** function is disabled by default.




Figure 9-47 Enable Line Out Inverter

## 9.5.5 Set Buzzer

**Note**

- Only ID2000EM series devices support buzzer function.
- Make sure that the device is in the **Normal** mode before using the buzzer function.

The buzzer is used to indicate the device's operation status, and you can set the buzzer function according to actual demands.

**Steps**

1. Right click the device in **Device Connection**, and click **Feature Tree**.
2. Go to **Trigger and IO Control** → **Buzzer Enable**, and enable **Buzzer Enable**.

**Note**

After **Buzzer Enable** is enabled, the buzzer beeps three times when the device is powered on, beeps twice when the device reads configuration codes successfully, and beeps once when the device reads codes successfully.

3. Set **Buzzer Duration (ms)** and **Buzzer Frequency (hz)** according to actual demands.




Figure 9-48 Set Buzzer

## 9.6 Communication Settings

The communication protocol is used to transmit and output code reading result and image. The communication protocol is related to the device modes. With various device modes, the device supports different communication protocols and corresponding parameters.

- If the device's running mode is **Test** or **Raw**, the device only supports **SmartSDK** protocol and no parameter settings are required.
- If the device's running mode is **Normal**, the device supports **SmartSDK**, **TCP Client**, **Serial**, **FTP**, **TCP Server**, **Profinet**, **MELSEC/SLMP**, **Ethernet/IP**, **ModBus**, **UDP**, **Fins** and **USB** communication protocols, and you need to set corresponding parameters.

---

### Note

- The supported communication protocols may differ by device models.
  - The device with USB interface supports **SmartSDK** and **USB** only, and device with network interface supports all communication protocols apart from **USB**.
  - The specific parameters of communication protocols may differ by device models.
  - If you need communication command for reference, you can open the Communication Commands document by clicking **Help** → **Communication Matrix** on the top menu bar.
- 

### 9.6.1 Set SmartSDK

If you select **SmartSDK** as the communication protocol, you can configure the following parameters:

**Table 9-5 SmartSDK Communication Protocol**

| Parameter                | Description                                                         |
|--------------------------|---------------------------------------------------------------------|
| <b>SmartSDK Protocol</b> | If enabled, the device will output data via SmartSDK.               |
| <b>Encode JPEG Flag</b>  | The device will compress images in JPG format after enabling it.    |
| <b>Quantity of JPG</b>   | It sets the image compression quality, and it ranges from 50 to 99. |

### 9.6.2 Set TCP Client

If you select **TCP Client** as the communication protocol, you can configure the following parameters:

**Table 9-6 TCP Client Communication Protocol**

| Parameter                   | Description                                                                                                                                                                                                                                                                 |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Output Result Buffer</b> | If enabled, when the TCP server is abnormal, the device will cache the images. When the server returns to normal, the device will send the cached images to the server. You can configure <b>Output Result Buffer Number</b> to determine the number of the images that the |

| Parameter           | Description                                                                      |
|---------------------|----------------------------------------------------------------------------------|
|                     | device will cache.                                                               |
| <b>TCP Protocol</b> | If enabled, the device will output data via the TCP server.                      |
| <b>TCP Dst Addr</b> | Enter the IP address of the server that receives data output by the code reader. |
| <b>TCP Dst Port</b> | Enter the port No. of the server that receives data output by the code reader.   |

### 9.6.3 Set Serial

If you select **Serial** as the communication protocol, you can configure the following parameters:

**Table 9-7 Serial Communication Protocol**

| Parameter               | Description                                                                                                                                                                                                                                   |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Serial Protocol</b>  | If enabled, the code reader will output data via serial port.                                                                                                                                                                                 |
| <b>Serial Baudrate</b>  | The baud rate of the serial port of the PC that receives data.                                                                                                                                                                                |
| <b>Serial Data Bits</b> | Data bits of the serial port of the PC that receives data.<br> <b>Note</b><br>The hexadecimal trigger is supported only when <b>Serial Data Bits</b> is 8. |
| <b>Serial Parity</b>    | Parity bits of the serial port of the PC that receives data.                                                                                                                                                                                  |
| <b>Serial Stop Bits</b> | Stop bits of the serial port of the PC that receives data.                                                                                                                                                                                    |

### 9.6.4 Set FTP

If you select **FTP** as the communication protocol, you can configure the following parameters:

**Table 9-8 FTP Communication Protocol**

| Parameter                   | Description                                                                                                                                                                                                                                                                                        |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Output Result Buffer</b> | If enabled, when the FTP server is abnormal, the device will cache the images. When the FTP server returns to normal, the device will send the cached images to the server. You can configure <b>Output Result Buffer Number</b> to determine the number of the images that the device will cache. |
| <b>FTP Protocol</b>         | If enabled, the code reader will output data via FTP server.                                                                                                                                                                                                                                       |
| <b>FTP Host Addr</b>        | IP address of the FTP host.                                                                                                                                                                                                                                                                        |

| Parameter     | Description               |
|---------------|---------------------------|
| FTP Host Port | Port No. of the FTP host. |
| FTP User Name | User name of the FTP.     |
| FTP User PWD  | Password of the FTP.      |

### 9.6.5 Set TCP Server

If you select **TCP Server** as the communication protocol, you can configure the following parameters:

**Table 9-9 TCP Server Communication Protocol**

| Parameter                          | Description                                                                                                                                                                                                                               |
|------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TCP Server Enable                  | If enabled, the code reader will output data via TCP server.                                                                                                                                                                              |
| TCP Server Port                    | The port No. of the TCP server that receives data outputted by code reader.                                                                                                                                                               |
| Tcp Server Flexible Connect Enable | Upon client disconnection, the server automatically disconnects from the client and releases resources for subsequent devices. As long as there are available resources, subsequent devices can connect to the server without limitation. |

---

#### Note

The port No. configured here should differ from that in the TCP trigger of trigger source or in the trigger stopping via TCP. Otherwise, parameter configuration will fail.

---

### 9.6.6 Set Profinet

If you select **Profinet** as the communication protocol, you can configure the following parameters:

**Table 9-10 Profinet Communication Protocol**

| Parameter            | Description                                                                                                      |
|----------------------|------------------------------------------------------------------------------------------------------------------|
| Profinet Enable      | If enabled, the device will output data via Profinet protocol.                                                   |
| Profinet Device Name | Enter the name of the code reader, which is used for code reader recognition in Profinet protocol communication. |

### 9.6.7 Set MELSEC/SLMP

If you select **Melsec/SLMP** as the communication protocol, you can configure the following parameters:

**Table 9-11 MELSEC/SLMP Communication Protocol**

| Parameter                            | Description                                                                                                                                                                                               |
|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>MELSEC Protocol Enable</b>        | If enabled, the code reader will output data via MELSEC protocol.                                                                                                                                         |
| <b>MELSEC Destination IP Address</b> | IP address of the Programmable Logic Controller (PLC) connected to the code reader.                                                                                                                       |
| <b>MELSEC Destination Port</b>       | Port No. of the MELSEC protocol channel on the PLC.                                                                                                                                                       |
| <b>MELSEC Data Base Address</b>      | The address of the data base of the PLC for receiving the data outputted by the code reader. The default value is 0.                                                                                      |
| <b>MELSEC State Base Address</b>     | The address of the state base of the PLC, which is used for sending trigger signal to the code reader and receiving trigger result and code reading results from the code reader. The default value is 0. |
| <b>MELSEC Network Number</b>         | MELSEC protocol network No. to communicate with.                                                                                                                                                          |
| <b>MELSEC PLC Number</b>             | No. of the PLC to be connected to the code reader.                                                                                                                                                        |
| <b>MELSEC Module I/O Number</b>      | No. of the target module.                                                                                                                                                                                 |
| <b>MELSEC Module Station Number</b>  | No. of the target module station.                                                                                                                                                                         |
| <b>MELSEC Timeout</b>                | Maximum waiting time for PLC response.                                                                                                                                                                    |

### 9.6.8 Set Ethernet/IP

If you select **EthernetIp** as the communication protocol, you can configure the following parameters:

**Table 9-12 Ethernet/IP Communication Protocol**

| Parameter                 | Description                                                            |
|---------------------------|------------------------------------------------------------------------|
| <b>Ethernet/IP Enable</b> | If enabled, the code reader will output data via Ethernet/IP protocol. |

### 9.6.9 Set ModBus

If you select **Modbus** as the communication protocol, you can configure the following parameters:

**Table 9-13 ModBus Communication Protocol**

| Parameter            | Description                                             |
|----------------------|---------------------------------------------------------|
| <b>ModBus Enable</b> | If enabled, the code reader will output data via ModBus |

| Parameter                         | Description                                                     |
|-----------------------------------|-----------------------------------------------------------------|
|                                   | protocol.                                                       |
| <b>ModBus Mode</b>                | Select a mode from <b>Server</b> and <b>Client</b> .            |
| <b>ModBus Control Space</b>       | The value is "holding_register" by default and not editable.    |
| <b>ModBus Control Offset</b>      | Offset of the control address. The default value is 0.          |
| <b>ModBus Control Size (Word)</b> | The value is 1 by default.                                      |
| <b>ModBus Status Space</b>        | It sets status space and it is "holding_register" by default.   |
| <b>ModBus Status Offset</b>       | It sets status offset and it is 1 by default.                   |
| <b>ModBus Status Size (Word)</b>  | It is 1 by default.                                             |
| <b>ModBus Result Space</b>        | It set result space and it is "holding_register" by default.    |
| <b>ModBus Result Offset</b>       | It is 2 by default.                                             |
| <b>ModBus Result Size (Word)</b>  | It is 100 by default.                                           |
| <b>ModBus Result Byte Swap</b>    | If it is enabled, the client software will swap ModBus results. |
| <b>ModBus Result Timeout (s)</b>  | It sets the result timeout of the ModBus protocol.              |

### 9.6.10 Set UDP

If you select **UDP** as the communication protocol, you can configure the following parameters:

**Table 9-14 UDP Communication Protocol**

| Parameter                  | Description                                                                    |
|----------------------------|--------------------------------------------------------------------------------|
| <b>UDP Protocol Enable</b> | If enabled, the code reader will output data via User Datagram Protocol (UDP). |
| <b>UDP Dst IP</b>          | The IP address of the PC receiving the output data.                            |
| <b>UDP Dst Port</b>        | The port of the PC receiving the output data.                                  |

### 9.6.11 Set Fins

If you select **Fins** as the communication protocol, you can configure the following

parameters:

**Table 9-15 Fins Communication Protocol**

| Parameter                              | Description                                                   |
|----------------------------------------|---------------------------------------------------------------|
| <b>Fins Enable</b>                     | If enabled, the code reader will output data via TCP/UDP FIN. |
| <b>Fins Communication Mode</b>         | Select UDP or TCP as the communication mode.                  |
| <b>Fins Server IP</b>                  | It sets the server IP of Fins.                                |
| <b>Fins Server Port</b>                | The local port of Fins. Default is 9600.                      |
| <b>Fins Control Poll Interval (ms)</b> | It sets how often read data.                                  |
| <b>Fins Data Format</b>                | Select 16 bit or 32 bit as the data format.                   |
| <b>Fins Control Space</b>              | It sets storage space of the control area.                    |
| <b>Fins Control Offset</b>             | It sets the start offset address of the control area.         |
| <b>Fins Control Size (Word)</b>        | It sets the size of the control area.                         |
| <b>Fins Status Space</b>               | It sets storage space of the status area.                     |
| <b>Fins Status Offset</b>              | It sets the start offset address of the status area.          |
| <b>Fins Status Size (Word)</b>         | It sets the size of the status area.                          |
| <b>Fins Result Space</b>               | It sets storage space of the result area.                     |
| <b>Fins Result Offset</b>              | It sets the start offset address of the result area.          |
| <b>Fins Result Size (Word)</b>         | It sets the size of the result area.                          |
| <b>Fins Result Byte Swap</b>           | If it is enabled, the client software will swap Fins results. |
| <b>Fins Result Timeout (s)</b>         | It sets the Fins result timeout, and the unit is s.           |

### 9.6.12 Set USB

If you select **USB** as the communication protocol, you can configure the following parameters:

**Table 9-16 USB Communication Protocol**

| Parameter         | Description                                           |
|-------------------|-------------------------------------------------------|
| <b>USB Enable</b> | If enabled, the code reader will output data via USB. |
| <b>USB Output</b> | It sets the USB output mode, including CDC and HID.   |

| Parameter     | Description                        |
|---------------|------------------------------------|
| USB Baudrate  | It is 9600 by default.             |
| USB Data Bits | It is 8 by default.                |
| USB Parity    | It is <b>No Parity</b> by default. |
| USB Stop Bits | It is 1 by default.                |

## 9.7 Data Processing Settings

In **Data Processing**, you can set filter rules for reading codes and other data processing related parameters.

---

### Note

The specific parameters may differ by device models and firmware versions.

---

### 9.7.1 Set Filter Rule

You can set rules via **Filter Rule** to filter unwanted codes to improve the reading efficiency.

#### Normal Filter Mode

If the device's running mode is normal, trigger mode is on, filter mode is normal, you can set following parameters according to actual demands:

- **Instant Output Mode Enable:** If it is enabled, the device will output barcode data immediately once a code is read. If not enabled, the barcode data will be outputted after the device trigger process ends.
- **Min. Output Time(ms):** Define the minimum time duration (unit: ms) for data output. The duration starts from trigger time. Note: The parameter is only available when the running mode is set to Normal mode and the trigger mode is enabled.
- **Min. Code Length:** If the length of a barcode is shorter (in terms of the number of characters) than the configured value, the device will NOT parse the barcode. For example, if you set the value to 6, the device will not parse the barcodes which contain fewer than 6 characters.

---

### Note

The valid value of the parameter is from 1 to 256.

---

- **Max. Code Length:** If the length of a barcode is longer (in terms of the number of characters) than the configured value, the device will NOT parse the barcode. For example, if you set the value to 9, the device will not parse the barcodes which contain more than 9 characters.

---

### **Note**

The valid value of the parameter is from 1 to 256.

---

- **Numeral Filter:** If it is enabled, the device will only parse and read the numeral contents of the barcodes, and the non-numeral contents will be filtered out.
- **CodeLen Max Num:** It refers to the max. length of the code for output.
- **Code Offset Num:** Define the offset for the start character of the barcode data. For example, if you set the value to 3, the code reader will output data starting from the third character of the barcode data. The first and second characters will NOT be outputted.
- **Begin with Specific Character for Result:** If it is enabled, the device will only read the barcodes which begin with a specific character string.
- **Begins with:** Enter the character string.
- **UPCA Fill Zero:** If it is enabled, when the content of the UPCA code is less than 13 digits, zero will be added at the beginning of the code. It is available only when the running mode is Normal, and the UPCA code is enabled.
- **Include Specific Character in Barcode:** If it is enabled, the device will only read the barcodes which include a specific character string.
- **Character:** Enter the character string.
- **Exclude Specific Character in Barcode:** If it is enabled, the device will only read the barcodes without a specific character string.
- **Character:** Enter the character string.
- **Regular Expression Filter Enable:** If it is enabled, the device will only read the barcodes which contain the configured character string(s).
- **NoRead TimeOut:** If no codes are not recognized after the time you set here, the client software will output NoRead instead.
- **Read Times Threshold:** If the reading results of a barcode is same for the configured times, the barcode will be regarded as valid and its data will be outputted. Or the barcode will be regarded as invalid and its data will not be outputted.
- **De-duplication Enable:** If it is enabled, the repeated code information will be filtered within specific trigger times. You can set trigger times in **De-duplication Windows Size**, and its default value is 1.
- **De-duplication By ROI:** If it is enabled, the device will filter information based on drawn ROIs.
- **Cut Mode:** **Simple Cut** or **Range Cut** can be selected.
  - **Simple Cut:** Set start/end offset of the code via **Code Start Offset Num** and **Code End Offset Num**. It will cut the specific length of code contents from starting/ending, and the remaining part will be outputted.
  - **Range Cut:** Cut the code via the character expressions. For example, the code content is 123456789, and the output will be performed based on the following expressions:  
Character expression (5) will output 5;  
Character expression (1-4) will output 1234;  
Character expression (1-4,6-9) will output 12346789;  
Character expression (1-4,8-) will output 123489;

Character expression (1-) will output 123456789.

---

### Note


- The parameters, such as **Instant Output Mode Enable**, **Min. Output Time**, **CodeLen Max Num**, **Code Offset Num**, **De-duplication Enable**, **De-duplication Windows Size**, **De-duplication By ROI**, and **Cute Mode**, are only available when the running mode is set to Normal mode and the trigger mode is enabled.
  - When **De-duplication Enable** is disabled, no filtering will be performed.
- 

## Regular Expression Filter Mode

The device supports filtering codes via the regular expression.


### Steps

1. Select **Regular Expression** as the **Filter Mode**, and click **Set** in **Regular Expression Filter** to enter regular expression filter settings window.
2. Import local files or add customized filter rules to set the regular expression.
  - Import local files: Click **Import** to import local .xml files, and click **OK** to finish.



**Figure 9-49 Regular Expression Filter Settings**

- Add customized filter rule: Click **Add** and set related parameters in the popped-up window, and click **OK** after configuring parameters.



**Figure 9-50 Customized Regular Expression Filter Rules**

**Table 9-17 Filter Rule Parameters**

| Parameter      | Description                                                                                                                                                                                                                                                                                                     |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Rule Name      | The default rule name is Rule 1, and you can edit it according to actual demands.                                                                                                                                                                                                                               |
| Length Limit   | It sets the length range of the code, and its upper limit is 256.                                                                                                                                                                                                                                               |
| Start With     | <p>It sets the specific start with code. You can use semicolon to separate if there are multiple characters.</p> <p> <b>Note</b><br/>If multiple characters are used, code meeting one of these characters is valid.</p>     |
| End With       | <p>It sets the specific end with code. You can use semicolon to separate if there are multiple characters.</p> <p> <b>Note</b><br/>If multiple characters are used, code meeting one of these characters is valid.</p>       |
| Not Start With | <p>It excludes the specific start with code. You can use semicolon to separate if there are multiple characters.</p> <p> <b>Note</b><br/>If multiple characters are used, code meeting one of these characters is valid.</p> |
| Not End With   | It excludes the specific end with code. You can use semicolon to separate if there are multiple characters.                                                                                                                                                                                                     |

| Parameter        | Description                                                                                                                                                                                                                                                                                                    |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                  | <p> <b>Note</b></p> <p>If multiple characters are used, code meeting one of these characters is valid.</p>                                                                                                                    |
| Included         | <p>It sets the code with specific content. You can use semicolon to separate if there are multiple characters.</p> <p> <b>Note</b></p> <p>If multiple characters are used, code meeting all these characters is valid.</p>    |
| Excluded         | <p>It sets the code without specific content. You can use semicolon to separate if there are multiple characters.</p> <p> <b>Note</b></p> <p>If multiple characters are used, code meeting all these characters is valid.</p> |
| Other Conditions | You can select uppercase, lowercase, digit or Chinese.                                                                                                                                                                                                                                                         |

3. After setting filter rule, enter the code in **Code Check** to check if the filter rule is successful.




Figure 9-51 Code Check

 **Note**

If the filter rule you configured is correct, the result is valid. Otherwise, it is invalid.

4. (Optional) Click  to delete unwanted filter rules.
  5. (Optional) Click **Export** to export configured filter rules to local PC.
- 

 **Note**

The filter rule parameters of the regular expression may differ by device models and firmware versions.

---

## 9.7.2 Data Processing Settings

You can configure the contents contained in the output barcode information.

---

 **Note**

- The actual parameters displayed may vary with different communication protocols. For details about communication settings, refer to section **Communication Settings**.
  - The device with USB interface supports **SmartSDK** and **USB** only, and device with network interface supports all communication protocols apart from **USB**.
  - The specific parameters and parameter order may differ by the device's running mode, trigger mode, device models and firmware versions.
- 

### SmartSDK

- **NoRead Image Index**: It sets the specific image that is outputted when no code information is read. For example, if you set this parameter as 5, and the 5th image will be output.
  - **Mirror Text Enable**: You can customize mirror characters in the data processing. The mirror characters can be defined through the mirror text parameters, while non-mirror characters defined through the non-mirror text parameters.
  - **L-Side Angle Enable**: You can set the acceptable angle range and output text of the L-side angle of the DM code through the following parameters.
- 

 **Note**

This parameter can be used only when the running mode is Normal and DM code is enabled.

- **1/2/3/4 Area Start**: It refers to the angle start position of the 1/2/3/4 area.
  - **1/2/3/4 Area End**: It refers to the angle end position of the 1/2/3/4 area.
  - **1/2/3/4 Area Text**: It refers to the output text in the 1/2/3/4 area.
  - **Text out of Area**: It refers to the output text out of the 1/2/3/4 area.
- 

### FTP

When the communication protocol is FTP, set the following parameters of data processing:

- **NoRead Image Index**: It sets the specific image that is outputted when no code information is read. For example, if you set this parameter as 5, and the 5th image will

be output.

- **Output Retrans Enable:** Enable to allow data re-transmission. Specify the limit of re-transmission attempts in **Output Retrans Number**.
  - **FTP Transmission Conditions:** Set the condition to upload the data outputted by the device to FTP server.
    - **All:** Always upload the data.
    - **ReadBarcode:** Upload the data only when the barcode is read by the device.
    - **NoReadBarcode:** Upload the data only when no barcode is read by the device.
  - **FTP Transmission Result Contain:** Select contents to upload to the FTP server.
    - **JustResult:** Only upload the content of the barcode.
    - **JustPicture:** Only upload the barcode image.
    - **ResultAndPicture:** Upload both the content of the barcode and the barcode image.
  - **FTP Picture Name Format:** Click  to select one or multiple items to be contained in the picture name. The selected items will be displayed in the frame. You can also enter more contents directly in the frame.
  - **FTP Time Format:** Select a format type from the drop-down list for the time stamp contained in the file name.
- 

### Note

Take YYYYMMDD\_HHMMSSFFF as an example, (from the left to the right) YYYY represents year, MM month, DD date, HH hour, MM minute, SS second, FFF millisecond.

---

## Other Communication Protocols

When the communication protocol is TCP Client, Serial, TCP Server, Profinet, MELSEC/SLMP, EthernetIp, ModBus, UDP, FINS, or USB, set the following parameters of data processing.

---

### Note

Here we use "\*\*\*" to represent the specific protocol name.

---

- **ROI Output Noread Enable:** Enable this to set the default output content if no code is read during transmission. Edit the output text in **Output NoRead Text**.
  - **NoRead Image Index:** It sets the specific image that is outputted when no code information is read. For example, if you set this parameter as 5, and the 5th image will be output.
  - **One By One Enable:** If it is enabled, the device will send one piece of code information each time in accordance with the specified interval. You can set the interval via **One By One Interval** and the default value 100 ms.
- 

### Note

This parameter cannot be used when the communication protocols are SmartSDK and FTP.

---

- **\*\*\* Output Format:** Click **Edit** to select one or multiple items to be contained in the picture name and click **Save**. The selected items will be displayed in the frame below. You can

also enter more contents directly in the frame.

**Table 9-18 Output Format Identifier**

| No. | Data                    | Identifier        | No. | Data                    | Identifier         |
|-----|-------------------------|-------------------|-----|-------------------------|--------------------|
| 1   | Code Content            | <code_content>    | 9   | Mirror                  | <code_mirror>      |
| 2   | Code Type               | <code_type>       | 10  | Code Quality Evaluation | <code_quality>     |
| 3   | Angle                   | <code_angle>      | 11  | Trigger No.             | <trigger_num>      |
| 4   | Code Vertex coordinates | <code_vertex_pos> | 12  | Frame No.               | <frame_num>        |
| 5   | Code Center coordinates | <code_cen_pos>    | 13  | Polling Parameter ID    | <polling_group_id> |
| 6   | L-Side Angle of DM Code | <DMcode_L_angle>  | 14  | ROI ID                  | <code_roi_id>      |
| 7   | Trigger Start Time      | <trig_start_time> | 15  | Newline                 | <line_feed>        |
| 8   | Code Score              | <code_eval_score> | 16  | Carriage Return         | <carriage_return>  |

- **\*\*\* Format Check:** Click **Execute** in **\*\*\* Format Check** to check if you entered is right in format, and the check result will be displayed in **\*\*\* Format Check Result**.
- **\*\*\* Output Noread:** Enable this to set the default output content if no code is read during transmission. Edit the output text in **Output NoRead Text**.
- **\*\*\* Output Start Text:** The contents of the start part of the data output. You can set the contents as desired.
- **\*\*\* Output Stop Text:** The contents of the end part of the data output. You can set the contents as desired.
- **\*\*\* Output Barcode Enter Character Enable:** Whether to show input character in the data.
- **\*\*\* Output Barcode Newline Character Enable:** Whether to show new-line character in the data.
- **\*\*\*Add NoRead Enable:** When the code content read does not meet the specified min. code length, this parameter will add the content to the required length for output.
  - **Off:** Output the code content.
  - **Add Noread:** Add the content to the required length for output.
  - **Just Noread:** Output Noread without adding.
- **Code Pos Width Enable:** When the code coordinates do not meet the specified length, this parameter will add 0 to the required length for output. The length of the code coordinates can be set in **Code Pos Width**.
- **Mirror Text Enable:** You can customize mirror characters in the data processing. The mirror characters can be defined through the mirror text parameters, while non-mirror characters defined through the non-mirror text parameters.
- **L-Side Angle Enable:** You can set the acceptable angle range and output text of the L-side angle of the DM code through the following parameters.

### Note

This parameter can be used only when the running mode is Normal and DM code is enabled.

- 1/2/3/4 Area Start: It refers to the angle start position of the 1/2/3/4 area.
- 1/2/3/4 Area End: It refers to the angle end position of the 1/2/3/4 area.
- 1/2/3/4 Area Text: It refers to the output text in the 1/2/3/4 area.
- Text out of Area: It refers to the output text out of the 1/2/3/4 area.

## 9.8 Characters Replace

### Note

This section is available for IDMVS V5.0 and later.

The **Characters Replace** function allows you to standardize code output by replacing specified characters or performing case conversion on the decoded content.

### Steps

1. On the Navigation Bar of the IDMVS main window, go to **Operator Settings** → **Data Processing** → **Characters Replace**.




Figure 9-52 Characters Replace

2. On the **Characters Replace** page, you can set rules to replace specific characters in the decoded code content.

- 1) Enable **Replace Mode**.
- 2) Click **Add** under **Character Set**.
- 3) In the **Original Text** and **Replace With** columns of the rule list, enter the character(s) to be replaced and the replaced character(s), respectively.

You can click  next to the input field and select characters from the **ASCII Table**.

- 4) Repeat the above steps to add multiple character replacement rules.

To delete a rule, select the box next to the rule and click **Delete** to remove it.

3. In the **Switch Mode** section, select a switch mode.

- **Normal Output**: No case conversion is applied.
- **To Upper**: Converts all lowercase letters to uppercase.

- **To Lower:** Converts all uppercase letters to lowercase.
- **Reverse:** Converts lowercase letters to uppercase and uppercase letters to lowercase.

4. Click **Save** to apply the settings.

### Result

If the configured rules and parameters of **Switch Mode** are like the example below, when the original code content is "A12345678A", the final output could be "1bb1".




Figure 9-53 Example of Characters Replace

## 9.9 Multi-Reader Synchronization

### Note

This section is available for IDMVS V5.0 and later.

When multiple code readers are simultaneously capturing images for code reading, they can work together through the multicast or main-sub operation mode. This achieves synchronized triggering and efficient data transmission across multiple code readers. Additionally, the multi-frame can be set in IDMVS main interface to preview images from multiple code readers.

Synchronization between code readers set by multicast mode and main-sub operation mode serves different application scenarios. You can select the appropriate mode based on requirements.

Table 9-19 Comparison of Networking Modes

| Networking Mode | Primary Purpose             | Working Principle                                                                                                                                                                                                         | Application Scenario                                                                                                                                                          |
|-----------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Multicast       | Synchronize trigger numbers | Main and sub code readers are triggered simultaneously. The main sends the trigger number to all sub devices. All code readers transmit their reading results to the decoding platform, which merges the results based on | It is applicable for multi-side scanning in logistics scenarios. The decoding platform integrates output from all main and sub code readers to achieve coordination of multi- |

| Networking Mode    | Primary Purpose                                           | Working Principle                                                                                                                                                                                               | Application Scenario                                                                                                                        |
|--------------------|-----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|                    |                                                           | the trigger number and outputs a unified result.                                                                                                                                                                | reader.                                                                                                                                     |
| Main-Sub Operation | Data integration or transmission of multiple code readers | Main and sub code readers are triggered simultaneously. Sub code readers send reading results to the main and the main integrates and transmits the reading results to the corresponding host or client system. | It is applicable for scenarios with limited communication ports, multi-station setups, or large-area scanning requiring coordinated output. |

### 9.9.1 Main-Sub Configuration

Main-sub network configuration consists of one main code reader and multiple sub code readers, allowing cooperation of multiple code readers. This section takes two code readers as an example to guide you through the configuration process.

In main-sub operation mode, one code reader is set as the main, while others are set as sub code readers. Sub code readers send their decoded results to the main, and the main merges or forwards the data and sends to the connected host system (PC or PLC). This enables coordination among multiple code readers. The diagrams of independent mode and cooperation mode are as follows.




Figure 9-54 Diagram of Working Mode


Table 9-20 Mode Overview

| Mode        | Description                                                               | Use Case                                                | Benefits                                      |
|-------------|---------------------------------------------------------------------------|---------------------------------------------------------|-----------------------------------------------|
| Independent | The main only forwards its own and sub devices' data to the host. No data | Each code reader scans code on different positions, and | Reduces the number of host-side communication |

| Mode        | Description                                                                 | Use Case                                                                                           | Benefits                                                                     |
|-------------|-----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------|
|             | merging is performed.                                                       | data are received by one host (PC or PLC).                                                         | ports. Only one port can forward all data to the host.                       |
| Cooperation | The main merges its own and data of sub devices before sending to the host. | It is applicable for large object or object with multiple sides which require multi-angle reading. | Merges duplicate codes, and simplifies host-side integration and processing. |

### Steps

1. Connect two or more code readers as needed.
2. Go to **Operator Settings** → **Net Config** → **Main Sub Configuration** in the Navigation Bar of the IDMSV main window.



**Figure 9-55 Main Sub Configuration**

3. Under the **Main Sub Configuration** tab, set the parameters for the main code reader.

### Common Parameters

#### Main-Sub Operation Mode

You can select whether to enable or configure the mode of the current connected code readers. The available modes are as follows.

---

### **Note**

Hover over  behind the mode selection box to view a data flow diagram for each mode.

---

- **Off:** Main-sub configuration feature is disabled.
  - **Independent:** Sub code readers send decoded data to the main, and the main sends its own data and forwards data of sub devices without merging. The data processing of the codes is completed at each device. This is suitable for scenarios involving multiple production lines. By using the main code reader for data forwarding, the occupation of communication ports can be reduced.
  - **Cooperation:** The sub code reader sends decoding results to the main for data processing. The main merges the data from both sub and its own stations based on its processing logic, and then outputs a consolidated package. This mode is suitable for scenarios requiring multi-side code integration due to limited coverage.
- 

### **Note**

The code symbologies used by the sub devices should be enabled in the main code reader; otherwise, decoded data may be filtered and lost.

---

## **Station Role**

Set the role of the current connected code reader as **Main**.

## **Waiting Time (ms)**

Set the max. waiting time for the main to receive sub data after triggering.

---

### **Note**

- This parameter can be set only when you select **Cooperation** in **Main-Sub Operation Mode**.
  - The value of the **Waiting Time** parameter should be greater than the total output processing time of the slowest sub code readers among all.
- 

## **Sync Main Station Trigger Signals**

Set if the main should send its trigger signal to the sub devices. When it is enabled, the trigger source of the sub code readers can be selected as **Cooperation**.

---

### **Note**

This parameter can be set only when you select **Cooperation** in **Main-Sub Operation Mode**.

---

## **Main-Sub Group ID**

Set the main-sub network group ID of the connected code readers. Devices with the same group ID are in the same main-sub network, and code readers in different

main-sub network groups cannot access each other.

### Advanced Parameters

#### Station Port

It refers to the port No. used for data transmission on the main station.

#### Sync Main Station ROI

Select whether to synchronize the ROI sequence numbers with the sub code readers. Once it is enabled, the ROI sequence numbers of the sub code readers can inherit the sequence numbers from the main and continue numbering.

---

#### Note

This parameter can be set only when you select **Main** in **Station Role**.

---

#### Display Sub Station Reading Data

Select whether to display the reading data of the sub station on the main station. Once it is enabled, if the sub code readers reads a code, the code information can be displayed on the main code reader.

#### Query Sub Station ID

Enter the sub station ID and you can check the following information.

- **Sub Station IP:** It refers to the IP address of the sub code reader.
- **Sub Station Connection Status:** A value of 1 means that the data transmission is normal, otherwise it means that there is no connection.
- **Sub Station Name:** It refers to the user name of the sub code reader.
- **Sub Station Model:** It refers to the model name of the sub code reader.
- **Sub Station Serial Number:** It refers to the serial number of the sub code reader.

---

#### Note


When configuring the sub code reader, the main code reader information will also be displayed through parameters similar to the above.

---

4. Drag the connected code reader from the device list into the dashed box of **Sub Cameras** to quickly complete the main-sub configuration.
- 

#### Note

- If you need to add multiple sub code readers, repeat this drag-and-drop method for each code reader.
  - If a sub code reader does not show in the **Sub Cameras** area after being added, you can switch to that device and make sure its **Main-Sub Operation Mode** parameter is consistent with that of the main code reader.
  - It is recommended to use code readers of the same series or model to set up a main-sub network. If mixed usage is necessary, it is advisable to configure the code reader with the lower resolution as the main station.
-



**Figure 9-56 Example of Adding Sub Cameras**

5. Double-click the sub code reader tab in the **Sub Cameras** area to open the configuration panel. Set the following parameters:

### Common Parameters

#### Main-Sub Operation Mode

Select the same mode as the main code reader.

#### Station Role

Select **Sub**.

#### Main-Sub Group ID

Enter the same group ID as the main code reader to ensure they are in the same network.

#### Station ID

It will be automatically assigned once the connection to the main code reader is established.



This parameter is read-only and cannot be edited.

---

#### Main Station IP

It will be automatically displayed once the connection to the main code reader is established.



This parameter is read-only and cannot be edited.

---

#### Main Station Connection Status

A value of 1 means that the data transmission is normal, and 0 means that there is no connection.

---

### **Note**

This parameter is read-only and cannot be edited.

---

### **Advanced Parameters**

The following parameters are read-only and cannot be edited.

#### **Main Station Name**

It refers to the user name of the main code reader.

#### **Main Station Model**

It refers to the model name of the main code reader.

#### **Main Station Serial Number**

It refers to the serial No. of the main code reader.

6. Configure the main-sub station trigger source according to the actual scenario. For the operation details, refer to section [Signal Input Settings](#).

To ensure the consistency of all code readers when using the main-sub network, the following two methods can be selected.

- Configure both main and sub code readers to use the same trigger source, such as LineIn 0/1/2/3. This ensures that all code readers are triggered simultaneously.
  - Set the main code reader to any supported trigger source and configure the sub code readers to "Main Sub" as their trigger source. Both main and sub code readers can be triggered at the same time.
- 

### **Note**

It is not commended to use "Self Trigger" for the main and sub station. Because it is difficult to ensure consistent triggering between the main and sub devices.

---

7. Under the page of **Main Sub Configuration** of the Main Camera, you can operate the following configurations.
    - Start/Stop: You can start or stop image acquisition.
- 

### **Note**

When the trigger source of the sub code readers is set to "Main Sub", sub devices should be in image acquisition mode to receive and respond to the main station's trigger signal.

---

- Check grabbing results: Check the decoding results in the **Grabbing Result** area. This view is consistent with the **History** section in the main window.
  - Remove sub devices: Click  in the sub station area.
- 

### **What to do next**

After the main-sub configuration is finished, you can proceed to configure data processing rules and data output settings. Refer to section [Data Processing Settings](#) and section

---

[Communication Settings](#) for details.

## 9.9.2 Multicast

A multicast network of multiple code readers includes one main code reader and several sub code readers. The main code reader is used for synchronizing trigger numbers, while all code readers transmit decoding data to the code-reading platform independently. The primary principle of multicast networking is to configure one of the code readers as the main device and the remaining code readers as sub devices. Both main and sub code readers trigger image acquisition simultaneously. The main code reader synchronizes trigger numbers with other sub code readers, and all code readers transmit decoding data to the code-reading platform. The platform integrates and processes the data based on trigger numbers and outputs integration results. This mode is suitable for logistics multi-side scanning scenarios (typically involving more than three code readers), enabling cooperation working across multiple cameras by integrating all outputs from main and sub code readers through the code reading platform.

You can go to **Operator Settings** → **Net Config** → **Group Broadcast** on the Navigation Bar of the main window to configure the following parameters.

---

### Note

IDMVS does not support simultaneous configuration of multicast and main-sub operation functions.

---




Figure 9-57 Group Broadcast

### Multicast Mode

Select whether to enable multicast mode or configure the operating mode of the connected code reader. The supported modes are introduced below.

- **Off**: Disable multicast mode.
- **Main**: Configure the connected code reader as the main code reader, which simultaneously sends trigger numbers to sub code readers.
- **Sub**: Configure the connected code reader as the sub device.

### Multicast Group ID

After selecting main or sub in **Multicast Mode**, you can specify the multicast group index of the code reader through this parameter. Devices with the same index belong to the same group.

## 9.9.3 Multi Frame

The client supports single- or multi-window previews. You can adjust the division based on the number of connected the code readers or other code reading requirements. The client provides three default divisions: 1-Window, 4-Window, and 9-Window. Custom divisions are also available if needed.

### Before You Start

Make sure the code reader(s) has been connected.

### Steps

1. Click **Multi Frame** on the quick access toolbar, and then select **1-Window**, **4-Window**, **9-Window**, or **Custom** as needed.

---

#### Note

If **Custom** is unselected, proceed to Step 3.

---

2. (Optional) Customize window division.
  - 1) In the **Custom Division** window, click **Add** in the upper-left corner.

---

#### Note

Up to 4 custom divisions can be added. You can select and click **Delete** to remove invalid divisions.

---

- 2) Enter a division name and click **OK**.
- 3) Select the optimal grid under **Window Division**, with options including **2x2**, **3x3**, and **4x4**.
- 4) Adjust the division by clicking **Merge** to merge the adjacent windows or clicking **Split** to split the merged windows.


---

#### Note

Up to 16 windows are supported.


---

- 5) Click **Save**.
3. Select code reader for preview.
    - In 1-window mode, the selected code reader is displayed by default. To switch windows, drag other connected code readers from the device list to the preview window. The 1-window preview is shown below.



**Figure 9-58 1-Window Preview**

- In multi-window division, drag multiple connected code readers from the device list to the preview window. Click  in the upper-right corner to unlink the code reader. A custom 3-window preview is shown below.



**Figure 9-59 Multi-Window Preview**

4. Click **Read Config** → **Fast Config** → **Real Grabbing** on the left, or click  on the left of the preview toolbar to check image capture.

## What to do next

Refer to section [Quick Start Guide](#) for fast debugging of image capture and code reading, and preview real-time images in the preview area.

## 9.10 Lua Script

### Note

- This section is available for IDTVS V5.0 and later.
- Lua Script is available for some device models.

The Lua Script is an embedded scripting language featuring concise syntax, high execution efficiency, and easy integration. IDTVS supports custom configurations for code reader format output and data filtering through Lua scripts.

In the navigation bar of the main interface, select **Operator Settings** → **Data Processing** → **Lua Script** to access the Lua Script page, as shown in the following picture.




Figure 9-60 Lua Script

The descriptions of each module are in the table below.

Table 9-21 Lua Script Module Description

| No. | Module Name         | Function Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Script Editing Area | <p>It is used for editing Lua script code.</p> <hr/> <p><b>Note</b></p> <p>The script editing area supports real-time syntax notification.</p> <hr/> <p>Button functions in the script editing area are introduced below:</p> <ul style="list-style-type: none"> <li>• <b>Script Enable:</b> Select whether to enable the format output function of the Lua Script. Once it is enabled, format output cannot be configured.</li> </ul> <hr/> <p><b>Note</b></p> <p>When the script contains formatting-related API, it will be enabled automatically.</p> <hr/> <ul style="list-style-type: none"> <li>• <b>Open:</b> Open the local script files.</li> <li>• <b>Load:</b> Load script files from the code reader.</li> <li>• <b>Export:</b> Export Lua scripts from the code reader to the selected directory.</li> <li>• <b>Test:</b> Execute the scripts in the script editing area and view the results in the output area.</li> <li>• <b>Import to Camera:</b> Save the scripts in the script editing area to the connected code reader.</li> <li>• <b>Save to Local:</b> Save the scripts in the script editing area as Lua files to the local.</li> </ul> |

| No. | Module Name        | Function Description                                                                                                                                                                                                                                                                   |
|-----|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2   | Script Output Area | <p>You can view script execution results here.</p> <ul style="list-style-type: none"> <li>• If compilation is successful, this area will show <b>Verify Success</b> with test results.</li> <li>• If compilation is failed, it will display error details and line numbers.</li> </ul> |
| 3   | API List           | <p>Display supported Lua APIs and related descriptions.</p> <hr/> <p> <b>Note</b></p> <p>Some APIs provide sample codes. You can check and copy sample codes.</p> <hr/>                               |

Using the Lua Script requires some cautions and procedures. Refer to the latest version of **IDMVS Client Software User Manual** for details.

## 9.11 Contrast Control Settings

### Note

You need to set device's running mode as normal before using this function.

The contrast control function compares the data that the device reads with preset data and outputs contrast result. The result can be used as the event source of trigger signal, including **Contrast Success** and **Contrast Fail**. This function has two ways to contrast, including regular contrast and consecutive number contrast.

### Regular Contrast


The regular contrast requires you to set code contents in advance, and the client software will contrast the data that the device reads with preset contents and outputs comparison result.

#### Steps

1. Right click the device in **Device Connection**, and click **Feature Tree**.
2. Go to **Contrast Control**, enable **Contrast Enable**, and select **Regular** as **Contrast Rules**.
3. Set **Start Position** that means the starting position of the comparison.
4. Set **Character Number** that means the comparison quantity.
5. Set code contents in **Wildcard String**.

### Note

You can use wildcard \* and ?. \* stands for multiple strings you can use, and ? stands for one string you can use. \* can be used once only and ? can be used many times.



**Figure 9-61 Regular Contrast**

## Consecutive Number Contrast

The consecutive number contrast requires you to set consecutive code rules, and the client software will contrast the data that the device reads with preset rules and outputs contrast result.

### Steps

1. Right click the device in **Device Connection**, and click **Feature Tree**.
2. Go to **Contrast Control**, enable **Contrast Enable**, and select **Consecutive Number** as **Compare Rules**.
3. Set **Start Position** that means the stating position of the comparison.
4. Set **Digital Number** that means the comparison quantity.
5. Set **Step** that means the client software will increase or decrease the preset value after each comparison according the step you set.

---

### Note

- If the preset value after increase or decrease exceeds the digital number you set, and then the preset value will become 0.
- The base value displays the preset value.

- 
6. (Optional) Click **Execute** in **Contrast Reset** to reset comparison. After that, the client software will use the first code it reads as the preset value.

Here we take start position (3), digital number (2) and step (2) as an example to explain the consecutive number comparison:

- If the first code that the device reads is ur96k, and then the preset value is 96. The preset value increases to 98 (96+2).
- If the second code is yr98kjkfd, and comparison succeeds. The preset value increases to 100 (98+2).
- If the third code is kl99fjkd, and comparison fails. The preset value does not increase.
- If the fourth code is kl00djf, and comparison succeeds. The preset value increases to 02 (00+2).




Figure 9-62 Consecutive Number Contrast

## 9.12 User Set Customization

In **Configuration Management**, you can set and manage the user set. A user set is a group of parameter values with all the settings needed to control the device, and you can save, load and switch different user sets.

- **Save Settings:** If you have set the device parameters as desired, you can save them into the user set. Go to **Config Management** → **Save Settings**, and click **UserSet1**, **UserSet2**, or **UserSet3** to save the current device settings.
- **Load Settings:** You can load the user set to restore the device to the saved group of parameter values again if required. Go to **Config Management** → **Load Settings**, and click **Default**, **UserSet1**, **UserSet2**, or **UserSet3** to load settings.

---

### Note

The **Default** refers to restore the device parameter settings to the factory ones.

---

- **Start Settings:** The selected user set will be automatically loaded after the device being powered on. For example, if you select **Default**, the device parameter settings will be restored to the factory settings.




Figure 9-63 User Set Customization

## 9.13 Statistics Information

The statistics information in the feature tree helps you to count data related with code reading.

---

### Note

You need to set device's running mode as normal before using this function.

---

### Steps

1. Right click the device in **Device Connection**, and click **Feature Tree**.
2. Go to **Feature Tree**, find **Statistics Info.**, and select **Statistics Mode**:
  - **All Frames** means the client software will display all data since the device is powered on.
  - **Latest Frames** means the client software will display data of the last 10 frames.
3. View related parameters.
4. (Optional) Click **Execute** in **Reset Statistics** to reset statistics information.

Table 9-22 Parameter Description

| Parameter Name      | Description                                           |
|---------------------|-------------------------------------------------------|
| Total Frame Number  | The total frame quantity.                             |
| Read Frame Number   | The quantity of frames that have been read codes.     |
| Noread Frame Number | The quantity of frames that have not been read codes. |
| Read Rate           | It refers to the code reading ratio.                  |
| Algo Time Ave       | The average time of algorithm, and the unit is ms.    |
| Algo Time Max       | The max. time of algorithm, and the unit is ms.       |
| Algo Time Min       | The min. time of algorithm, and the unit is ms.       |
| Read Time Ave       | The average time of code reading, and the unit is ms. |

| Parameter Name   | Description                                           |
|------------------|-------------------------------------------------------|
| Read Time Max    | The max. time of code reading, and the unit is ms.    |
| Read Time Min    | The min. time of code reading, and the unit is ms.    |
| Reset Statistics | Click <b>Execute</b> to reset statistics information. |

The screenshot shows a dark-themed panel titled "Statistics Info" with a dropdown arrow. It contains several rows of statistics, each with a label on the left and a numeric value (all are 0) on the right, accompanied by up and down arrow icons. The statistics are: Statistics Mode (set to "All Frames"), Total Frame Number, Read Frame Number, Noread Frame Number, Read Rate(%), Algo Time Ave(ms), Algo Time Max(ms), Algo Time Min(ms), Read Time Ave(ms), Read Time Max(ms), and Read Time Min(ms). At the bottom, there is a "Reset Statistics" label and an "Execute" button.

Figure 9-64 Statistics Information

## 9.14 Diagnose Event Report

The diagnose event report function monitors memory and CPU usage rate, and let you know when there is a crash, higher CPU usage rate, insufficient memory, and other events.

### Steps

1. Right click the device in **Device Connection**, and click **Feature Tree**.
2. Go to **Feature Tree**, and find **Diagnose Event Report**.
3. View related information.
4. (Optional) Click **Execute** in **Reset Event** to clear all information.

The screenshot shows a dark-themed panel titled "Diagnose Event Report" with a dropdown arrow. It contains several rows of event information, each with a label on the left and a value on the right: Event Code (0x0), Event Name (UnKnown), Event Report Time (19700101\_004234811), and Event Detail (■■■■59). At the bottom, there is a "Reset Event" label and an "Execute" button.

Figure 9-65 Event Report

## Chapter 10 Device Maintenance

### 10.1 Update Firmware

The device supports updating firmware via the client software.

---

#### Note

- Disconnect the device with client software.
  - Please use the firmware package of the corresponding device model for upgrading.
  - Do not power off the device or disconnect network during upgrading.
  - The device will reboot automatically after updating the firmware.
- 

#### Steps

1. Select the device to be updated in the device list, and right click the device.
  2. Click **Firmware Update**.
  3. Click  to select update file from local PC, and click **Update** to update firmware.
- 

#### Note

You can also go to **Tool** → **Firmware Updater** to update firmware.

---




Figure 10-1 Update Firmware

### 10.2 Set Time

After enabling NTP time synchronization, the device will synchronize time according to the configured interval.

#### Steps

1. Go to **Config Management**, and find **Timing**.
  2. Click **Setting** and enable **NTP Enable**.
  3. Set parameters according to actual demands.
- 

#### Note

Configure NTP server settings before using NTP time synchronization function.

---

4. Click **OK** after settings.




Figure 10-2 Set NTP Timing

## 10.3 Enable Device Auto Work

This function allows the device to automatically enter the operation status after being powered on.

You can go to **Config Management** → **Device Auto Work Enable**, and enable **Device Auto Work Enable**.





Figure 10-3 Enable Device Auto Work

## 10.4 Restart Device

You can restart the device via client software in 2 ways. Go to **Config Management**, and click **Restart Device**. Or, you can select the device to be restarted in the device list, right click the

device, and click **Device Reset**.



**Figure 10-4 Restart Device**

## Chapter 11 FAQ (Frequently Asked Question)

### 11.1 Why there is no device listed after I run the IDMVS client software?

Table 11-1 Question 1

| Possible Cause             | Solution                                                                                                                                                                                                                                       |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The device is powered off. | Check the device's power connection (observe whether the PWR indicator is solid green) to make sure the device is powered up normally.                                                                                                         |
| Network exception occurs.  | Check the network connection (the LNK indicator is flashing green if the network exception occurs) to make sure the device can be connected to the network normally, and make sure that the PC and the device are in the same network segment. |

### 11.2 Why the image is very dark?

Table 11-2 Question 2

| Possible Cause                           | Solution                                                                            |
|------------------------------------------|-------------------------------------------------------------------------------------|
| Insufficient brightness of light source. | Increase the brightness of light source appropriately, or change to a brighter one. |
| Too small value of exposure and gain.    | Increase exposure and gain appropriately.                                           |

### 11.3 Why the image's frame rate is very low in the live view?

Table 11-3 Question 3

| Possible Cause                           | Solution                                                    |
|------------------------------------------|-------------------------------------------------------------|
| Network circuitry speed is not 100 Mbps. | Check whether the network transit speed is 100 Mbps or not. |

## 11.4 Why there is no image in the live view?

**Table 11-4 Question 4**

| Possible Cause                                        | Solution                                                            |
|-------------------------------------------------------|---------------------------------------------------------------------|
| Enabled trigger mode, but there is no trigger signal. | Sent the trigger signal to the device, or disable the trigger mode. |
| Network circuitry speed is not 100 Mbps.              | Check whether the network circuitry speed is 100 Mbps or not.       |

## Chapter 12 Revision History

Table 12-1 Revision History

| Version No. | Date          | Revision Details                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------------|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| V4.2.0      | May 18, 2026  | <ul style="list-style-type: none"> <li>• Delete C-mount device information in Section <a href="#">Appearance</a>.</li> <li>• Add Section <a href="#">Debugging via Configuration Codes</a>.</li> <li>• Update Sections <a href="#">Device Connection</a> and <a href="#">Quick Start Guide</a> of IDMVS V5.0.0.</li> <li>• Add Chapter <a href="#">Configuration Codes</a>.</li> <li>• Update Sections <a href="#">Set Parameter Polling</a>, <a href="#">Characters Replace</a>, <a href="#">Multi-Reader Synchronization</a>, and <a href="#">Lua Script</a> of IDMVS V5.0.0.</li> </ul>                                                                                             |
| V4.1.0      | May 20, 2025  | <ul style="list-style-type: none"> <li>• Edit Section Appearance, Table 3-3 Component Description.</li> <li>• Edit Section Device Wiring, ID2000EM series devices with network interface and ID2000EM series devices with USB interface.</li> <li>• Edit Section ID2000EM Series Devices with Network Interface.</li> <li>• Edit Section ID2000EM Series Devices with USB Interface (Without I/O Function).</li> <li>• Edit Section ID2000EM Series Devices with USB Interface (With I/O Function).</li> <li>• Add Section Opto-Isolated I/O.</li> <li>• Edit Section Signal Input Settings, Set and Execute Hardware Trigger Mode.</li> <li>• Edit Section Set TCP Server.</li> </ul> |
| V4.0.0      | Mar. 31, 2025 | Edit the whole structure and content.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

## Appendix A ASCII Table

### Note

The device with USB interface only supports the red color character only regarding setting prefix and suffix characters.

**Table A-1 ASCII Table**

| Character | Value | Character | Value | Character | Value | Character | Value |
|-----------|-------|-----------|-------|-----------|-------|-----------|-------|
| NUL       | 0     | (SPACE)   | 20    | @         | 40    | `         | 60    |
| SOH       | 1     | !         | 21    | A         | 41    | a         | 61    |
| STX       | 2     | "         | 22    | B         | 42    | b         | 62    |
| ETX       | 3     | #         | 23    | C         | 43    | c         | 63    |
| EOT       | 4     | \$        | 24    | D         | 44    | d         | 64    |
| ENQ       | 5     | %         | 25    | E         | 45    | e         | 65    |
| ACK       | 6     | &         | 26    | F         | 46    | f         | 66    |
| BEL       | 7     | '         | 27    | G         | 47    | g         | 67    |
| BS        | 8     | (         | 28    | H         | 48    | h         | 68    |
| HT        | 9     | )         | 29    | I         | 49    | i         | 69    |
| LF/NL     | 0a    | *         | 2a    | J         | 4a    | j         | 6a    |
| VT        | 0b    | +         | 2b    | K         | 4b    | k         | 6b    |
| FF/NP     | 0c    | ,         | 2c    | L         | 4c    | l         | 6c    |
| CR        | 0d    | -         | 2d    | M         | 4d    | m         | 6d    |
| SO        | 0e    | .         | 2e    | N         | 4e    | n         | 6e    |
| SI        | 0f    | /         | 2f    | O         | 4f    | o         | 6f    |
| DLE       | 10    | 0         | 30    | P         | 50    | p         | 70    |
| DC1/XON   | 11    | 1         | 31    | Q         | 51    | q         | 71    |
| DC2       | 12    | 2         | 32    | R         | 52    | r         | 72    |
| DC3/XOFF  | 13    | 3         | 33    | S         | 53    | s         | 73    |
| DC4       | 14    | 4         | 34    | T         | 54    | t         | 74    |
| NAK       | 15    | 5         | 35    | U         | 55    | u         | 75    |

| Character | Value | Character | Value | Character | Value | Character | Value |
|-----------|-------|-----------|-------|-----------|-------|-----------|-------|
| SYN       | 16    | 6         | 36    | V         | 56    | v         | 76    |
| ETB       | 17    | 7         | 37    | W         | 57    | w         | 77    |
| CAN       | 18    | 8         | 38    | X         | 58    | x         | 78    |
| EM        | 19    | 9         | 39    | Y         | 59    | y         | 79    |
| SUB       | 1A    | :         | 3A    | Z         | 5A    | z         | 7A    |
| ESC       | 1B    | ;         | 3B    | [         | 5B    | {         | 7B    |
| FS        | 1C    | <         | 3C    | \         | 5C    |           | 7C    |
| GS        | 1D    | =         | 3D    | ]         | 5D    | }         | 7D    |
| RS        | 1E    | >         | 3E    | ^         | 5E    | ~         | 7E    |
| US        | 1F    | ?         | 3F    | _         | 5F    | DEL       | 7F    |



***HIKROBOT***

SHAPE OUR FUTURE INTELLIGENTLY

**Hikrobot Co., Ltd.**

Tel: 400-989-7998

Website: <https://en.hikrobotics.com/>

**UD46682B**